

Nikdy nepoužívejte abrazivní čisticí prostředky nebo materiály, neboť poškodují neprůhledný povrch desek.

Nikdy neponořujte přístroj do vody.

1 Přístroj odpojte od sítě a nechte ho vychladnout.

2 Než desky vyjmete, nejprve otřete papírovou utěrkou zbytky oleje.

3 Vymítejte grilovací desky (Obr. 14).

Chcete-li desky vyjmout, stiskněte upevňovací svorky na zařízení a poté desky zvedněte a vytáhněte je ze zařízení.

4 Otvrite grilovací desky měkkým hadříkem nebo houbou namočenou v horké vodě s trochu čisticího prostředku. Můžete je také umýt v myčce nádobí (Obr. 15).

Namočte grilovací desky na pět minut do horké vody s přídavkem myčky prostředu, abyste odstranili zbytky potravin. Tím se uvolní zaschlé jídlo a mastnotu.

5 Grilovací desky vysušte a vrátěte je zpět (Obr. 16).

Umištěte přístroj do opěkací grilovací polohy.

Umištěte zadní hrany grilovacích desek na přístroj (1).

Spouštějte grilovací desky na přístroj a zatlačte je smírem dolů pod upevňovací svorky (2).

6 Vnější povrch přístroje čistěte navlhčeným hadříkem.

Výměna

Výměna baterie čásovače (pouze u modelu HD4408/HD4469)

Baterie vydří přibližně dva roky v případě normálního domácího používání. Tento přístroj využívá 1 litrovou knoflíkovou baterii typu L1131 (1,55V), která je běžně k dostání.

1 Umištěte přístroj do opěkací grilovací polohy a odstraňte šroub ze závěsu (Obr. 17).

2 Přístroj užavíte, otočte jej a umištěte do svislé polohy (1).

Vymítejte horní šroub (2) a dolní šroub (3) ze závěsu (Obr. 18).

3 Sejměte ze závěsu kryt závěsu a vymítejte z krytu závěsu čásovač (Obr. 19).

4 Pomocí mince otevřete kryt přihrádky na baterii čásovače a vymítejte starou baterii. Starou baterii zlikvidujte (viz kapitola „Recyklyace“) (Obr. 20).

5 Vložte novou baterii do přihrádky na baterii tak, aby kladný polí směřoval ke krytu přihrádky na baterii (Obr. 21).

6 Umištěte kryt přihrádky na baterii zpět na čásovač. Pomocí mince jej opět utahněte.

7 Vložte čásovací do krytu závěsu a znova připojte kryt závěsu k závěsu.

8 Vložte a utáhněte šrouby v obřázém pořadí. Začněte s přístrojem ve svíslé poloze a poté umištěte přístroj do opěkací grilovací polohy.

Recykldace

Symbol na výrobku znamená, že výrobek splňuje evropskou směrnici 2012/19/EU (Obr. 22).

Symbol na výrobku znamená, že výrobek obsahuje materiál splňující evropskou směrnici 2006/66/EC, takže nemůže být likvidován společně s běžným domácím odpadem (Obr. 23).

Zjistěte si informace o místním systému sběru tříděného odpadu elektrických a elektronických výrobků a baterií. Dodržujte místní předpisy a nikdy nelikvidujte výrobek nebo baterie společně s běžným domácím odpadem. Správnou likvidaci starých výrobků a baterií pomůžete předejít negativním dopadům na životní prostředí a lidské zdraví.

Vyjmout baterie (pouze modely HD4408/HD4469)

Baterie vymějte podle pokynů v kapitole „Výměna“, část „Výměna baterie čásovače (pouze u modelu HD4408/HD4469)“.

Skladování

1 Sítový kabel oviněte okolo držáku pro uložení kabelu umístěném v závěse přístroje. (Obr. 24)

2 Zaržení skladujte ve svíslé poloze na bezpečném a suchém místě.

Záruka a podpora

Vice informací a podpory naleznete na adrese www.philips.com/support nebo samostatném záručním listu s celosvětovou platností.

Tabulka pokrmů (Obr. 25)

1 Tabulka pokrmů

HRVATSKI

Uvod

Čestitamo na kupnji i dobro došli u Philips! Kako biste u potpunosti iskoristili podršku koju nudi tvrtka Philips, registrirajte svoj proizvod na: www.philips.com/welcome.

Opći opis (Sl. 1)

A Roštíl (samo HD4407/HD4467)

1 Crveni indikator temperature

2 Kontrola temperature

3 Grijanje ploče

4 Kopče za přihrávání grijajících ploča

5 Rukce koje se ne zagnjavaju tijekom rada

6 Odvodni žlijeb

7 Držaći za kabel

B Roštíl (samo HD4408/HD4469)

1 Crveni indikator napajanja

2 Zeleni indikator spremnosti

3 Kontrola temperature

4 Grijanje ploče

5 Kopče za přihrávání grijajících ploča

6 Nosac koji se ne zagnjava

7 Drška koja se ne zagnjava

8 Odvodni žlijeb

9 Gumb timer-a

10 Zaslon timer-a

11 Držaći za kabel

Važno

Prije uporabe aparata pažljivo pročitajte ovaj korisnički priročnik i spremite ga za buduće potrebe.

Opasnost

- Nikada ne uranjajte aparat ili mrežni kabel u vodu ili neku drugu tekućinu.

Upozorenje

- Prije učinkovanja aparata provjerite odgovara li mrežni napon naveden na aparatu naponu lokalne mreže. Informacije o naponu i snazi potražite na plочici s označkami na aparatu.

- Ako se kabel za napajanje ošteti, mora ga zamjeniti tvrtka Philips, ovašteni Philips servisni centar ili neka druga kvalificirana osoba kako bi se izbjegle potencijalno opasne situacije.

- Aparat mogu upotrebljavati djeca starija od 8 godina i osobe sa smanjenim fizičkim, senzornim ili mentalnim sposobnostima te osobe koje nemaju dovoljno iskustva i znanja, pod uvjetom da su pod nadzorom ili da su bilo upute za rukovanje aparatom na siguran način te da razumiju moguće opasnosti. Djeca se ne smiju igратi aparatom. Čistiti i održavati aparat smiju samo djeca starija od 8 godina koja su pod nadzorom.

- Kabel za napajanje držite podalje od vrućih površina.

- Ne ostavljamte aparat da radi bez nadzora.

Oprez

- Aparat priključujte samo u uzemljenu zidnu utičnicu.

- Aparat stavite na ravnu, stabilnu površinu uz dovoljno slobodnog prostora oko njega.

- Ploče obavezno zagnjite prije stavljanja bilo kakve hrane na njih.

- Dostupne površine aparata mogu postati vruće tijekom rada aparata (Sl. 2).

- Pazite na prskanje ulja tijekom pečenja masnog mesa ili kobasica.

- Prije iskopčavanja aparata obavezno okrenite regulator temperature na 0.

Fontos!

A készülék első használata előtt figyelmesen olvassa el a használati útmutatót, és órizze meg későbbi használatra.

Vigyáztat!

- Ne merítse a készüléket vagy a hálózati csatlakozatot kábel bízból vízhez.

Figyelmeztetés

- A készülék csatlakoztatása előtt ellenőrizze, hogy a készülék felkészített pečenjűséghez-e a hálózati feszültséggel.

- Tijekom odvođavanju preostalo vrijeme treperi na zaslonu.

Napomena: Postavku timera možete izbrisati pritiskom na gumb timer-a u trajanju od 3 sekunde (u trenutku kada vrijeme zatrepi) dok se ne pojavi '00'.

3 Kada istekne podeseno vrijeme, začut će zvučni signal.

Nakon 10 sekundi zvučni signal se ponavlja. Za isključivanje signala pritisnite gumb timer-a.

Vrijeme pečenja

Na početku ovog korisničkog priročnika možete pronaći tablicu hrane koju možete pripremiti na roštiju. Tablica prikazuje koju temperaturu trebate odabrat, koliko duže se hrana mora peći i odgovarajući položaj roštija. Vrijeme pečenja ovisi o vrsti hrane, ali i o načinu pripreme.

Maksimalno vrijeme koje se može postaviti je 99 minuta.

4 Nekoliko sekundi nakon unosa vremena pečenja, timer će započeti odvođavanje.

Tijekom odvođavanja preostalo vrijeme treperi na zaslonu.

Napomena: Postavku timera možete izbrisati pritiskom na gumb timer-a u trajanju od 3 sekunde (u trenutku kada vrijeme zatrepi) dok se ne pojavi '00'.

5 Kada istekne podeseno vrijeme, začut će zvučni signal.

Nakon 10 sekundi zvučni signal se ponavlja. Za isključivanje signala pritisnite gumb timer-a.

Timer (samo HD4408/HD4469)

Timer označava kraj pripreme, ali NE isključuje aparat.

Napomena: Roštij možete koristiti i bez postavljanja timera.

1 Pritisnite gumbe timera kako biste namjestili vrijeme pečenja u minutama (Sl. 13).

2 Postavljeno vrijeme vidjet će se na zaslonu.

3 Držite gumbe pritisnutim kako biste brže pomicali minute.

Kada postavite željeno vrijeme pečenja, otpustite gumb.

Maksimalno vrijeme koje se može postaviti je 99 minuta.

4 Nekoliko sekundi nakon unosa vremena pečenja, timer će započeti odvođavanje.

Tijekom odvođavanja preostalo vrijeme treperi na zaslonu.

Napomena: Postavku timera možete izbrisati pritiskom na gumb timer-a u trajanju od 3 sekunde (u trenutku kada vrijeme zatrepi) dok se ne pojavi '00'.

5 Kada istekne podeseno vrijeme, začut će zvučni signal.

Nakon 10 sekundi zvučni signal se ponavlja. Za isključivanje signala pritisnite gumb timer-a.

Fontos!

A készülék első használata előtt figyelmesen olvassa el a használati útmutatót, és órizze meg későbbi használatra.

Vigyáztat!

- Ne merítse a készüléket vagy a hálózati csatlakozatot kábel bízból vízhez.

Figyelmeztetés

- A készülék csatlakoztatása előtt ellenőrizze, hogy a készülék felkészített pečenjűséghez-e a hálózati feszültséggel.

- Tijekom odvođavanju preostalo vrijeme treperi na zaslonu.

Napomena: Postavku timera možete izbrisati pritiskom na gumb timer-a u trajanju od 3 sekunde (u trenutku kada vrijeme zatrepi) dok se ne pojavi '00'.

3 Kada istekne podeseno vrijeme, začut će zvučni signal.

Introduction

Congratulations on your purchase and welcome to Philips! To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome.

General description (Fig. 1)

- 1 Grill (HD4407/HD4467 only)
- 2 Red temperature light
- 3 Temperature control
- 4 Grilling plates
- 5 Fixing clips of grilling plates
- 6 Cool-touch handgrips
- 7 Drainage groove
- 8 Cord storage facility
- 9 Grill (HD4408/HD4469 only)
- 10 Red power-on light
- 11 Green ready-to-cook light
- 12 Temperature control
- 13 Grilling plates
- 14 Fixing clips of grilling plates
- 15 Cool-touch bracket
- 16 Cool-touch handgrip
- 17 Drainage groove
- 18 Timer button
- 19 Timer display
- 20 Cord storage facility

Important

Read this user manual carefully before you use the appliance and save it for future reference.

Danger

- Do not immerse the appliance or the mains cord in water or any other liquid.

Warning

- Check if the voltage indicated on the appliance corresponds to the local mains voltage before you connect the appliance. Check the type plate on the appliance for information on voltage and wattage.
- If the mains cord is damaged, you must have it replaced by Philips, a service centre authorised by Philips or similarly qualified persons in order to avoid a hazard.
- The appliance can be used by children aged 8 or above and by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised.
- Keep the mains cord away from hot surfaces.
- Do not let the appliance operate unattended.

Caution

- Only connect the appliance to an earthed wall socket.
- Put the appliance on a flat, stable surface with sufficient free space around it.
- Always preheat the grilling plates before you put any food between them.
- The accessible surfaces may become hot when the appliance is operating (Fig. 2).
- Be careful of spattering fat when you grill fatty meat or sausages.
- Always turn the temperature control to 0 before you unplug the appliance.
- Always unplug the appliance after use.
- Always clean the appliance after use.
- Let the appliance cool down completely before you remove the grilling plates, clean the appliance or put it away.
- Never touch the grilling plates with sharp or abrasive items, as this damages the non-stick surface.
- Make sure you reassemble the grilling plates properly after you have removed them.
- This appliance is intended for normal household use only. It is not intended for use in environments such as staff kitchens of shops, offices, farms or other work environments. Nor is it intended to be used by clients in hotels, motels, bed and breakfasts and other residential environments.
- This appliance is not intended to be operated by means of an external timer or a separate remote-control system.
- If the appliance is used improperly or for professional or semi-professional purposes or if it is not used according to the instructions in the user manual, the guarantee becomes invalid and Philips refuses any liability for damage caused.

Electromagnetic field (EMF)

This Philips appliance complies with all applicable standards and regulations regarding exposure to electromagnetic fields.

Before first use

- 1 Remove the insert between the grilling plates and remove any stickers.
- 2 Wipe the outside of the appliance with a damp cloth.
- 3 Clean the grilling plates thoroughly (see chapter 'Cleaning').

Note: The appliance may produce some smoke when you use it for the first time. This is normal.

Using the appliance**Three grilling positions**

- Contact grill position (Fig. 3)

This position is especially suitable for quick high-temperature grilling on both sides (rump steaks, hamburgers etc.) and for making toasted sandwiches or paninis.

Note: Both grilling plates are in contact with the food.

- Oven grill position (Fig. 4)

This is the ideal position to grill and cook au gratin at the same time. The oven grill position is also suitable for the preparation of all kinds of 'open' toasts, e.g. with egg, tomato, peppers and/or onion rings, covered with cheese.

Note: The upper grilling plate must not touch the food.

- Barbecue grill position (Fig. 5)

In this position, the grill offers a large grilling surface for the preparation of all kinds of snacks, such as shashlik, satay, vegetables, fruits etc.

1 Fully unwind the mains cord from the storage facility in the hinges of the appliance (Fig. 6).

2 Make sure the grill is closed. Then put the plug in the wall socket (Fig. 7). HD4408/HD4469 only: The red power-on light goes on to indicate that the grill is connected to the mains.

3 Turn the temperature control to the temperature setting that is appropriate for the ingredients to be grilled. See the food table at the beginning of this user manual.

The red light indicates that the grill is heating up.

Never let the appliance operate unattended.

4 Let the appliance heat up.

- HD4408/HD4469 only: Wait until the green ready-to-cook light goes out.

5 Open the grill to put the ingredients on the grilling plate or plates.

Be careful: the grilling plates are hot.

- Contact grill and oven grill positions: open the grill halfway (Fig. 8).

Barbecue grill position: open the grill halfway and pull the upper grilling plate up to its highest position (1). Then put the grill in open position (2) (Fig. 9).

6 Place a bowl or plate under the drainage groove to collect fat or juice.

7 Place the ingredients on the grilling plate or plates (Fig. 10).

For an optimal result, place the ingredients in the centre of the grilling plate or plates.

The grilling time depends on the type of ingredients, their thickness and your personal taste. See the food table at the beginning of this user manual for recommended grilling times.

Note for HD4408/HD4469: During the grilling process, the green ready-to-cook light goes out.

Note for HD4407/HD4467: During the grilling process, the temperature light goes on from time to time. This indicates that the grill is heating up to keep the grilling temperature at the preset level.

- Contact grill position and oven grill position: put the food in the middle of the lower grilling plate.

- Barbecue grill position: spread the food on top of the grilling surface. Turn the food from time to time with a wooden or plastic spatula.

8 Close the grill (only for contact grill and oven grill positions).

- Contact grill position: lower the upper grilling plate centrally onto the ingredients. The upper grilling plate now rests on the food. In this way, the food is grilled evenly on both sides (Fig. 11).

- Oven grill position: pull the upper grilling plate up to its highest position (1) and then put it in horizontal position (2). The upper grilling plate must not touch the food (Fig. 12).

9 Open the appliance when the required grilling time has elapsed (only for contact grill and oven grill positions).

10 Remove the food with a wooden or plastic spatula.

Do not use metal, sharp or abrasive kitchen utensils.

11 If you want to grill another batch of food, remove excess oil from the plates with a piece of kitchen paper.

12 Wait until the green ready-to-cook light goes on (HD4408/HD4469 only) or the temperature light goes out (HD4407/HD4467 only) before you put the food on the grilling plate or plates.

Timer (HD4408/HD4469 only)

The timer indicates the end of the grilling time, but does NOT switch off the appliance.

Note: You can also use the grill without setting the timer.

1 Press the timer button to set the grilling time in minutes (Fig. 13).

2 The set time becomes visible on the display.

2 Keep the button pressed to put the minutes forward quickly.

Release the button once the required grilling time has been reached.

The maximum time that can be set is 99 minutes.

3 Seconds after you have set the grilling time, the timer starts to count down.

4 While the timer counts down, the remaining grilling time flashes on the display. The last minute is displayed in seconds.

Note: You can erase the timer setting by pressing the timer button for 3 seconds (at the moment the time flashes) until '00' appears.

5 When the preset time has elapsed, you hear an audible signal.

After 10 seconds, the audible signal is repeated. Press the timer button to stop the audible signal.

Grilling times

At the beginning of this user manual, you find a food table with ingredients you can prepare with the grill. The table gives indications of which temperature to select, how long the food has to be grilled and the appropriate position of the grill. The time necessary to preheat the appliance is not included in the indicated grilling time.

The actual grilling time and temperature depend on the type of food that is prepared (e.g. meat), its thickness and its temperature and also on your own taste. See also the indications on the grill.

Tips

- Lightly grease the food to be grilled (instead of the grilling plates) with a little butter or oil. This prevents excess butter or oil from smoking.

- The grill is unsuitable for grilling breadcrumb-filled food.

- Sausages tend to burst when you grill them. To prevent this, punch a few holes in them with a fork.

- For the best result, make sure the pieces of meat you use are not too thick (approx. 1.5cm).

- Fresh meat gives better grilling results than frozen or defrosted meat.

- When you prepare satay, chicken, pork or veal, first sear the meat at a high temperature (setting 5). Then set the temperature control one position lower and grill the food until it is done.

- If you want to defrost frozen food, put the food in the oven grill position and wrap the frozen food in aluminium foil. Set the temperature control to setting 1 or 2. The defrosting time depends on the weight of the food.

Cleaning

Never use abrasive cleaning agents and materials, as this damages the non-stick coating of the plates.

Never immerse the appliance in water.

1 Unplug the appliance and let it cool down.

2 Remove excess oil from the plates with a piece of kitchen paper before you remove the plates.

3 Remove the grilling plates (Fig. 14).

To remove the plates, press on the fixing clips on the appliance and then lift the plates out of the appliance.

4 Clean the grilling plates with a soft cloth or sponge in hot water with some washing-up liquid or in the dishwasher (Fig. 15).

Soak the grilling plates in hot water for five minutes with some washing-up liquid to remove residues. This loosens any caked food or grease.

5 Dry the grilling plates and reassemble them (Fig. 16).

- Put the appliance in the barbecue grill position.

- Place the rear edge of the grilling plates on the appliance (1).

- Lower the grill plates onto the appliance and press them down under the fixing clip (2).

6 Clean the outside of the appliance with a damp cloth.

Replacement

Replacing the timer battery (HD4408/HD4469 only)

The battery lasts approximately two years in case of normal domestic use.

This timer runs on 1 button-type L1131 (1.55V) lithium battery, which is generally available.

1 Put the appliance in barbecue grill position and remove the screw from the hinge (Fig. 17).

2 Close the appliance, turn it around and put it in upright position (1).

3 Remove the hinge cover from the hinge and take the timer out of the hinge cover (Fig. 19).

4 Open the battery compartment cover of the timer with a coin and remove the old battery. Dispose of the old battery (see chapter 'Recycling' (Fig. 20)).

5 Place the new battery in the battery compartment with the + pole facing the battery compartment cover (Fig. 21).

6 Place the battery compartment cover back onto the timer.

7 Insert the timer into the hinge cover and reattach the hinge cover to the hinge.

8 Insert and tighten the screws in reverse order. Start with the aperture in upright position and then put it in barbecue grill position.

Recycling

This symbol on a product means that the product is covered by European Directive 2012/19/EU (Fig. 22).

This symbol means that the product contains batteries covered by European Directive 2006/66/EC, which cannot be disposed of with normal household waste (Fig. 23).

Inform yourself about the local separate collection system for electrical and electronic products and batteries. Follow local rules and never dispose of the product and batteries with normal household waste. Correct disposal of old products and batteries helps prevent negative consequences for the environment and human health.

Removing the disposable battery (HD4408/HD4469 only)

To remove the disposable batteries, see chapter 'Replacement', section 'Replacing the timer battery (HD4408/HD4469 only)'.

Storage

1 Wind the mains cord around the storage facility in the hinges of the appliance. (Fig. 24)

2 Store the appliance in upright position in a safe and dry place.

Guarantee and support

If you need information or support, please visit www.philips.com/support or read the separate worldwide guarantee leaflet.

Food table (Fig. 25)

1 Food table

БЪЛГАРСКИ**Въведение**

Поздравления за вашата покупка и добре дошли във Philips! За да се използвате изцяло от предлаганата от Philips поддръжка, регистрацията на продукта си на адрес www.philips.bg/welcome.

Общо описание (фиг. 1)

- 1 Грил (само за HD4407/HD4467)
- 2 Червен светлинен индикатор за температурата
- 3 Температурен регулатор
- 4 Пловчи на печени
- 5 Шипки за закрепване на плочите за печени
- 6 Хладна дръжка
- 7 Канал за отцеждане
- 8 Приспособление за прибиране на кабела
- 9 Грил (само за HD4408/HD4469)
- 10 Червен светлинен индикатор за готовност за печени
- 11 Заден светлинен индикатор за готовност за печени
- 12 Дисплей на таймера
- 13 Трикотажна обвивка за прибиране на кабела

Важно

Преди да използвате уреда, прочетете внимателно това ръководство за потребителя и го запазете за спрока в бъдеще.

Опасност

- <ul style