





BORN INNOVATIVE

USER MANUAL (GB)	P 01
MANUEL D'UTILISATION (FR)	P 05
BEDIENUNGSANLEITUNG (DE)	P 09
MANUALE ISTRUZIONI (IT)	P 13
GEbruikersHANDLEIDING (NL)	P 17
MANUAL DE INSTRUÇÕES (PT)	P 21
MANUAL DE INSTRUCCIONES (ES)	P 25
BRUGERVEJLEDNING (DK)	P 29
BRUKSANVISNING (NO)	P 33
INSTRUKTIONSMANUAL (SE)	P 37
KÄYTTÖOHJE (FI)	P 41
ΟΔΗΓΙΕΣ ΧΡΗΣΕΩΣ (GR)	P 45
РУКОВОДСТВО ПОЛЬЗОВАТЕЛЯ (RU)	P 49
INSTRUKCJA OBSŁUGI (PL)	P 53
NÁVOD K OBSLUZE (CZ)	P 57
UŽIVATEĽSKÝ MANUÁL (SK)	P 61
KULLANIM KILAVUZU (TR)	P 65
HASZNÁLATI ÚTMUTATÓ (HU)	P 69





* Certain models only ** May vary according to models



* Certain models only ** May vary according to models

INSTRUCTIONS FOR SAFE USE

This appliance should only be used for domestic cleaning, as described in this user guide. Please ensure that this guide is fully understood before operating the appliance.

Do not leave the appliance plugged in. Always switch off and remove the plug from the socket after use, or before cleaning the appliance or any maintenance task.

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance.

Cleaning and user maintenance shall not be made by children without supervision.

If the power cord is damaged stop using the appliance immediately. To avoid a safety hazard, an authorised HOOVER service engineer must replace the power cord.

Keep hands, feet, loose clothing and hair away from rotating brushes.

Use only attachments, consumables or spares recommended or supplied by HOOVER.

Static electricity: Some carpets can cause a small build up of static electricity. Any static discharge is not hazardous to health.

Do not use your appliance out of doors or on any wet surface or for wet pick up.

Do not pick up hard or sharp objects, matches, hot ashes, cigarette ends or other similar items.

Do not spray with or pick up flammable liquids, cleaning fluids, aerosols or their vapours.

Do not run over the power cord when using your appliance or remove the plug by pulling on the power cord.

Do not continue to use your appliance if it appears faulty.

Do not stand on or wrap the cord around arms or legs when

using your appliance.

Do not use the appliance to clean animals or people.

Do not position the appliance above you when cleaning the stairs.

Keep batteries away from children.

If a battery is swallowed, immediately consult a doctor.

Exhausted batteries are to be removed from the appliance and safely disposed of.

If the appliance is to be stored unused for a long period, the batteries should be removed and stored safely.

If the appliance is to be disposed of the batteries must first be removed.

The appliance must be disconnected from the supply mains when removing the battery.

Dispose of the batteries safely.

Use only battery type Lithium CR2032 3V. Non-rechargeable type.

Batteries are to be inserted with the correct polarity: The positive pole “+” is on the top side. [23]

Non-rechargeable batteries are not to be recharged.

The battery terminals are not to be short-circuited.

HOOVER service: To ensure the continued safe and efficient operation of this appliance we recommend that any servicing or repairs are only carried out by an authorised HOOVER service engineer.

The Environment

The symbol on this appliance indicates that this appliance may not be treated as household waste. Instead it must be handed over to the applicable collection point for the recycling of electrical and electronic equipment. Disposal must be carried out in accordance with local environmental regulations for waste disposal. For more detailed information about treatment, recovery and recycling of this appliance, please contact your local city office, your household and waste disposal service or the shop where you purchased the appliance.



For Models with Hi-Controller Remote Control:

Frequency bands	300Mhz ~ 450Mhz
Maximum RF power transmitted in the frequency band	11 dBm

Obsah je uzamčen

**Dokončete, prosím, proces objednávky.
Následně budete mít přístup k celému dokumentu.**



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

**) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!