



TIK&TOK

HR

EN

Please read the manual before use.

- ◆ **The information in this document won't be modified or extended in accordance with any notice.**
- ◆ **The watch should be charging 2 hours at least before use.**

1. Caution:

1.1 Waterproof and dustproof

The watch supports waterproof and dustproof. Please follow below guidelines to maintain the waterproof and dustproof function. Otherwise your device might be damaged.

- Do not use watch under the strong pressure water.
- Do not use watch when diving, snorkeling or other sports in turbulent water.
- Please dry your hands or watch fully before operating.
- If the watch is exposed to water, please dry it fully with soft cloth. If it is exposed to other liquids (such as salt water, pool water, soapy water, oil, perfume, sunscreen, hand sanitizer) or chemicals (such as cosmetics), please wash it with clean water and dry it fully with soft cloth. Do not follow these instructions may damage its performance and appearance.
- If the watch is dropped or hit, the waterproof and dustproof function may be damaged.

- Do not disassemble your watch. The waterproof and dustproof function may be damaged.
- Do not use watch in extremely high or low temperature environments.
- Do not use blowers and other heated equipment to dry the watch.
- In sauna room, the waterproof function may be damaged.

1.2 Cleaning and management of TIK&TOK HR

Follow the below points to ensure that TIK&TOK HR is operating normally and looks good. Otherwise, maybe damage TIK&TOK HR and cause skin irritation.

- Protect watch from dust, sweat, ink, oil and chemical products (such as cosmetics, antibacterial sprays, hand sanitizers, detergents, and insecticides). Otherwise, the internal and external parts may be damaged or causes performance degradation. If TIK&TOK HR is stained with above substances, please clean it with lint-free soft cloth.
- When cleaning TIK&TOK HR, do not use soap, detergent, abrasive materials, compressed air, ultrasonic waves or external heat sources. Otherwise, TIK&TOK HR may be damaged. Soap, detergent, hand sanitizer, or detergent residue may cause skin irritation.
- After exercising or sweating, please clean your wrist and strap. Use water to clean TIK&TOK HR and dip a small amount of alcohol to wipe, then dry it thoroughly.

Obsah je uzamčen

Dokončete, prosím, proces objednávky.

Následně budete mít přístup k celému dokumentu.



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

**) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!