Lenco

Model PMX-250



User manual - High power DJ mixer system with Bluetooth USB FM and party lights Gebruikershandleiding - Krachtig DJ mixersysteem met Bluetooth USB, FM en feestlichten Bedienungsanleitung Hochleistungs-DJ-Mixersystem mit Bluetooth, USB, UKW und Partylicht Mode d'emploi - Système de mixage DJ puissant avec Bluetooth, USB, FM et éclairages de fête Manual de usuario - Sistema mezclador de DJ de alta potencia con Bluetooth USB FM y luces festivas

Index

English	3
Nederlands	
Deutsch	25
Français	
Español	

English PMX-250

CAUTION:

Usage of controls or adjustments or performance of procedures other than those specified herein may resulte in hazardous radiation exposure.

This unit should not be adjusted or repaired by anyone except qualified service personnel.

PRECAUTIONS BEFORE USE

KEEP THESE INSTRUCTIONS IN MIND:

- 1. Do not use this device near water.
- 2. Clean only with a slightly damp cloth.
- 3. Do not cover or block any ventilation openings. When placing the device on a shelf, leave 5 cm (2") free space around the whole device.
- 4. Install in accordance with the supplied user manual.
- 5. Don't step on or pinch the power adaptor. Be very careful, particularly near the plugs and the cable's exit point. Do not place heavy items on the power adaptor, which may damage it. Keep the entire device out of children's reach! When playing with the power cable, they can seriously injure themselves.
- 6. Unplug this device during lightning storms or when unused for a long period.
- 7. Keep the device away from heat sources such as radiators, heaters, stoves, candles and other heat-generating products.
- 8. Avoid using the device near strong magnetic fields.
- 9. Electrostatic discharge can disturb normal usage of this device. If so, simply reset and restart the device following the instruction manual. During file transmission, please handle with care and operate in a static-free environment.
- 10. Warning! Never insert an object into the product through the vents or openings. High voltage flows through the product and inserting an object can cause electric shock and/or short circuit internal parts. For the same reason, do not spill water or liquid on the product.
- 11. Do not use in wet or moist areas such as bathrooms, steamy kitchens or near swimming pools.
- 12. Do not use this device when condensation may occur.
- 13. Although this device is manufactured with the utmost care and checked several times before leaving the factory, it is still possible that problems may occur, as with all electrical appliances. If you notice smoke, an excessive build-up of heat or any other unexpected phenomena, you should disconnect the plug from the main power socket immediately.
- 14. This device must be well ventilated at all time!
- 15. This device must operate on a power source as specified on the specification label. If you are not sure of the type of power supply used in your home, consult your dealer or local power company.
- 16. The socket outlet must be installed near the equipment and must be easily accessible.
- 17. Do not overload ac outlets or extension cords. Overloading can cause fire or electric shock.
- 18. Devices with class 1 construction should be connected to a main socket outlet with a protective earthed connection.
- 19. Devices with class 2 construction do not require a earthed connection.
- 20. Keep away from rodents. Rodents enjoy biting on power cords.
- 21. Always hold the plug when pulling it out of the main supply socket. Do not pull the power cord. This can cause a short circuit.
- 22. Avoid placing the device on any surfaces that may be subject to vibrations or shocks.
- 23. To protect the device during a thunderstorm, unplug the ac power adaptor.
- 24. When the device is not in use for long periods, unplug the ac power adaptor for safety reasons.
- 25. To clean the device, use a soft dry cloth. Do not use solvents or petrol based fluids. To remove severe stains, you may use a damp cloth with dilute detergent.
- 26. The supplier is not responsible for damage or lost data caused by malfunction, misuse, modification of the device or battery replacement.
- 27. Do not interrupt the connection when the device is formatting or transferring files. Otherwise, data may be corrupted or lost.

Obsah je uzamčen

Dokončete, prosím, proces objednávky.

Následně budete mít přístup k celému dokumentu.



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.
 - *) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.
- 2) Pak jsou tady "roboti", kteří se přiživují na naší práci a "vysávají" výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!