


EJ09

Sewing Machine

User Manual



TESCO

IMPORTANT SAFETY GUIDE

Please follow all the precautions listed below for safety and to reduce the risk of fire, injury or electrical shock.

Read all the instructions before operating the appliance and keep them for future reference. If you pass the product on to a third party, include these instructions.

Always unplug the sewing machine from the mains supply when removing covers, lubricating, or when making any user or servicing adjustments mentioned in the instruction manual.

Do not unplug the unit by pulling on the cord. To unplug, grasp the plug, not the cord. Ensure there is adequate room to operate the unit.

Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the appliance to a competent service centre for examination, repair, electrical or mechanical adjustment.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of this appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance

Do not use outdoors or in damp or wet conditions.

Before operating, ensure that the surface on which the unit is placed is stable.

Never operate the appliance with any air openings blocked. Keep all ventilation openings of the sewing machine and foot controller free from accumulations of lint, dust, and loose cloth.

Do not insert any object into ventilation slots.

Keep fingers away from all moving parts. Special care is required around the sewing machine needle.

Always use the proper needle plate. The wrong plate can cause the needle to break.

Do not use broken, deformed or blunt needles.

Do not pull or push fabric while stitching. It may deflect the needle causing it to break.

Switch the sewing machine off when making any adjustments in the needle area, such as threading the needle, changing needles, threading bobbins, changing the presser foot and the like.

Do not operate where aerosol spray products are being used or where oxygen is being administered.

This appliance is only for household use. Industrial or professional use will invalidate the warranty.

Do NOT use this appliance for any purpose not covered by the instructions.

THE APPLIANCE MUST NOT BE LEFT UNATTENDED WHILE IT IS CONNECTED TO THE SUPPLY MAINS.

ELECTRICAL INFORMATION

Before using this appliance ensure that the voltage of your electricity supply is the same as that indicated on the appliance.

The means of disconnecting this appliance from the mains supply is the mains plug. This should be unobstructed and readily operable at all times.


May we suggest that before you start to use your sewing machine, you discover its many features and advantages by going through this instruction book, step by step, while seated at your sewing machine.

CONTENTS

Safety Guide	Page 2	More about the pressure foot	Page 20
Details of the machine- Front View	Page 4	Matching the needle, fabric and thread	Page 21
Details of the machine- Rear View	Page 5	Sewing on buttons	Page 22
Accessories	Page 6	Sewing buttonholes	Page 23
Fitting the snap-in sewing table	Page 7	Attaching zippers and piping	Page 24
Connecting power	Page 8	3-step zig-zag sewing	Page 25
Attaching the needle	Page 9	Stitch selection	Page 26
The presser foot	Page 10	Smocking stitch	Page 27
Winding the bobbin	Page 11	Decorative and practical stitches	Page 28
Inserting the bobbin	Page 12	Patching	Page 29
Checking the bobbin tension	Page 12	Appliqué	Page 30
Threading the upper thread	Page 13	Monogramming and embroidering -1	Page 31
Bringing up the lower thread	Page 14	Monogramming and embroidering -2	Page 32
Basic sewing	Page 15	Maintenance -1 (Replacing the Light Bulb)	Page 33
Reverse sewing	Page 16	Maintenance -2 (Cleaning and Lubrication)	Page 34
Removing the work	Page 16	Troubleshooting	Page 35
More about Straight Stitching	Page 17	After Use	Page 36
Zig-Zag stitching	Page 18	Care	Page 36
Adjusting the upper thread tension	Page 19	Warranty	Page 36


DETAILS OF THE MACHINE – FRONT VIEW

1. Thread tension dial
2. Presser foot pressure
3. Thread take-up lever
4. Thread cutting
5. Presser foot
6. Needle plate
7. Sewing table/ Accessories box
8. Bobbin stopper
9. Stitch length dial
10. Stitch display
11. Reverse sewing lever
12. Base




DETAILS OF THE MACHINE – REAR VIEW

- 13. Spool pin
- 14. Bobbin winder
- 15. Hole for second spool pin
- 16. Hand wheel
- 17. Patten selector dial
- 18. Power switch
- 19. Main plug socket
- 20. Bobbin thread guide
- 21. Upper thread guide
- 22. Handle
- 23. Presser foot lever




SUPPLIED ACCESSORIES

- A. Standard foot
- B. Zipper foot
- C. Buttonhole foot
- D. Button sewing foot
- E. L-screwdriver
- F. Seam ripper/ brush
- G. Lubricating Oil bottle
- H. Pack of 3 needles
- I. Seam guide
- J. 3 Bobbins
- K. Darning plate
- L. Spool holder
- M. Second spool pin
- N. Spool pin felt




FITTING THE SNAP-IN SEWING TABLE

Hold the the snap-in sewing table horizontal, and push it in the direction of the arrow.




The inside of the snap-in sewing table can be utilized as an accessory box.




CONNECTING POWER

- A:** Switch the machine's Power Switch OFF – "0" position
 - B:** Plug in the Machine Power connector firmly.
 - C:** Place the Foot Controller in a convenient unobstructed place.
 - D:** Plug in the Mains Plug to the mains supply and switch on.
 - E:** Adjust the position of the foot controller (*see Fig. 2 below*)
Now remove your foot from the control.
 - F:** Switch the machine's Power Switch ON – "I" position
- Your sewing machine is now ready for use.



ATTACHING THE NEEDLE

The Presser Foot Assembly is raised and lowered with the Presser Foot Lever (No.23 on P.5). This also raises and lowers the needle.



Insert the needle following the illustrated instructions (Fig. 1)

Loosen the needle clamp screw (A).

Insert the needle with the flat side towards the back (B) and the eye facing the front (C).

Push the needle as far as it will go (D).

Re-tighten the screw.



Change the needle regularly, especially if it is showing signs of wear and causing problems.

Needles must be in perfect condition. (Fig. 2) Problems can occur with:

- A. Bent needles
- B. Blunt needles
- C. Damaged points


Attention: ALWAYS switch the power off when attaching needles.

CAUTION: Always exercise care when attaching needles. Store needles safely away from children and pets and dispose of them with great care with the points protected.



THE PRESSER FOOT

The Presser Foot Assembly is raised and lowered with the Presser Foot Lever (No.23 on P:XX)



First, switch the power off:

To attach the Presser Foot Holder- Refer to figure 1:

A: Raise the presser foot clamp.

B: Attach the presser foot holder as illustrated.

You can use the provided screw driver to loosen and tighten the screw.

To attach the Pressure Foot- Refer to figure 2:

Place the All Purpose Foot (F) on the needle plate

Gradually lower the presser foot holder (B) until the cut-out (C) is directly above the pin (D) on the plate.

Raise the lever (E). Lower the presser foot holder fully onto the presser foot and the presser foot will lock automatically in place. Release the lever.


To remove the Pressure Foot- Refer to figure 3:

Raise the presser foot. Raise the lever (e) and the foot disengages.

To Attach the Seam Guide- Refer to figure 4:

The seam guide is a useful accessory to help you gauge the position of seams etc. but its use is not essential.

Attach the seam guide (g) in the slot as illustrated. Adjust according to need for hems, pleats, etc.



WINDING THE BOBBIN

Your sewing machine works by stitching two threads. The main thread is contained on the spool which is at the top of the machine. A second thread is contained in a compartment under the machine. This thread is wound onto a "bobbin" from the main spool.

Place the main spool as shown in the top illustration.

For large spools of thread place the spool holder with the large side next to the spool (Fig 1). For small spools of thread place the spool holder with the small side next to the spool (Fig 2).

To wind the bobbin:

Wind thread clockwise around bobbin winder tension disc (Fig. 3).

Thread the bobbin as illustrated and place on spindle (Fig. 4).

Push the bobbin to the right (Fig. 5). This is the "bobbin winding" position.

Hold the thread end (Fig. 6).

Switch the power on:

Step on the foot control pedal (Fig. 7). Gradually apply pressure to increase speed.

Allow the bobbin to wind sufficient thread. Remove your foot from the pedal.



Now cut the threads (8).

Press the bobbin to left (9) and remove. Moving the bobbin to the left places the machine in the "sewing" position.

Note:

When the bobbin winder spindle is in "bobbin winding" position, the machine will not sew.

To start sewing, push the bobbin winder spindle to the left (sewing position).



INSERTING THE BOBBIN

When inserting or removing the bobbin, the needle must be fully raised.

Switch the power OFF

1. Open the hinged cover.
2. Hold the bobbin case with one hand. Insert the bobbin so that the thread runs in a clockwise direction (arrow).
3. Put the thread under the tension spring.
4. Hold the bobbin case by the hinged latch.
5. Insert it into the shuttle. Press it fully home and then release the latch.



CHECKING AND ADJUSTING THE BOBBIN TENSION

The bobbin tension is factory preset and should not need adjusting. However if the tension is not correct the thread will not feed properly.

To test the bobbin thread tension:

Remove the bobbin case and bobbin and hold it by suspending it by the thread. Jerk it once or twice. If the tension is correct, the thread will unwind by about 25-50 mm.

If the tension is too tight, it does not unwind at all. If the tension is too loose, it will drop too much. To adjust, turn the small screw on the side of the bobbin case.



THREADING THE UPPER THREAD

This operation is important to carry out correctly as by not doing so many sewing problems could result.

We suggest you read through the procedure carefully and carry out this process several times before using the machine to familiarise yourself with the process.

Switch the power OFF.

Raise the needle to its highest point (1).

Raise the presser foot to release the tension discs. (2)

Lift up the spool pin. Place the spool of thread on the holder with the thread coming off the spool as shown. For small thread spools, place the small side of spool holder next to spool. (3)

Draw thread from spool through the upper thread guide. (4)

Guide the thread around the thread guide (5) pulling thread through pre-tension spring as illustrated.


Thread the tension module by leading thread down the right channel and up the left channel (6). During this process it is helpful to hold the thread between the spool and thread guide (4).

At the top of this movement pass thread from right to left through the slotted eye of the take-up lever and then downwards again. (7)

Now pass thread behind the thin wire needle clamp guide (8) and then down to the needle which should be threaded from front to back.

Pull about 6-8 inches of thread to the rear beyond the needle eye.

Trim the thread to length with built in thread cutter. (9)




BRINGING UP THE LOWER THREAD

Refer to Figure 1

Hold the upper thread LOOSELY with the left hand.

Turn the handwheel forwards to lower and then fully raise the needle.




Refer to Figure 2

The upper thread will catch and raise the lower thread.

Pull on the upper thread to bring the lower thread up through the stitch plate hole.

Lay both threads to the back under the presser foot. (2)




BASIC SEWING

Basic Machine Setting (Figure 1)

Set the Stitch Length Dial to 2. This provides a small/medium stitch length


Set the Pattern Selector Dial to display A in the Stitch Display Window. This sets the needle to centre stitch position.



Raise the Presser Foot

Inserting the Fabric (Figure 2)

Lay the upper and lower threads to the rear of the presser foot
Insert the fabric under the presser foot and line it up carefully






Stitching the Fabric (Figure 3)

Switch the machine on.

Lower the presser foot onto the fabric.

Press the foot pedal to start the machine.

Keeping a steady pressure on the foot pedal, guide the fabric through the machine with a steady hand.



REVERSE SEWING

At the end of the seam (Figure 1):

Press down the reverse sewing lever A. Sew a few reverse stitches.

Release the lever and the machine will sew forwards again.

REMOVING THE WORK (Figure 2):



Turn the handwheel towards you to bring the thread take up lever to its highest position, raise the presser foot and remove work towards the back and side.

To cut the thread (Figure 3):

Gently pull the work away releasing a generous length of thread.

Place the threads over the cutting slot B and press down to cut the thread.

Lay the threads to the back of the presser foot before continuing.



MORE ABOUT STRAIGHT STITCHING

Straight Stitching Centre Needle Position



Turn the pattern selector dial so that "A" appears in the stitch display window.
Adjust the stitch length by turning the stitch length dial to the desired stitch length.

To get a reinforced triple straight stitch, turn the stitch length dial to position "S1".

Straight Stitching Right Needle Position


Turn the pattern selector dial so that "B" appears in the stitch display window.
Adjust the stitch length by turning the stitch length dial to the desired stitch length.

To get a reinforced triple straight stitch, turn the stitch length dial to position "S1".



ZIG-ZAG STITCHING

Turn the pattern selector dial so that the stitch display shows “C”-zig-zag.
Turning the pattern selector dial will increase or decrease the zig zag width.




Using the stitch length dial while zig-zag stitching

The density of zig-zag stitches increase as the setting of stitch length dial approaches “0”.

Neat zig-zag stitches are usually achieved at settings of “2.5” or below.

Closed up zig-zag stitches (close together) are referred to as a satin stitch.




ADJUSTING THE UPPER THREAD TENSION

Rotate the dial to adjust the upper thread tension

The basic thread tension setting is "4"


To increase the tension, turn the dial to the next number up.

To reduce the tension, turn the dial to the next number down.



The diagram shows the effects of different thread tension settings:


- A. Normal thread tension
- B. Upper thread tension too loose
- C. Upper thread tension too tight



MORE ABOUT THE PRESSURE FOOT

The presser foot can be raised through two levels

When sewing several layers or thick fabrics, the presser foot can be raised a second stage for easy positioning of the work. (A)




Adjusting the pressure of the presser foot:

The presser foot pressure of the machine has been pre-set and requires no particular readjustment for different types and weights of fabric.

However, if you need to adjust the presser foot pressure, turn the presser adjusting screw with a coin.

For sewing very thin fabric, loosen the pressure by turning the screw counter clockwise, and for heavy fabric, tighten by turning it clockwise.



MATCHING THE NEEDLE, FABRIC AND THREAD

NEEDLE, FABRIC, THREAD SELECTION GUIDE

NEEDLE SIZE	FABRICS	THREAD
9-11(65-75)	Lightweight fabrics-thin cottons, voile, serge, silk , muslin, interlocks, cotton knits, tricot, jerseys, crepes, woven polyester, shirt & blouse fabrics.	Light-duty thread in cotton, nylon or polyester.
12(80)	Medium weight fabrics- cotton, satin, sailcloth, double knits, lightweight woollens.	Most threads sold are medium size and suitable for these fabrics and needle sizes. Use polyester threads on synthetic materials and cotton on natural woven fabrics for best results. Always use the same thread on top and bottom.
14(90)	Medium weight fabrics-cotton duck, woollen, heavier knits, terry cloth, denims.	
16(100)	Heavyweight fabrics-canvas, woollens, outdoor tent and quilted fabrics, denims, upholstery material (light / medium).	
18(110)	Heavy woollens, overcoat fabrics, upholstery fabrics, some leathers and vinyls.	Heavy duty thread, carpet thread. (Use heavy foot pressure – large numbers.)

IMPORTANT: Match needle size to thread size and weight of fabric

NEEDLE, FABRIC SELECTION

NEEDLES	EXPLANATION	TYPE OF FABRIC
HAX1	Standard sharp needles. Sizes range thin to large. 9 (65) to 18(110)	Natural woven fabrics-wool, cotton, silk, etc. Not recommended for double knits.
15x1/705H(SUK)	Semi-ball point needle, scarfed. 9(65) to 18(110)	Natural and synthetic woven fabrics, polyester blends. Knits-polyesters, interlocks, tricot, single and double knits. Can be used instead of 15x1 for sewing all fabrics.
15x1/705H(SUK)	Full ball point needle 9(65) to 18(110)	Sweater knits, Lycra, swimsuit fabric, elastic.
130 PCL	Leather needles. 12(80) to 18(110)	Leather, vinyl, upholstery. (Leaves smaller hole than standard large needle.)

SEWING ON BUTTONS

Set the Stitch Length Dial and the Pattern Selector as shown

Install the Button Sewing Foot

Install the Darning Plate. (See Fig 1)

Position the work under the foot.

Place the button on the marked position and lower the foot. Set the pattern selector knob on "B" and sew a few securing stitches.

Select the zig-zag stitch width according to the distance between the two holes of the button.



Turn the handwheel to check if the needle goes into the right and the left hole of the button without any obstruction (adjust the stitch width according to the button).

Slowly sew on the button with about 10 stitches.

Select pattern "B" and sew a few securing stitches.

If a shank is required, place a darning needle on top of the button and sew. (Fig. 3)

For buttons with 4 holes, sew through the front two holes first (Fig. 2), push the work forward and then sew through the back two holes as described. (Fig. 3)







SEWING BUTTONHOLES

Preparation: Attach the buttonhole foot. Adjust the stitch length dial between "0.5" - "1". The density of the stitch depends on thickness of the fabric.

Note: Always test sew a buttonhole.

To prepare the fabric: Measure the diameter of the button and add 0.3 cm (1/8") for the bartacks. If you have a very thick button, add more to the diameter measurement. Mark the position and length of the buttonhole on the fabric. Position the fabric so that the needle is on the mark that is furthest from you. Pull the buttonhole foot towards you as far as it will go. Lower the foot.



Sewing the buttonhole

1. Turn the pattern selector dial to . Sew at moderate speed until you reach the end mark.
2. Turn the pattern selector dial to  and sew 5-6 bartack stitches.
3. Now turn the selector dial to . Sew the left side of the buttonhole to the mark at the end furthest from you.
4. Turn the pattern selector dial to  and sew bar tack stitches.

Remove the fabric from under the foot. Draw the upper thread through the reverse side of the fabric and knot upper and lower threads. Cut the centre of the buttonhole with the seam ripper, being careful not to cut the stitches on either side.


Tips:

- Slightly reduce upper thread tension to produce better results.
- Use backing material for fine and stretchy fabrics.
- It is advisable to use a gimp cord for stretch or knit fabrics. The zigzag should sew over the gimp. (5)



ATTACHING ZIPPERS AND PIPING


Set the machine as illustrated. (Figure1)



The zipper foot can be inserted right or left, depending on which side of the foot you are going to sew. (Fig. 2)

To sew past the zipper pull, lower the needle into the fabric, raise the presser foot and push the zipper pull behind the presser foot. Lower the foot and continue to sew.


It is also possible to sew in a length of cord, into a bias strip to form a 'welt'. (Fig.3)
Set the stitch length control between "1" - "4" (according to thickness of fabric).



3-STEP ZIG-ZAG SEWING

Use this technique for sewing on lace and elastic, darning, mending, reinforcing edges.


Set the machine as illustrated. (Figure1)



Place patch in position.

The stitch length can be shortened to produce very close stitches. (Fig. A)

When mending tears, it is advisable to use a piece of backing fabric to reinforce. The stitch density can be varied by adjusting the stitch length. First sew over the center and then overlap on both sides. Depending on the type of fabric and damage, sew between 3 and 5 rows. (Fig. B)




STITCH SELECTION

Triple straight stitch: (Fig. 1)

For hardwearing seams.

Turn the stitch length dial to "S1".

The machine sews two stitches forwards and one stitch backwards. This gives triple reinforcement.




Triple zig-zag: (2)

For hardwearing seams, hems and decorative seams.

Turn the stitch length dial to "S1".


Triple zig-zag is suitable for firm fabrics like denim, corduroy, etc.



SMOCKING STITCH


Use for seams, hems, T-shirts, underwear, etc.

Set the machine as illustrated. (Fig. 1) Pattern selector "D"; stitch length "S1".



This stitch can be used for all types of jersey as well as for woven fabrics. (Fig. 2)


Sew at 1 cm (1/4") from the fabric edge and trim the surplus fabric. (Fig. 3)



DECORATIVE AND PRACTICAL STITCHES

Set the machine as illustrated.

Turn the stitch length dial to suit the fabric.



Shell hem (Fig. A) For decorative edges.


Suitable for edges on sheer, fine and stretch fabrics. The larger stitch should go just over the edge of the fabric to create the shell effect.

Rampart (Fig. B) For flat joining seams, sewing on elastic, visible hems.

This stitch can be used for firm, thicker fabrics.

Bridging (Fig. C) For seams, place mats, tablecloths.

Decorative joining seam for a fagoted effect. Gathering with cord or shirring elastic.





PATCHING

These stitches are used to join two pieces of fabric while leaving a space between their edges.

Set the pattern selector on "H". Turn the stitch length dial to "S1".


1. Fold over the edges of the two pieces of fabric for the hem and baste the edges to a thin piece of paper leaving a small space between them.
2. Stitch along the edge, pulling both threads slightly when beginning to sew.
* Use thicker than normal threads for sewing.
3. After sewing, remove the basting and the paper. To finish, tie knots on the reverse side at the beginning and the end of the seams.



APPLIQUÉ

Turn stitch length dial to the desired length.

Turn pattern selector dial to small zigzag width.




Cut out the appliqué design and baste it to the fabric.

Sew slowly around the edge of the design.

Trim excess material outside the stitching. Make sure not to cut any stitches.

Remove the basting thread.

Tie top and bottom thread under the appliqué to avoid unravelling.



MONOGRAMMING AND EMBROIDERING - 1*

* USING AN EMBROIDERY HOOP (NOT SUPPLIED)

PREPARATION

Set the machine as illustrated opposite. (The "0" setting means the machine will not feed the fabric leaving you to manoeuvre it freely yourself).

Remove the presser foot and the presser foot holder.

Attach the darning plate.

Lower the presser foot lever before starting to sew.

Adjust the stitch width according to the size of lettering or design.

OPERATION - 1



Draw the desired lettering or design on the right side of the fabric.

Stretch the fabric between embroidery hoop as firmly as possible.

Place the fabric under the needle. Make sure the presser foot bar is down in its lowest position.

Turn the balance wheel towards you to bring up the lower thread through the fabric. Sew a few securing stitches at the starting point.

Hold the hoop with thumb and forefingers of both hands while pressing the material with the middle and third fingers and supporting the outside of hoop with smaller finger.





MONOGRAMMING AND EMBROIDERING - 2*

* USING AN EMBROIDERY HOOP (NOT SUPPLIED)

MONOGRAMMING

1. Sew, moving the hoop slowly along the lettering at a constant speed.
2. Secure with a few straight stitches at the end of the last letter.





EMBROIDERING

1. Stitch the outline of the design by moving the embroidery hoop.
2. Fill in the design working from the outline of the design to the inside and from the inside to the edge of the outline until the design is completely filled in. Keep the stitches close together.

* A long stitch is made by moving the hoop rapidly and a short stitch is made by moving it slowly.

3. Secure with a few straight stitches at the end of the design.




MAINTENANCE - 1

REPLACING THE LIGHT BULB

Disconnect the machine from the power supply by removing the plug from the mains socket.


Loosen screw (A) as illustrated. (Figure 1).

Remove the cover (B).



Unscrew the bulb and fit a new one (C). (Figure 2)

Replace the cover and tighten the screw.



MAINTENANCE - 2

CLEANING AND LUBRICATION

Disconnect the machine from the power supply by removing the plug from the mains socket.

Remove the stitch plate: (Figure 1)

Turn the handwheel until the needle is fully raised. Open the hinged front cover and unscrew the needle plate screw with the screw driver.

Cleaning the feed dog: (Figure 2)

Remove the bobbin case and use the brush supplied to clean the whole area.

Cleaning and lubricating the hook: (Figure 3)

Remove the bobbin case.

Snap the two hook retaining arms (A) outwards.



Remove the hook race cover (B) and the hook (C) and clean with a soft cloth. Lubricate at the point (D) (1-2 drops) with sewing machine oil ONLY.

Turn the handwheel until the hook race (E) is in the left position.

Replace the hook (C).

Replace the hook race cover (B) and snap back the two hook retaining arms (A).

Insert the bobbin case and bobbin and replace the stitch plate.



TROUBLESHOOTING

If your machine is not working satisfactorily, please work through this checklist before returning it to Tesco or taking it for service.

The upper thread breaks	<ol style="list-style-type: none">1. The machine is not threaded correctly2. The thread tension is too tight3. The thread is too thick for the needle4. The needle is not inserted correctly5. The thread is round wound the spool holder pin6. The needle is damaged	<ol style="list-style-type: none">1. Rethread the machine2. Reduce the thread tension (lower number)3. Select a larger needle4. Remove and reinsert the needle (flat side towards the back)5. Remove the reel and wind thread onto reel6. Replace the needle
The lower thread breaks	<ol style="list-style-type: none">1. The bobbin case is not inserted correctly2. The bobbin case is threaded wrongly3. The lower thread tension is too tight	<ol style="list-style-type: none">1. Reinsert the bobbin in the case. The thread should pull easily2. Check both bobbin and bobbin case3. Loosen lower thread tension as described
Skipped stitches	<ol style="list-style-type: none">1. The needle is not inserted correctly2. The needle is damaged3. The wrong size needle has been used4. The foot is not attached correctly	<ol style="list-style-type: none">1. Remove and reinsert needle (flat side towards the back)2. Insert a new needle3. Choose a needle to suit the thread and fabric4. Check and attach the foot correctly
Needle breaks	<ol style="list-style-type: none">1. The needle is damaged2. The needle is not correctly inserted3. Wrong needle size for the fabric4. The wrong foot is attached	<ol style="list-style-type: none">1. Insert a new needle2. Insert the needle correctly (flat side towards the back)3. Choose a needle to suit the thread and fabric4. Select the correct foot
Loose stitches	<ol style="list-style-type: none">1. The machine is not correctly threaded2. The bobbin case is not correctly threaded3. Needle/fabric/thread combination is wrong4. Thread tension wrong	<ol style="list-style-type: none">1. Check the threading2. Thread the bobbin case as illustrated3. The needle size must suit the fabric and thread4. Correct the thread tension
Seams gather or pucker	<ol style="list-style-type: none">1. The needle is too thick for the fabric2. The stitch length is wrongly adjusted3. The thread tension is too tight	<ol style="list-style-type: none">1. Select a finer needle2. Readjust the stitch length3. Loosen the thread tension
Uneven stitches, uneven feed	<ol style="list-style-type: none">1. Poor quality thread2. The bobbin case is wrongly threaded3. Fabric has been pulled	<ol style="list-style-type: none">1. Select a better quality thread2. Remove bobbin case and retread and insert correctly3. Do not pull on the fabric while sewing, let it be taken up by the machine
The machine is noisy	<ol style="list-style-type: none">1. The machine must be lubricated2. Fluff or oil have collected on the hook or needle bar3. Poor quality oil has been used4. The needle is damaged	<ol style="list-style-type: none">1. Lubricate as described2. Clean the hook and feed dog as described3. Only use good quality sewing machine oil4. Replace the needle
The machine jams	<ol style="list-style-type: none">1. Thread is caught in the hook	<p>Remove the upper thread and bobbin case, turn the handwheel backwards and forwards by hand and remove the thread remainders. Lubricate as described.</p>

CONCLUSION

AFTER USE

Disconnect the machine from the power supply by removing the plug from the mains socket.

Remove the cord connecting the foot pedal.

Store the machine securely together with all accessories in a cool dry place away from heat and damp and where it cannot be interfered with by children or pets.

CLEANING THE CASE

The case of the sewing machine may be cleaned with a barely damp cloth and then dried thoroughly. Do not wet the appliance body, cord or mains plug. NEVER allow water to penetrate the case or foot pedal.

CAUTION: Never use scouring pads, abrasives or harsh cleaners.

WARRANTY

Your TESCO appliance is covered by a warranty for 12 months from the date of purchase. If a fault develops during this period, please contact the TESCO electrical help line on 0845 456 6767. Please have your original purchase receipt with you when you call. This warranty in no way affects your consumer rights.

SPECIFICATIONS

Voltage Rating: 220 -240V AC, 50Hz

Power Consumption: 85W

Noise Performance (SPL) : 75dBA

Net Weight: 6.1 kg



Class II construction double insulated.

This product must not be connected to earth



UK: Waste electrical products should not be disposed of with household waste. Separate disposal facilities exist, for your nearest facilities. See www.recycle-more.co.uk or in-store for details.

ROI: Produced after 13th August 2005. Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice.

Tesco Stores Ltd, Delamare Road, Cheshunt, Herts, EN8 9SL