

★★★ TRISTAR

EN | Instruction manual

NL | Gebruiksaanwijzing

FR | Mode d'emploi

DE | Bedienungsanleitung

ES | Manual de usuario

PT | Manual de utilizador

IT | Manuele utente

SV | Bruksanvisning

PL | Instrukcja obsługi



CS | Návod na použití

SK | Návod na použitie



FR-6970

PARTS DESCRIPTION / ONDERDELENBESCHRIJVING / DESCRIPTION DES PIÈCES / TEILEBESCHREIBUNG /
DESCRIPCIÓN DE LAS PIEZAS / DESCRIÇÃO DOS COMPONENTES / DESCRIZIONE DELLE PARTI /
BESKRIVNING AV DELAR / OPIS CZĘŚCI / POPIS SOUČÁSTÍ / POPIS SÚČASTÍ



SAFETY

- By ignoring the safety instructions the manufacturer cannot be held responsible for the damage.
 - If the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons in order to avoid a hazard.
 - Never move the appliance by pulling the cord and make sure the cord cannot become entangled.
 - The appliance must be placed on a stable, level surface.
 - The user must not leave the device unattended while it is connected to the supply.
 - This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
 - Close supervision is necessary when any appliance is used by or near children.
- **WARNING:** Spilled food can cause serious burns. Keep appliances and cords away from children. Never drape the cord over the edge of a counter, never use an outlet below the counter, and never use with an extension cord.
 - The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
 - Do not use this appliance outdoors.
 - Do not place on or near a hot gas or electric burner, or in a heated oven.
 - Do not clean with metal scouring pads. Pieces can break off the pad and touch electrical parts, creating a risk of electric shock.
 - Use extreme caution when removing the frying baskets.
 - Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
 - **CAUTION:** To protect against damage or electric shock, do not cook in the base unit. Cook only in the frying baskets provided.
 - To disconnect, press the power button, then remove the plug from the wall outlet.

Obsah je uzamčen

**Dokončete, prosím, proces objednávky.
Následně budete mít přístup k celému dokumentu.**



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

**) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!