

CLASSIC		CHERRY	
ZY0802T	cool white	ZY0812T	multicolor
ZY0807T	cool white	ZY0817T	multicolor
ZY0803T	cool white	ZY0813T	multicolor
ZY0804T	cool white	ZY0814T	multicolor
ZY0805T	cool white	ZY0815T	multicolor
ZY0806T	cool white	ZY0816T	multicolor
ZY1702T	warm white	ZY1432T	vintage
ZY1428T	warm white	ZY1433T	vintage
ZY1703T	warm white	ZY1434T	vintage
ZY1704T	warm white		
ZY1705T	warm white		
ZY1429T	warm white		
NET			
ZY1446T	warm white		
ZY1447T	warm white		
ZY1449T	warm white		

GB	Christmas LED Lights + Timer
CZ	Vánoční LED osvětlení + Časovač
SK	Vianočné LED osvetlenie + Časovač
PL	Oświetlenie choinkowe LED + Timer
HU	Karácsonyi LED fényfüzér + Időzítő
SI	LED božična okrasna razsvetljava + Programska ura
RS HR BA	Novogodišnje LED osvjetljenje + Tajmer
DE	LED-Weihnachtsbeleuchtung + Timer
UA	Різдв'яне світлодіодне освітлення + Таймер
RO	Iluminație de crăciun cu LED + Temporizator
LT	Kalėdinė šviesos diodų girlianda + Laikmatis
LV	Ziemassvētku LED apgaismojums + Taimeris



**Type / Typ / Typ / Typ / Típus / Nasvet / Tip / Typ / тип / Tip
/ Tipas / Tips**

CLASSIC	ZY0802T
	ZY0807T
	ZY0803T
	ZY0804T
	ZY0805T
	ZY0806T
	ZY1702T
	ZY1428T
	ZY1703T
	ZY1704T
	ZY1705T
	ZY1429T
	ZY0812T
	ZY0817T
	ZY0813T
	ZY0814T
	ZY0815T
	ZY0816T
	ZY1432T
	ZY1433T
ZY1434T	

CHERRY	ZY0902T
	ZY1601T
	ZY1603T
	ZY1605T
	ZY0901T
	ZY0903T
	ZY1602T
	ZY1604T
	ZY0911T
	ZY0912T
	ZY1610T
ZY1612T	

NET	ZY1446T
	ZY1447T
	ZY1449T

GB Christmas LED Lights + Timer

Do not connect the chain to power supply if it is in packaging.

Light sources are not replaceable.

Do not connect another Christmas light.

When handling, disconnect from the power network.

In case of malfunction, do not remove bulbs and do not repair the chain!

Do not interfere with the connection.

Use only with the power source supplied with the product.

Suited for both indoor and outdoor use.

Timer (T)

The light chain has a built-in timer on the body of the transformer (adapter).

After the first connection, the chain will be constantly lit. After the second connection (a green light will light up), the timer will be set to 6 hours. Afterwards, it turns off automatically and will remain off for 18 hours. The timer will operate automatically in these intervals (6 hours on/18 hours off) until turned off by making a third contact.

Example:

The chain will turn on on 1 December at 18 o'clock. It will remain lit until midnight, then turns off automatically. On 2 December, it will turn on automatically at 18 o'clock and turn off again at midnight. That means that the chain only has to be turned on once, and it will automatically keep lighting in this fashion until you turn it off.

Changing the timer settings

If you wish to change the time when the chain automatically turns on and off (e.g. 19 o'clock until 1 o'clock), all you need to do is turn off the chain at the desired time (if it is turned on) and then turn it on again.

Note:

The timer may deviate by a few minutes per month. If you want to adjust the turn-on timer back to the original time, set the timer again.



Do not dispose with domestic waste. Use special collection points for sorted waste. Contact local authorities for information about collection points. If the electronic devices would be disposed on landfills, dangerous substances may reach groundwater and subsequently food chain, where it could affect human health.

CZ Vánoční LED osvětlení + Časovač

Nepřipojujte řetěz k napájení, pokud je v obalu.

Světelné zdroje nejsou vyměnitelné.

Nenapojujte další vánoční svítidlo.

Při manipulaci odpojte z elektrické sítě.

V případě poruchy nevytahujte žárovky a řetěz neopravujte!

Nezasahujte do zapojení.

Používejte jen se zdrojem dodaným k výrobku.

Vhodné jak pro vnitřní, tak i venkovní použití.

Časovač (T)

Tento světelný řetěz má na těle transformátoru (adaptéru) zabudovaný časovač.

Po prvním sepnutí bude řetěz svítit stále. Po druhém sepnutí (rozsvítí se zelené světlo) se nastaví časovač na dobu 6 hodin. Poté se automaticky vypne a bude po dobu 18 hodin vypnutý. V těchto intervalech (6 hodin zapnuto/18 hodin vypnuto) bude automaticky pracovat do té doby, dokud ho třetím sepnutím nevypnete.

Obsah je uzamčen

Dokončete, prosím, proces objednávky.

Následně budete mít přístup k celému dokumentu.



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

**) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!