


CANDY

Instruction Manual For Induction Hob	ENGLISH
Table De Cuisson Induction	FRENCH
Návod k použití pro indukční varnou desku	CECK
Brugervejledning til induktionskogetop	DANISH
Manuale di istruzioni per piano cottura a induzione	ITALIAN
Manual de instrucciones para encimera de inducción	SPANISH
Induktiokäyttöä ohjeita.	FINN
Gebrauchsanleitung für Induktions-Kochfeld	GERMAN
Bruksanvisning for induksjonsplatetopp	NORWEGIAN
Instrukcja użytkowania indukcyjnej płyty grzejnej	POLISH
Руководство по эксплуатации индукционной варочной панели	RUSSIAN
Instruktionshandbok för induktionshäll	SWEDISH
Gebruiksaanwijzing inductiekookplaat	DUTCH
Manual de Instruções da placa de indução	PORTUGUESE
Navodila za uporabo indukcijskih kuhalnih plošč	SLOVENIAN
Návod na použitie indukčnej varnej dosky	SLOVENSKY

CTP634SC, CTP643SC, CCTP644S, CTP644SCWIFI

Thank you for purchasing the CANDY induction hob. Please read this instruction manual carefully before using the hob and keep it in a safe place for future reference.

By placing the CE  marking on this product, we declare, on our own responsibility, compliance to all the European safety, health and environmental requirements stated in the legislation for this product. As applicable, the parts of this appliance are compliant to: REGULATION (EC) No 1935/2004 on materials and articles intended to come into contact with food.

Safety Reminding and Maintenance:

- **WARNING:** The appliance and its accessible parts become hot during use. Care should be taken to avoid touching heating elements.
- Children under 8 Year of age must be kept away from the appliance unless they are continuously supervised.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the
- appliance in a safe way and understand the hazards involved. Children must not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision
- **WARNING:** Unattended cooking on a hob with fat or oil can be dangerous and may result in fire.
- **NEVER** try to extinguish a fire with water, but switch off the appliance and then cover flame e.g. with a lid or a fire blanket.
- **WARNING:** Danger of fire: do not store items on the cooking surfaces.

Obsah je uzamčen

Dokončete, prosím, proces objednávky.

Následně budete mít přístup k celému dokumentu.



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

**) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!