

PHILCO®



Famous for Quality the World Over

VACUUM SEALER
VAUKOVÁ SVÁŘEČKA
VÁKUROVÁ ZVÁRAČKA
ZGRZEWARKA PRÓŻNIOWA
VÁKUUM HEGESZTŐ



PHVS 3030

User's Manual
Návod k obsluze
Návod na obsluhu
Instrukcja obsługi
Használati utasítás

CONTENTS

1. IMPORTANT SAFEGUARDS	3
2. FOOD STORAGE GUIDE	4
3. FEATURES AND FUNCTIONS	5
PRODUCT PICTURE:.....	6
4. OPERATING INSTRUCTIONS	7
VACUUM PACKAGING USING BAGS	7
SEALING PACKAGING USING BAGS.....	7
VACUUMING PACKAGING USING ACCESSORY CANISTERS OR CONTAINERS	8
OPEN ACCESSORY CANISTERS OR CONTAINERS	8
5. CLEANING AND MAINTENANCE	8
6. TROUBLE SHOOTING	9
7. TECHNICAL SPECIFICATIONS	9

1. IMPORTANT SAFEGUARDS

1. Always unlock the lid when the appliance is plugged in or unplugged from the power outlet and when not in use or before cleaning.
2. This appliance is not a toy. Children should be supervised to ensure they are not close to the appliance when it is in use. Keep this appliance out of reach of children when not in use.
3. Use of embossed vacuum bags is recommended. Do not use appliance for other than intended purpose.
4. Do not use appliance if the power cord is damaged and it must be replaced by a recommended qualified technician.
5. Do not make skin contact with the hot sealing strip located on the edge of the top lid of this appliance. **It is hot and may result in burns.**
6. It is forbidden to repair this appliance without permission. If repair is needed, please send it to Service Center.
7. Do not use appliance if it has been or may be damaged.
8. Avoid the following operations: Pull the power cord when moving the appliance; hold the power cord as a handle; make the power cord stuck inside the crack; wrap the power cord around the sharp edges of an object; use appliance when the power cord or power outlet is wet.
9. Do not place the appliance near hot gas, heated ovens, electric burners or any heated area. Do not use appliance in a wet or humid environment.
10. In case of a power outage, to avoid accidents, please do not pull on the cord to remove the plug from the power outlet.
11. Do not handle or operate the appliance with wet hands.
12. Always operate the appliance on a stable surface and keep it away from moving objects to avoid damaging it.
13. Do not oil or lubricate this appliance.
14. Do not immerse cord, plug or any other parts of this appliance in any liquid.

Obsah je uzamčen

Dokončete, prosím, proces objednávky.

Následně budete mít přístup k celému dokumentu.



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

**) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!