

CE

Teläair

AIR CONDITIONER



Silent 5400H
MANUAL FOR INSTALLATION AND
USER MANUAL

GB

ENGLISH

v.002 July 2015



Via E. Majorana , 49 48022 Lugo (RA) ITALY

"CE" DECLARATION OF CONFORMITY

in compliance with EC Machine Directive 2006/42/EC

It is hereby declared that the air conditioner specified below has been designed and built in compliance with essential safety and health requisites as per the European Directive on Machine Safety.

This declaration is rendered null and void in the event of incorrect assembly, improper use or modifications made to the machine without our written approval.

Machine: AIR CONDITIONER

Model: SILENT 5400 H

Serial n°

Reference directive:

Machine Directive 2006/42/CE

Low Voltage Directive 2006/95/CE

Electromagnetic compatibility 2004/108/EC

Applied harmonised standards, especially: EN55014-1 ; EN55014-2 ; EN61000-3-2 ; EN61000-3-3 ; EN62233 ; IEC/EN 60335-1 ; IEC/EN 60335-2-40 ; 2009/19/CE ; DIN EN 378-2

DATE15/04/2015.....

C.E.O.

A handwritten signature in black ink, appearing to read "Rauffo".

CONTENTS

1 INTRODUCTION	4
1.1 Purpose and field of application of this manual	4
1.2 Key to symbols and definitions	4
1.3 General information	4
2 IDENTIFYING THE AIR CONDITIONER	5
2.1 Components (fig. 1)	5
2.2 ID label	5
2.3 Technical specifications	6
3 TRANSPORT, HANDLING, STORAGE.....	6
3.1 Storage	6
3.2 Weight	6
3.3 Handling	6
4 INSTALLATION.....	6
4.1 Preliminary information	6
4.2 Installation	7
4.3 Positioning the air conditioner	9
4.4 Connecting the power lead	10
4.5 Installing the diffuser	11
5 INSTRUCTIONS FOR USE	11
5.1 Introduction	11
5.2 Preliminary checks	12
5.3 Useful tips	12
5.4 Installing batteries in the Remote Control	12
5.5 Information on Remote Control use	12
5.6 Remote control key definitions/ functions	13
5.7 Remote control display (fig. 19)	13
5.8 Setting system time on remote control	14
5.9 Automatic operation mode	14
5.10 Cold operation mode	14
5.11 Heating operation mode	14
5.12 Diffuser Display	15
5.13 Cleaning the filters	15
5.14 Timer setting	15
5.15 Operation without remote control	15
6 SAFETY REGULATIONS	16
7 TROUBLESHOOTING	16
8 DISPOSAL	17
9 MAINTENANCE	17
9.1 Routine maintenance	17
GENERAL TERMS OF WARRANTY	18
WIRING DIAGRAM	19
SPARE PARTS LIST	20

Obsah je uzamčen

Dokončete, prosím, proces objednávky.

Následně budete mít přístup k celému dokumentu.



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

**) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přizívají na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!