

REVLON®



DOUBLE STRAIGHT
Copper Ceramic Dual Plate Straightener

RVST2204E

CONTENTS

ENGLISH (GB)	2	Use and Care Instruction Manual
ČEŠTINA	5	Návod k použití a péči o přístroj
DEUTSCH	8	Gebrauchs- und Pflegeanleitung
DANSK	11	Brugsanvisning og vedligeholdelsesinstruktion
ESPAÑOL	14	Manual de instrucciones de uso y precauciones
SUOMI	17	Käyttö- ja hoito-ohje
FRANÇAIS	20	Manuel d'utilisation et d'entretien
ΕΛΛΗΝΙΚΑ	23	Οδηγίες χρήσης και φροντίδας
MAGYAR	26	Használati és karbantartási tanácsok
ITALIANO	29	Istruzioni per l'uso e la manutenzione
NEDERLANDS	32	Handleiding voor gebruik en verzorging
NORSK	35	Håndbok for bruk og stell av apparatet
POLSKI	38	Instrukcja użycia i konserwacji
PORTUGUÊS	41	Manual de instruções de utilização e cuidados
ROMÂNĂ	44	Manual de utilizare și întreținere
РУССКИЙ	47	Руководство по использованию и уходу
SVENSKA	50	Instruktioner för användning och underhåll
TÜRKÇE	53	Kullanım ve Bakım Kılavuzu
ENGLISH (ZA, KW)	56	Additional Important Safety Instructions

Copper Ceramic Dual Plate Straightener

Keramicko-médéná žehlička s dvojími destičkami
Haarglätter mit zwei Kupfer-Keramikplatten
Kobberkeramisk glattejern med dobbeltplader
Plancha de cerámica y cobre de doble placa
Kuparikeramainen kaksilevyinen suoristusrauta
Lisseur doubles plaques en céramique et cuivre
Ισιωτικό με διπλές κεραμικές πλάκες χαλκού
Réz kerámia kétlappos hajjegyenesítő
Piastra in rame con doppio rivestimento ceramico
Stijtang met dubbele platen van keramiek met kopercoating

Copper Ceramic Dual Plate Straightener
Prostownica z podwójną płytą ceramiczną z powłoką miedzianą
Alisador de placa dupla em cerâmica e cobre
Placă dublă de îndreptat părul, cu plăci din inveliş ceramic și cupru
Выпрямитель для волос с двойными медно-керамическими пластинами
Plattång med dubbel platta i koppar/keramik
Bakır Seramik Çift Maşalı Düzleştirici



KEEP THESE IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions before using this appliance. This appliance is intended for household use only.

These instructions are also available on our website. Please visit www.helenofroy.com/emea-en/



WARNING: Do not use this appliance near bathtubs, showers, basins or other vessels containing water.

This appliance can be used by children aged from 8 years and above, and by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.

Children should be supervised to ensure that they do not play with the appliance.

Cleaning and user maintenance shall not be made by children without supervision.

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

WARNING: Do not leave the appliance unattended. Do not allow bare skin or the eyes to come into contact with any heated surface on the appliance when in use. Do not place the appliance on any heat-sensitive surfaces when hot or plugged into the mains. Always unplug the appliance when not in use.

WARNING: Do not use this appliance on synthetic hair or wigs.

NOTE: Use on dry hair only.

WARNING: Should this product malfunction, do not attempt to repair it. This appliance has no user-serviceable parts or components.

Copper Ceramic Dual Plate Straightener

Only use this appliance for its intended purpose as described in this manual.

Advanced Copper 3x Ceramic Plates

Ultra-smooth Advanced Copper 3X Ceramic Coating transfers heat fast and helps reduce damage from over-styling with even heat distribution for reduced frizz.

Smart Heat Memory System

State-of-the-art design automatically recalls the last temperature as your preferred heat setting.

Colour Fade Control*

Preserves hair colour temperature settings of 200°C or below. Turn the unit on by pressing the ON/OFF Button. Press the + / - symbols button to select your preferred setting. Your straightener will recognize the selected heat temperature the next time the unit is turned on.

Plate-Locking Switch

For easier storage, the plates of the flat iron can be locked together. To engage the locking switch, first turn the appliance off and unplug it. Push the switch up while pressing the handles together to lock the plates. To unlock, press the handles together and push the unlock switch down.

WARNING: DO NOT engage the plate-locking switch during styling, and DO NOT lock the plates onto hair, as serious damage to hair or even injury could result.

Operating The Double Straightener

Straightening and smoothing irons should be used only on clean, dry hair.

- Plug the straightener into an electrical outlet and press On/Off button.
- The Double Straightener automatically sets to 140 °C. Choose your temperature according to your hair type.
- Use the Heat Adjustment Buttons (+/-) to select the heat level best suited to your hair type.
- Allow the appliance at least 30 seconds heating time.

NOTE: Once temperature is selected, the temperature setting will blink for 30 seconds. Once the temperature becomes solid, the straightener is ready to use.

- When changing temperature settings, you will see temperature flashing until selected temperature is reached.
- For best results, follow the 10 LED Heat Settings guidelines below:

Hair Type	Temperature °C
Fine, thin colour-treated hair	140 - 160 °C
Medium to wavy hair	170 - 190 °C
Curly to thick hair	200 - 210 °C
Coarse, hard-to-style-hair	220 - 235 °C

Styling Tips

Separate your hair in up to 5 cm sections.

- Gently place hair between the straightening plates and clamp the straightener down firmly on the hair.
- You will achieve professional results if you work from the scalp to the ends of your hair.
- Once the straightener is heated, slide the iron along the isolated section, making sure the hair is heated and straightened all the way to the ends. The ends will probably require less heat than the hair that grows closer to the scalp.
- For best results, hold ends of hair while smoothing the hair section.
- To remove hair from the flat iron, simply release pressure and allow the hair to gently slip out from the straightening plates.
- The straightening process does not require overlapping; separate each section of hair and work on it as indicated above.
- Allow hair to cool before combing or brushing.
- Repeat the process until you have achieved the look you desire.

IMPORTANT: The high-performance heater in this unit contains an oil-based protective coating that will burn off during the first few minutes of initial use and may emit smoke and/ or an odor. You may also hear a humming noise during use. This is normal and is not a cause for concern.

When storing the straightener, unplug it and allow the appliance to cool completely. Lock plates by following instructions above (PLATE-LOCKING SWITCH). This will conserve space and help protect the appliance when not in use. When ready to use again, slide the locking switch to unlock and open the straightener.

Automatic Shut-Off

Your appliance has an Automatic Shut-off feature. Should you forget to turn off the appliance, it will automatically shut off after one hour.

Automatic Worldwide Dual Voltage

This appliance will automatically adjust to the correct voltage.

FEATURES (See page 1)

- Cool Tip**
- Four - 12.7 mm Copper Ceramic Plates**
- LED Digital Temperature Display**
- Tangle-free swivel cord**
- Plate locking switch**
- On/off power button**
- Separate '+' & '-' temperature buttons**

The appearance of this appliance may differ from the illustration.

Cleaning

Always unplug the appliance from the mains after use and allow it to cool before cleaning. To clean, wipe the appliance and plates with a damp cloth.

Obsah je uzamčen

Dokončete, prosím, proces objednávky.

Následně budete mít přístup k celému dokumentu.



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

**) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!