



SIMPLE OPERATING INSTRUCTIONS

EN | DE | CZ | SK | HU

TRIQ

True Wireless Earbuds

Want to see a TRICK? Try TRIQ!

Before you begin using the earphones, remove the protective film from the charging pins. After removing the earphones from the charging case, the earphones start automatically, switch to pairing mode, and the LEDs on both earphones begin to flash quickly. You can now pair the earphones with your phone. After successful pairing, you will hear “Connected” from the earphones. After pairing, the earphones automatically connect to the phone the next time you use them. **The earphones can also be turned on manually** by pressing the multi-function button on both earphones for three seconds. When you put the earphones back in the case, they turn off automatically. (The case LED lights up for four seconds and then goes out). **The earphones can also be switched off manually.** It is necessary to unpair them from the phone first and then hold the multi-function buttons on both earphones for four seconds. **The earphones turn off automatically** if they are not paired with the phone or if they are out of Bluetooth range.

Earphone function – touch gestures

Adjust volume

+ Increase: Single tap the R earphone

- Decrease: Single tap the L earphone

Answering a call: When a call is incoming, single tap the **L** or **R** earphone

Ending a call: Double tap the **L** or **R** earphone

Rejecting a call: When a call is incoming, hold the **L** or **R** earphone for two seconds



Play/Pause

Double tap the **L** or **R** earphone

Next track

Hold the **R** earphone for two seconds

Previous track

Hold the **L** earphone for two seconds

Turning on SIRI

Triple tap the **L** or **R** earphone

When to use it? E.g. after an unsuccessful connection to the phone or when only one earphone is playing. However, it can help in many other situations.

1. Delete **“Intezze TRIQ”** from the list of paired devices on the phone. Ideally, turn off the Bluetooth function on your phone as well.
2. Remove both charged earphones from the case and put them into your ears. You will hear **“Pairing”** from the earphones.
3. Quickly tap the multifunction button on both earphones five times, a short tone sounds, then **“Power OFF”** and the earphones turn off. By holding down both multifunction buttons for three seconds, the earphones will turn on again and you will hear **“Power ON”**.
4. After a short time, **“Pairing”** is heard in the earphones. This completes the reset successfully and the earphones can be paired with the phone again.

Warranty conditions - The warranty does not cover the following situations:

1. Damage caused by unauthorised tampering with the device.
2. Filters clogged by earwax (may not be immediately visible) or otherwise needing cleaning. Cleaning must be done by an authorised service and a fee is charged.
3. Earbuds with their duct filters removed.
4. Physical damage to the earbuds caused by a fall or impact.
5. Damage caused by force majeure.

Obsah je uzamčen

Dokončete, prosím, proces objednávky.

Následně budete mít přístup k celému dokumentu.



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

**) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!