


USER'S MANUAL
NÁVOD K OBSLUZE
NÁVOD NA OBSLUHU
INSTRUKCJA OBSŁUGI
HASZNÁLATI ÚTMUTATÓ
KORISNIČKI PRIRUČNIK
KORISNIČKI PRIRUČNIK
ΕΓΧΕΙΡΙΔΙΟ ΧΡΗΣΤΗ

Mini Bluetooth Soundbar TIMBRE
Mini Bluetooth Soundbar TIMBRE
Mini Bluetooth Soundbar TIMBRE
Mini Bluetooth Soundbar TIMBRE
Mini Bluetooth Soundbar TIMBRE
Mini Bluetooth Soundbar TIMBRE
Mini Bluetooth Soundbar TIMBRE
Μίνι ηχητική μπάρα Bluetooth TIMBRE

EN CZ SK PL HU RS HR EA




 **YENKEE**

YSP 3050

USER'S MANUAL

- 1 | "Vol -" button to decrease volume/jump to previous track
- 2 | "Vol +" button to increase volume/jump to next track
- 3 | On/Off Button
- 4 | LED indicator
- 5 | "Play/Pause" button
- 6 | Charging socket (micro USB)
- 7 | Socket for audio AUX IN mini jack (3.5 mm)
- 8 | Reset button

Before first use, please charge the BT speaker to a maximum level. Hold down the power On button to turn on the BT speaker. To turn the BT speaker off, hold down the power On button. In case of problems with turning the device off, please use the RESET button on the speaker rear side.



1. LED indicators

The LED indication speed and colour vary with the BT speaker status (Bluetooth pairing readiness, pairing to another device, playback, audio jack connection, device charging).

2. Pairing devices via Bluetooth

Turn the BT speaker on and in the device you wish to pair, search for the speaker's Bluetooth name "TIMBRE", then start the pairing process. When you are prompted to enter the pairing code, please enter: "0000". After disconnecting the paired device, hold down the "Play/Pause" button until a beep sounds.

3. Audio AUX IN

Your device can be connected to the BT speaker via the audio cable. First connect the audio plug to your device and then to the BT speaker's jack.

Caution: before connecting your device to the BT speaker, make sure that your device's output signal is set to minimum.

4. Track playback

During current track playback, you can jump to the next track by holding down the "Vol +" button. To select previous track, please hold down the "Vol -" button.

5. Charging

A charged battery provides power for several hours of operation at normal volume levels. A high volume will consume the battery energy faster. Low battery status will be announced by an acoustic signal.

YOU CAN DOWNLOAD THE EXTENDED MANUAL VERSION at www.yenkee.eu

Instructions and information regarding the disposal of used packaging materials

Dispose of packaging material at a public waste disposal site.



Disposal of used electrical and electronic appliances

The meaning of the symbol on the product, its accessory or packaging indicates that this product shall not be treated as household waste. Please, dispose of this product at your applicable collection point for the recycling of electrical & electronic equipment waste. Alternatively in some states of the European Union or other European states you may return your products to your local retailer when buying an equivalent new product.

The correct disposal of this product will help save valuable natural resources and help in preventing the potential negative impact on the environment and human health, which could be caused as a result of improper liquidation of waste. Please ask your local authorities or the nearest waste collection centre for further details. The improper disposal of this type of waste may fall subject to national regulations for fines.

For business entities in the European Union

If you wish to dispose of an electrical or electronic device, request the necessary information from your seller or supplier.

Disposal in other countries outside the European Union

If you wish to dispose of this product, request the necessary information about the correct disposal method from local government departments or from your seller.



This appliance complies with EU rules and regulations regarding electromagnetic and electrical safety.

Changes to the text, design and technical specifications may occur without prior notice and we reserve the right to make these changes.

Hereby, FAST ČR, a.s. declares that the radio equipment type YSP 3050 is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address: www.yenkee.eu

Obsah je uzamčen

Dokončete, prosím, proces objednávky.

Následně budete mít přístup k celému dokumentu.



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

**) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!