



# One by wacom®



## User's manual

Wacom Tablet (CTH-471, CTH-671)

[Setting up your tablet](#)

[Customizing your tablet](#)


[Customize your pen experience](#)

[Caring for your tablet](#)

[Troubleshooting](#)

[Product information](#)

[Technical support options](#)





One by Wacom User's Manual

Version 1.3, Rev B0314

Copyright © Co., Ltd., 2014

All rights reserved. No part of this manual may be reproduced except for your express personal use. Wacom reserves the right to revise this publication without obligation to provide notification of such changes. Wacom does its best to provide current and accurate information in this manual. However, Wacom reserves the right to change any specifications and product configurations at its discretion, without prior notice and without obligation to include such changes in this manual.

The above year indicates when this manual was prepared. However, the date of release to the users of the manual is simultaneous with the introduction into the market of the applicable Wacom product.

Wacom is a registered trademark of Wacom Co., Ltd.

Adobe and Photoshop are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States and/or other countries. Microsoft, Windows, and Vista are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries. Apple, the Apple logo, and Mac are trademarks of Apple, Inc., registered in the U.S. and other countries.

Any additional company and product names mentioned in this documentation may be trademarked and/or registered as trademarks. Mention of third-party products is for information purposes only and constitutes neither an endorsement nor a recommendation. assumes no responsibility with regard to the performance or use of these products.





## TABLE OF CONTENTS

TABLE OF CONTENTS	3	Technical support options	37
ABOUT THE MANUAL	4	Obtaining driver downloads	38
GETTING STARTED	5	Product information	38
Your Pen tablet	5	APPENDIX	39
Pen	6	Caring for your tablet	39
Pen holder	6	Replacing the pen nib	40
SETTING UP YOUR TABLET	7	Uninstalling	41
Ergonomics	7	Managing preferences	42
Configuring tablet orientation	8	Pen and digital ink capabilities in Windows	43
Working with multiple monitors	9	Product information	44
Control panel basics	9	Ordering parts and accessories	45
USING YOUR TABLET	10	Available accessories	45
The pen experience with the tablet	11	GLOSSARY	46
Using the pen on the tablet	11	Wacom international offices	48
Positioning	12		
Clicking	13		
Dragging	13		
Using the pen buttons	14		
Writing and drawing with pressure sensitivity	15		
Erasing	16		
Eye-hand coordination exercise	17		
Customizing pen input	17		
CUSTOMIZING YOUR TABLET	18		
Opening the control panel	18		
Control panel overview	19		
Customize your pen experience	20		
Setting the tip and eraser feel, and double-click distance	21		
Setting the pen button functions	22		
Setting the tablet mapping	23		
Portion of screen area	25		
Portion of tablet area	25		
Setting the pen speed in mouse mode	26		
Customizing tablet Orientation	27		
Button functions	28		
Testing your tablet	32		
Testing a pen	32		
Troubleshooting	33		
General problems	33		
Pen input problems	33		
Windows-specific problems	35		
Mac-specific problems	35		



# Obsah je uzamčen

**Dokončete, prosím, proces objednávky.  
Následně budete mít přístup k celému dokumentu.**



**Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:**

1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne\*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

*\*) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!