



PORTABLE SOUND SYSTEM 8"/20CM - 300W
WITH USB, BLUETOOTH, FM & MIC

ENCEINTE PORTABLE 8"/20CM - 300W
AVEC USB, BLUETOOTH, FM et MICRO

TRAGBARES SOUNDSYSTEM 8"/20CM - 300W
MIT USB, BLUETOOTH, UKW RADIO & MIKROFON

DRAAGBARE GELUIDSYSTEEM 8"/20CM - 300W
MET USB, BLUETOOTH, FM en MICRO

SISTEMA DE SONORIZACIÓN PORTÁTIL 8"/20CM - 300W
CON USB, BLUETOOTH, FM y MICRO

REF. PARTY-8LED

Code: 15-6100PLS

USER MANUAL


FR - MANUEL D'UTILISATION - p. 7
DE - BEDIENUNGSANLEITUNG - S. 11
NL - HANDLEIDING - p. 15
ES - MANUAL DE USO - p. 19t



*Imported from China by LOTRONIC S.A.
Avenue Zénobe Gramme 9
B-1480 Saintes*

© Copyright LOTRONIC 2019





PORTABLE SOUND SYSTEM 8"/20CM - 300W

WITH USB, BLUETOOTH, FM & MIC

INSTRUCTION MANUAL

Please read the manual carefully and keep it for future reference.




The lightning flash with arrowhead symbol, within an equilateral Triangle, is intended to alert the user to the presence of not insulated dangerous voltages within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.



Important Safety instructions and danger warnings

- ⚡ All safety instructions and warnings must be adhered to. They are part of the manual and must be kept with the manual.
- ⚡ Any guarantee claims are rendered invalid if damage occurs due to non-observance of these operating instructions. We assume no liability for any consequent damage.
- ⚡ We assume no liability for personal injury or damage to property caused by incorrect handling or non-observance of the safety instructions. Any guarantee claims expire in such cases.
- ⚡ Unauthorized conversions and/or modifications of the appliance are not permitted for safety and licensing reasons (CE).
- ⚡ The appliance is approved for operation in dry, closed rooms only . Do not operate the device nearby water, such as in bathrooms or nearby swimming pools.
- ⚡ The appliance may not be exposed to extreme temperatures ($< +5^{\circ}\text{C}$ / $> +35^{\circ}\text{C}$) in operation.
- ⚡ The appliance may not be subjected to strong vibrations or heavy mechanical strain.
- ⚡ The appliance may not be exposed to excessive moisture (due to dripping or sprayed water, for example).
- ⚡ Do not place any recipients filled with liquids, such as glasses or vases, on top of or directly next to the appliance. They could fall over, causing water to enter the appliance. Never pour out liquids above the appliance. Do not place any small objects, such as coins or paper clips, on the appliance since they could fall inside the appliance. You run a high risk of causing a fire or life-threatening electrocution!
- ⚡ Never place the appliance on an unstable or movable surface. Persons could be injured or the appliance damaged by it falling down.
- ⚡ When using a rack, make sure it is in a stable position and is transported securely. Installation on uneven, slanted surfaces or stopping the rack abruptly during transport can result in the rack overturning or appliances falling from or out of the rack and injuring people.
- ⚡ Live components can be exposed by opening covers or removing components (unless this can be done without tools). Contact points can also be live. If the appliance has to be opened in order to calibrate, service, repair or replace components or assemblies, all of its poles must be disconnected from all sources of voltage first. If the appliance has to be kept open and under voltage during maintenance or repairs, this work may only be carried out by a specialist who is familiar with the risks involved and the relevant regulations.
- ⚡ Never connect the appliance directly after transferring it from a cold to a warm room. The condensation water that forms could destroy the appliance or result in an electric shock. Allow the device to reach room temperature before connecting it. Wait until the condensation water has evaporated. This can take some hours.
- ⚡ Do not place any naked flames such as those of burning candles on or next to the appliance.
- ⚡ Do not place the appliance on soft surfaces such as carpets or beds. Do not cover the air vents of the appliance. Do not obstruct the air circulation with objects such as magazines, table cloths or curtains. This prevents the dissipation of heat from the appliance and can result in overheating.
- ⚡ Only use the appliance in a moderate climate, not in tropical environments.
- ⚡ All persons involved in operating, installing and servicing the appliance and putting it into service must be trained and qualified accordingly and observe these operating instructions.
- ⚡ If you are not sure about the correct connection or if questions arise which are not answered by the operating instructions, please do not hesitate to contact support or a specialist of your choice. Consult a specialist if you

Obsah je uzamčen

Dokončete, prosím, proces objednávky.

Následně budete mít přístup k celému dokumentu.



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

**) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!