


Baseus



Baseus Control Smartphone Handheld Gimbal Stabilizer

User Manual • Uživatelský manuál •
Uživatelský manuál • Használati utasítás

Dear customer,

Thank you for purchasing our product. Please read the following instructions carefully before first use and keep this user manual for future reference. Pay particular attention to the safety instructions. If you have any questions or comments about the device, please contact the customer line.

✉ www.alza.co.uk/kontakt

☎ +44 (0)203 514 4411

Importer Alza.cz a.s., Jankovcova 1522/53, Holešovice, 170 00 Praha 7, www.alza.cz

Disclaimer and warning

Thank you for purchasing Baseus Control smartphone handheld gimbal stabilizer. The information about your safety and your legal rights and responsibilities. Read this entire document carefully to ensure proper configuration before use. Failing to read and follow the instructions and warnings may result in serious injury to you or bystanders, or damage to your device or property. Shenzhen Times Innovation Technology Co. Ltd. reserves the right of final explanation for this document and all relevant documents relating to Baseus Control, and the right to make changes at any time without notice. By using this product, you hereby signify that you have read this document carefully and that you understand and agree to abide by the terms and conditions herein. You agree that you are solely responsible for your own conduct while using this product, and for any consequences thereof. You agree to use this product only for purposes that are proper and in accordance with all terms, precautions, practices, policies and guidelines Shenzhen Times Innovation Technology Co. Ltd. (Baseus Control Smartphone Handheld Gimbal) has made and may make. Shenzhen Times Innovation Technology Co., Ltd. (Baseus Control Smartphone Handheld Gimbal) accepts no liability for damage, injury or any legal responsibility incurred directly or indirectly from the use of this product. Users shall observe safe operation guidelines including, but not limited to, those set forth herein.

Precautions

- Disconnect the product from the charger after charging.
- If you do not use the product for more than 10 days, please discharge the battery for 2 to 4 hours, then store it. This can prolong the battery life.
- Charge and discharge once every 3 months to keep the battery active.
- Keep the handle stable when the product powers on. Shaking during the start-up may cause start-up failure.
- Refer to the specification parameters for supported phones and accessories weight, otherwise the balance may not be adjusted and the using effect will be affected.
- Store the gimbal in the correct order.

Obsah je uzamčen

Dokončete, prosím, proces objednávky.

Následně budete mít přístup k celému dokumentu.



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

**) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!