


brother®

TZ
TAPE

P-touch

2400/2410



USER'S GUIDE

- Read this User's Guide before you start using your P-touch.
- Keep this User's Guide in a handy place for future reference.

INTRODUCTION

Thank you for purchasing the P-touch 2400/2410!

Your new P-touch will allow you to create labels and stamps for any need. Its versatility enables you to design custom labels by choosing from a variety of frame designs and from many characters sizes and styles. In addition, the five tape widths (1/4" (6 mm), 3/8" (9 mm), 1/2" (12 mm), 3/4" (18 mm), and 1" (24 mm)) and variety of tape colors allow you to print personalized labels, useful for color-coded filing. With the **Stamp** function, you can quickly and easily make stamps for reusable pre-inked stamp holders.

You no longer have to worry about urgent tasks that require professional printing. In the office, the factory, the lab, and the home, the quality and performance of the P-touch 2400/2410 make it an extremely practical machine.)

(The PT-2400 and the PT-2410 models are equipped with the same functions; however, only the PT-2410 includes a carrying case and AC adaptor.)

FCC NOTICE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help.

Patent numbers and patent publication numbers which are related to this product are as below:

USP4839742	USP4983058	USP5120147
USP4927278	USP5009530	
USP4976558	USP5069557	

Use only the adaptor designed exclusively for this machine. See GENERAL PRECAUTIONS on page 4.

CONTENTS

Getting Started

GENERAL DESCRIPTION	2
GENERAL PRECAUTIONS.....	4
BATTERIES	5
OPTIONAL AC ADAPTOR.....	6
CONNECTING THE P-TOUCH TO A COMPUTER	7
INSTALLING P-TOUCH EDITOR	8
STARTING UP P-TOUCH EDITOR.....	15
DESIGNING AN AUTO FORMAT LAYOUT.....	17
IMPORTING A GRAPHICS FILE	20
READING THE USER'S GUIDE	21
TAPE CASSETTE	23
ATTACHING LABELS	24
PRINT HEAD & ROLLERS	25

Learning the Ropes

DOOR LABEL EXAMPLE	28
ADDRESS LABEL EXAMPLE.....	32
STORAGE SHELF LABEL EXAMPLE	38

For Your Information

POWER KEY.....	46
CURSOR KEYS	47
CODE, ALT & SHIFT KEYS	49
SPACE KEY	52
RETURN KEY	53
NEW BLOCK FUNCTION	54
TAB FUNCTION	55
DELETE KEY	57
LINE OUT FUNCTION.....	58
CLEAR FUNCTION	59
ACCENT FUNCTION	62
SYMBOL FUNCTION.....	64

Obsah je uzamčen

Dokončete, prosím, proces objednávky.

Následně budete mít přístup k celému dokumentu.



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

**) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!