


Panasonic

Parts location



Charging indicator light (in a battery charger)

Fig. 1

How to insert a AA Battery




Fig. 2

How to insert a AAA Battery




Fig. 3

AA size and AAA size up to 4 pcs




Fig. 4

AA size and AAA size up to 4 pcs

GBR

Parts location

Thank you for purchasing the Panasonic BQ-CC17 Charger.

This manual contains important safety and operating instructions for the Panasonic BQ-CC17 Battery Charger.

Before using, please read the instructions and warnings on (1) the battery charger, (2) the batteries, and (3) the product using the batteries.

CAUTION

- To reduce the risk of injury, we recommend that Panasonic Ni-MH rechargeable batteries are used.
- Do not use or use non-rechargeable batteries.
- Do not charge a humid conditioner.
- Do not use the charger if it has become damaged.
- Do not use the charger after it has been dropped or damaged.
- Do not open the charger.
- Do not touch the charging indicator light.
- Do not touch the charging indicator light.
- Do not touch the charging indicator light.

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.

Children should not play with the appliance. Cleaning and user maintenance should not be made by children without supervision.

OPERATING INSTRUCTIONS

In diesem Ladegerät können 4 AA und/oder 2 AAA Batterien in verschiedenen Kombinationen aufgeladen werden (siehe Abb. 4).

For AA battery, insert from (1) terminal and push to (2) terminal. (Fig. 2)

For AAA battery, insert from (1) terminal and push to (2) terminal. (Fig. 3)

Do not use the charger if it has become damaged.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

DEU

Parts location

Vielen Dank für den Kauf dieses Panasonic BQ-CC17-Ladegeräts!

Diese Anleitung enthält wichtige Sicherheits- und Bedienungsanweisungen für das Panasonic Ladegerät BQ-CC17.

Bevor Sie das Ladegerät benutzen, lesen Sie bitte die Anleitungen und Warnhinweise auf (1) dem Ladegerät, (2) den Batterien und (3) dem Gerät, das die Akkus nutzt.

ACHTUNG

- Um das Beschädigungsrisiko zu reduzieren, empfehlen wir, nur wiederaufladbare Ni-MH-Akkus von Panasonic zu verwenden.
- Verwenden Sie keine nicht-wiederaufladbaren Batterien.
- Nicht in einem Luftfeuchtigkeitsschutzbehälter verwenden.
- Ladegerät nicht benutzen, nachdem es heruntergefallen ist oder beschädigt wurde.
- Ladegerät nicht verwenden, wenn es überhitzt ist.
- Verwenden Sie das Ladegerät nicht, wenn es überhitzt ist.
- Verwenden Sie das Ladegerät nicht, wenn es überhitzt ist.
- Verwenden Sie das Ladegerät nicht, wenn es überhitzt ist.

Dieses Gerät darf von Kindern ab 8 Jahren und von Personen mit eingeschränkter körperlicher, sensorischer oder geistiger Fähigkeiten oder mangelhaften Erfahrungen und Kenntnissen verwendet werden, sofern sie beaufsichtigt werden oder eine gründliche Einweisung in die sichere Nutzung des Geräts erhalten und die davon ausgehenden Gefahren verstanden haben.

Kinder dürfen mit dem Gerät nicht spielen. Das Gerät darf nicht von Kindern ohne Aufsicht gereinigt und gewartet werden.

BEWENIGUNGSANLEITUNG

In diesem Ladegerät können 4 AA und/oder 2 AAA Batterien in verschiedenen Kombinationen aufgeladen werden (siehe Abb. 4).

For AA battery, insert from (1) terminal and push to (2) terminal. (Fig. 2)

For AAA battery, insert from (1) terminal and push to (2) terminal. (Fig. 3)

Do not use the charger if it has become damaged.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

FRA

Parts location

Merci d'avoir acheté ce chargeur Panasonic BQ-CC17.

Ce manuel contient des conseils de sécurité et d'utilisation importantes pour le chargeur de piles Panasonic BQ-CC17.

Avant d'utiliser le chargeur, lire attentivement les instructions et les avertissements figurant sur (1) le chargeur de piles, (2) les piles et (3) le produit utilisant les piles.

ATTENTION

- Pour réduire le risque de blessures corporelles, et est recommandé d'utiliser des piles rechargeables Panasonic de Ni-MH.
- Ne pas utiliser de piles non rechargeables.
- N'utiliser pas le chargeur dans un environnement humide.
- N'utiliser pas le chargeur avec une pile endommagée.
- N'utiliser pas le chargeur si le chargeur est tombé ou endommagé.
- N'utiliser pas le chargeur si le chargeur est tombé ou endommagé.
- N'utiliser pas le chargeur si le chargeur est tombé ou endommagé.
- N'utiliser pas le chargeur si le chargeur est tombé ou endommagé.

Cet appareil peut être utilisé par des enfants âgés de 8 ans et plus, des personnes avec des capacités physiques, sensorielles ou mentales réduites, ou des personnes manquant d'expérience et de connaissances seulement si elles ont été formées et ont reçu des instructions pour l'utilisation de cet appareil en toute sécurité et qu'elles comprennent les risques encourus.

Les enfants ne doivent pas jouer avec l'appareil. Le nettoyage et l'entretien par l'utilisateur ne doivent pas être effectués par des enfants sans surveillance.

CONSIGES D'UTILISATION

Ce chargeur permet de charger 4 piles 4 AA ou/et 2 AAA en différentes combinaisons (voir fig. 4).

For AA battery, insert from (1) terminal and push to (2) terminal. (Fig. 2)

For AAA battery, insert from (1) terminal and push to (2) terminal. (Fig. 3)

Do not use the charger if it has become damaged.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Do not touch the charging indicator light.

Obsah je uzamčen

Dokončete, prosím, proces objednávky.

Následně budete mít přístup k celému dokumentu.



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

**) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!