



hama

00
186380

Weather Station

Premium

Wetterstation

Operating Instructions

GB

Bedienungsanleitung

D

Mode d'emploi

F

Instrucciones de uso

E

Gebruiksaanwijzing

NL

Istruzioni per l'uso

I

Instrukcja obsługi

PL

Használati útmutató

H

Manual de utilizare

RO

Návod k použití

CZ

Návod na použitie

SK

Manual de instruções

P

Bruksanvisning

S

Руководство по эксплуатации

RUS

Работна инструкция



BG





Οδηγίες χρήσης

GR

Käyttöohje

FIN





Controls and Displays

- A1 Outdoor temperature
A2 Outdoor humidity
A3 Temperature and frost alarm
A4 Time and calendar display
A5 Moon phases
A6 Air pressure display
A7 24-hour air pressure display
A8 Room humidity
A9 Comfort display
A10 Room temperature
A11 Weather forecast
A12 Measuring station wireless symbol
A13 Wireless symbol
- B1 "☀/ZZ" button = Display lighting, interrupt alarm signal
B2 "☀" button = Switch between seconds and date display/ Settings/Confirm setting value
B3 "🕒" button = Set alarm time / Switch between alarm time and date display
B4 "▲" button = Increase the current setting value / Toggle between °C and °F / Activate/deactivate manual radio signal reception
B5 "▼" button = Reduce the current setting value / Retrieve values from individual outdoor radio sensors / Manually search for the signal from the measuring station
B6 "🔔" button = Temperature alarm / Set temperature limits for the temperature alarm
B7 "☀" button = Set display brightness (5 levels) / Change measurement unit for air pressure
B8 "MEM" button = Access/reset the stored maximum/ minimum values
B9 ON/OFF button = Switch alarm on/off
B10 Socket for power supply
B11 USB socket
B12 Battery compartment
B13 Recess for wall mounting
- C1 Temperature indicator
C2 Air humidity indicator
C3 Celsius / Fahrenheit setting key
C4 Channel setting key
C5 Battery compartment
C6 Cut-out for wall mounting

Thank you for choosing a Hama product.

Take your time and read the following instructions and information completely. Please keep these instructions in a safe place for future reference. If you sell the device, please pass these operating instructions on to the new owner.

1. Explanation of Warning Symbols and Notes

Warning



This symbol is used to indicate safety instructions or to draw your attention to specific hazards and risks.

Note



This symbol is used to indicate additional information or important notes.

Risk of electric shock



This symbol indicates product parts energized with a dangerous voltage of sufficient magnitude to constitute a risk of electric shock.

2. Package Contents

- Weather station (base station for indoors / measuring station for outdoors)
- 2 x AA batteries
- Power supply unit
- These operating instructions

3. Safety Notes

- The product is intended for private, non-commercial use only.
- Use the product for its intended purpose only.
- Protect the product from dirt, moisture and overheating, and only use it in a dry environment.
- Do not use the product in the immediate vicinity of heaters or other heat sources or in direct sunlight.
- Keep this product, as all electrical products, out of the reach of children!
- Do not operate the product outside the power limits given in the specifications.
- Do not use the product in areas where the use of electronic devices is not permitted.
- Do not use the product in moist environments and avoid splashes.
- Do not place the product near interference fields, metal frames, computers, TVs, etc. Electronic devices and window frames can negatively affect the product's functionality
- Do not drop the product and do not expose it to any major shocks.
- Do not modify the product in any way. Doing so voids the warranty.
- Keep the packaging material out of the reach of children due to the risk of suffocation.
- Dispose of packaging material immediately according to locally applicable regulations.

Obsah je uzamčen

Dokončete, prosím, proces objednávky.

Následně budete mít přístup k celému dokumentu.



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

**) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!