

For FAQs and more information, please visit:  
**[anker.com/support](https://anker.com/support)**



@anker\_official  
@anker\_jp



@Anker Deutschland  
@Anker Japan  
@Anker



@AnkerOfficial  
@Anker\_JP



Product Number: A1289 51005003435 V01



English	01
Čeština	05
Dansk	08
Deutsch	11
ελληνικά	14
Español	17
Suomi	20
Français	23
Magyar	26
Italiano	29
Nederlands	32
Norsk	35

Język polski	38
Português	41
Русский	44
Slovenský Jazyk	47
Slovenski Jezik	50
Svenska	53
Türk	56
日本語	59
简体中文	61
العربية	64
עברית	67

LCD Screen Information	
Temperature	Battery temperature
Battery Health	Battery health
Total Input	Total recharging input
Battery Cycle	Number of battery charging/recharging cycles
Total Output	Total charging output
Screen Uses	Number of times the screen has lit up

- The Power Bank will automatically turn off if the screen is on standby for 30 minutes.

## Important Safety Instructions

When using this product, basic precautions should always be followed, including the following:

- 1). Store this product in a cool and dry place.
- 2). Do not store this product in a hot or humid environment.
- 3). Use of a power supply or charger not recommended or sold by the product manufacturer may result in a risk of fire or personal injury.
- 4). Operating temperature should be between 0°C to 35°C / 32°F to 95°F.
- 5). Do not disassemble this product. Take it to a qualified service person when service or repair is required. Incorrect reassembly may result in a risk of fire or personal injury.
- 6). If this product is not used for long periods of time, you should charge and discharge it once every three months.
- 7). When charging a device, this product may feel warm. This is a normal operating condition and should not be a cause for concern.

- 8). In normal conditions, the battery performance will decline over several years.
- 9). Do not dispose of this product in heat or fire.
- 10). Do not clean this product with harmful chemicals or detergents.
- 11). Misuse, dropping, or excessive force may cause product damage.
- 12). When disposing of secondary cells or batteries, keep cells or batteries of different electrochemical systems separate from each other.
- 13). Be aware that a discharged battery may cause fire or smoke. Tape the terminals to insulate them.
- 14). CAUTION: Risk of explosion if the battery is replaced by an incorrect type.
- 15). WARNING: The batteries (battery pack or installed batteries) shall not be exposed to excessive heat such as from sunshine or fire.
- 16). A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

## SAVE THESE INSTRUCTIONS

**Note:** Only connect your Power Bank to a 2021 Apple MacBook Pro (16") using a USB-C to MagSafe 3 cable to achieve max power output (28V ≡ 5A) via a single port (USB-C 1 / USB-C 2).

## Declaration of Conformity

Hereby, Anker Innovations Limited declares that this product is in compliance with Directives 2014/35/EU, 2014/30/EU & 2011/65/EU. The full text of the EU declaration of conformity is available at the following internet address: <https://www.anker.com>

# Obsah je uzamčen

**Dokončete, prosím, proces objednávky.**

**Následně budete mít přístup k celému dokumentu.**



**Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:**

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne\*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

*\*) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!