

# **HOT TOOLS™**


## **PRO SIGNATURE™**


### **OWNERS MANUAL**

Dual Plate Straightener

HTST2589ED1

GB	<b>DUAL PLATE STRAIGHTENER</b> Use and Care Instruction Manual	3
CZ	<b>ŽEHLIČKA S DVOJITÝMI DESTIČKAMI</b> Návod k použití a údržbě	6
DE	<b>ZWEIPLATTEN-HAARGLÄTTER</b> Gebrauchs- und Pflegeanleitung	9
DK	<b>GLATTEJERN MED DOBBELTE PLADER</b> Brugsanvisning og vedligeholdelsesinstruktion	13
ES	<b>PLANCHA ALISADORA DE DOBLE PLACA</b> Manual de instrucciones de uso y precauciones	16
FI	<b>KAKSILEVYINEN SUORISTIN</b> Käyttö- ja hoito-ohje	19
FR	<b>LISSEUR À DOUBLES PLAQUES</b> Manuel d'utilisation et d'entretien	22
NL BE	<b>STIJLTANG MET DUBBELE PLATEN</b> Handleiding voor gebruik en verzorging	25
NO	<b>DUAL PLATE STRAIGHTENER</b> Håndbok for bruk og stell av apparatet	28
PL	<b>PROSTOWNICA Z PODWÓJNYMI PŁYTKAMI</b> Instrukcja obsługi i konserwacji	31
RU	<b>ВЫПРЯМИТЕЛЬ С ДВУМЯ ПЛАСТИНАМИ</b> Руководство по применению и уходу	34
SE	<b>DUBBEL PLATTÅNG</b> Instruktioner för användning och underhåll	38
ZA	Additional Safety Instructions	41





GB

## SAVE THESE IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions before using this appliance.

These instructions are also available on our website.

Please visit [www.helenofroy.com/emea-en/](http://www.helenofroy.com/emea-en/)

This appliance is intended for household use only.



**WARNING:** Do not use this appliance near bathtubs, showers, basins or other vessels containing water.

This appliance can be used by children aged from 8 years and above, and by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.

Children shall not play with the appliance.

Cleaning and user maintenance shall not be made by children without supervision.

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

**WARNING:** Do not leave the appliance unattended. Do not allow bare skin or the eyes to come into contact with any heated surface on the appliance when in use. Do not place the appliance on any heat-sensitive surfaces when hot or plugged into the mains. Always unplug the appliance when not in use.

**WARNING:** Do not use this appliance on synthetic hair or wigs.

**NOTE:** Use on dry hair only.

**WARNING:** Should this product malfunction, do not attempt to repair it. This appliance has no user-serviceable parts or components.

# Obsah je uzamčen

**Dokončete, prosím, proces objednávky.**

**Následně budete mít přístup k celému dokumentu.**



**Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:**

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne\*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

*\*) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!