

# LAMAX

ELECTRONICS

---

USER MANUAL

---

## LAMAX DRIVE C7



---

## CONTENTS

|                                                              |          |
|--------------------------------------------------------------|----------|
| <b>Introduction .....</b>                                    | <b>1</b> |
| <b>LAMAX DRIVE C7 car camera features and functions.....</b> | <b>1</b> |
| <b>Pack contents .....</b>                                   | <b>1</b> |
| <b>Product picture .....</b>                                 | <b>1</b> |
| <b>Product installation.....</b>                             | <b>2</b> |
| <b>Quick functions .....</b>                                 | <b>2</b> |
| <b>Icons annotation.....</b>                                 | <b>2</b> |
| <b>Using the LAMAX DRIVE C7 car camera .....</b>             | <b>3</b> |
| 1) Inserting Micro SDHC card .....                           | 3        |
| 2) Power.....                                                | 3        |
| 3) Turning the camera on and off .....                       | 3        |
| 4) Changing modes and menu navigation.....                   | 3        |
| 5) Recording / taking photos / gallery .....                 | 3        |
| 6) Timelapse recording .....                                 | 4        |
| 7) Deleting the entries on the camera .....                  | 4        |
| 8) Protecting the files on the camera .....                  | 4        |
| 9) Connecting to a PC.....                                   | 4        |
| <b>GPS function.....</b>                                     | <b>4</b> |
| <b>LAMAX Player .....</b>                                    | <b>4</b> |
| <b>LAMAX DRIVE C7 car camera settings – video mode.....</b>  | <b>4</b> |
| 1) Video settings.....                                       | 4        |
| 2) Video quality .....                                       | 5        |
| 3) Recording duration .....                                  | 5        |
| 4) Auto power off .....                                      | 5        |
| 5) SOS recording duration .....                              | 5        |
| 6) Microphone.....                                           | 5        |
| 7) Microphone sensitivity .....                              | 5        |
| 8) Exposure.....                                             | 5        |
| 9) White balance.....                                        | 5        |
| 10) ISO sensitivity.....                                     | 5        |
| 11) Parking mode.....                                        | 5        |
| <b>LAMAX DRIVE C7 car camera settings – photo mode.....</b>  | <b>5</b> |
| 1) Image size .....                                          | 5        |
| 2) Photo quality .....                                       | 5        |
| 3) Exposure.....                                             | 5        |
| 4) White balance.....                                        | 5        |
| 5) ISO sensitivity .....                                     | 5        |
| <b>LAMAX DRIVE C7 car camera general settings .....</b>      | <b>6</b> |
| 1) Key tones.....                                            | 6        |
| 2) Auto power off .....                                      | 6        |
| 3) Date/Time .....                                           | 6        |
| 4) Date format .....                                         | 6        |
| 5) Display location .....                                    | 6        |
| 6) Display speed.....                                        | 6        |
| 7) Display GPS .....                                         | 6        |
| 8) Refresh rate .....                                        | 6        |
| 9) USB.....                                                  | 6        |

---

---

|                                                   |          |
|---------------------------------------------------|----------|
| 10) Rotate display .....                          | 6        |
| 11) Screensaver.....                              | 6        |
| 12) G-sensor level .....                          | 6        |
| 13) Motion detection.....                         | 6        |
| 14) GPS status.....                               | 6        |
| 15) Choose time zone .....                        | 6        |
| 16) Restore factory settings .....                | 6        |
| 17) Format SD card .....                          | 6        |
| 18) SD card info .....                            | 7        |
| 19) Firmware version .....                        | 7        |
| <b>Language settings.....</b>                     | <b>7</b> |
| <b>LAMAX DRIVE C7 car camera parameters .....</b> | <b>7</b> |
| <b>Safety measures.....</b>                       | <b>8</b> |
| <b>Precautions and notices .....</b>              | <b>8</b> |
| <b>Safety precautions .....</b>                   | <b>8</b> |
| <b>Caring for your device .....</b>               | <b>8</b> |
| <b>Other information .....</b>                    | <b>9</b> |
| <b>Declaration of Conformity .....</b>            | <b>9</b> |

---

# Obsah je uzamčen

**Dokončete, prosím, proces objednávky.  
Následně budete mít přístup k celému dokumentu.**



**Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:**

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne\*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

*\*) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!