


E5068

GB	WIRELESS WEATHER STATION
CZ	BEZDRÁTOVÁ METEOSTANICE
SK	BEZDRÔTOVÁ METEOSTANICA
PL	BEZPRZEWODOWA STACJA METEOROLOGICZNA
HU	VEZETÉK NÉLKÜLI IDŐJÁRÁS-ÁLLOMÁS
SI	BREŽIČNA METEOROLOŠKA POSTAJA
RS HR BA	BEŽIČNA METEOROLOŠKA STANICA
DE	DRAHTLOSE WETTERSTATION
UA	БЕЗДРОТОВИЙ МЕТЕОРОЛОГІЧНИЙ ПРИСТРІЙ
RO	STAȚIE METEO FĂRĂ FIR
LT	BELAIDĖ ORO STOTELĖ
LV	BEZVADU METEOROLOĢISKĀ STACIJA

GB E5068 Wireless Weather Station



The weather station displays a clock, 2 alarms with the snooze function, weather forecast for the following 5 days, indoor and outdoor temperature, humidity, and the moon phase. It displays date and the day of the week. It has a memory of the minimum and maximum readings. Read carefully this manual before first using this product.

Specifications:

radio controlled clock

Indoor/outdoor temperature:	0 °C to +50 °C; -50 °C to +70 °C
temperature increments:	0.1 °C
temperature measurement accuracy:	± 1 °C (0 to 40 °C), otherwise ± 2 °C
wireless sensor:	transmission frequency 433 MHz
radio signal range:	up to 50 m in an open area
number of sensors:	max. 3
wire probe length:	1 m
relative humidity:	20 % - 95 %
resolution:	1 %
measurement accuracy:	± 5 % (30 - 80 %), otherwise ± 8 %
power supply:	
main station:	2× 1.5 V AA batteries (not supplied)
remote sensor:	2× 1.5 V AAA batteries (not supplied)
dimensions and weight without batteries:	
main station:	110 × 147 × 45 mm, 250 g
remote sensor:	100 × 60 × 21 mm, 54 g

Overview of icons and buttons

Front side and display

- A**– Weather forecast icon, pressure trend icon
- B**– Current time
- C**– Alarm icons No. 1 and 2
- D**– DCF77 radio signal reception icon
- E**– Icon for low battery in the weather station
- F**– Date
- G**– Day of the week
- H**– Moon phase icon
- I**– Outdoor temperature and humidity, icon for low battery in the sensor
- J**– Sensor No.
- K**– Day of the week
- L**– Weather forecast icon
- M**– Icon for maximum and minimum readings
- N**– Indoor temperature and humidity


Back side

	Press button	Press and hold (3 seconds)
MODE	-	Setting the time format, time zone, year, hours, date, day of the week and the day of the week language
+	Displays max/min temperature and humidity readings	-
-	Displays temperature in °C or °F; alarm activation	Searches for DCF77 signal
ALARM	Alarm time 1, 2	Setting an alarm
CHANNEL	Displays the sensor No.	Search for sensor 1, 2, 3

Top side

SNOOZE/LIGHT – Activates display backlight and snooze feat.

Wireless sensor



Obsah je uzamčen

Dokončete, prosím, proces objednávky.

Následně budete mít přístup k celému dokumentu.



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

**) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!