

HSM®

OPERATING INSTRUCTIONS PAPER SHREDDER



HSM FA 500.2

english



Keep this instruction for future use!

1.655.999.112 – 1002

Contents

1 Proper use, warranty.....3

2 Safety instructions.....3

3 Overview4

4 Dimensions5

5 Transportation, installation6

6 Operating and display elements on the keypad.....7

7 Start-up and inspecting the safety devices8

8 Malfunctions.....10

9 Maintenance and care10

10 Technical data.....13

11 Electric wiring diagrams for Solo- and Combination-version14

HSM (UK) Ltd.

14, Attwood Road / Zone 1
 Burntwood Business Park
 Burntwood
 Staffordshire
 WS7 3GJ
 United Kingdom

Phone: +44 (0) 1543 272 480
 Fax: +44 (0) 1543 272 080
info@hsmuk.co.uk
www.hsmuk.co.uk

HSM of America LLC

419 Boot Road
 Downingtown, PA 19335
 USA

Phone: 001 610 918 4894
 Fax: 001 610 918 4899
customerservice@hsmofamerica.com
info@hsmofamerica.com
www.hsmofamerica.com



HSM GmbH + Co. KG
 Austrasse 1-9
 88699 Frickingen / Germany

Tel. +49 7554 21 00-0
 Fax. +49 75 54 2100 160
info@hsm.eu
www.hsm.eu

1 Proper use, warranty

The document shredder is designed for destroying paper and cardboard, as well as store cards, credit cards, CD-ROMs and floppy discs. Its sturdy drive mechanism is not damaged by paper clips and staples and is even suitable for shredding whole files and folders.

Our general business conditions are applicable. We provide a one year warranty for the document shredder. The warranty period is 6 months when used in multiple shifts. This warranty excludes wear, damage due to improper handling, natural depreciation, and actions taken by third parties.

2 Safety instructions



Caution:

It is prohibited to operate one only machine of a combination-version machine.

- Before using the machine for the first time, read the operating manual, and keep it for later use and to pass on to any subsequent users.
- Do not remove or modify safety devices which guarantee the safe operation of the machine.
- Observe all safety instructions attached to the machine.
- Carry out inspection and maintenance regularly.
- Switch off the shredder, disconnect the power plug and call customer service in the following circumstances:
 - power cables or plugs are damaged
 - liquid has entered the shredder
 - the shredder has been exposed to rain
 - the machine does not work properly despite the operating manual having been observed
 - the shredder has been damaged
- No platforms or other raised surfaces may be placed near the shredder if they encroach on the specified safety clearances.

Warning

- Ensure that no unauthorised persons can access the document shredder. Do not leave the document shredder switched on when it is unattended. The shredder may not be operated by anyone under 16 years of age. When the machine is not in use, it must be shut down and secured against unauthorised use. To do so, you can secure the mains switch with a padlock when it is in the off position.



Danger of injury


Do not reach into the paper feed opening.

Splinters can cause injury

Wear protective goggles when destroying diskettes, CDs and hard credit cards.

Danger of injury during intake

Do not go near the paper feed opening with long hair, loose clothing, ties, scarves, necklaces, bracelets etc. Do not destroy any material which might become tangled, such as tapes, binder ties or foil.




Switch off the shredder and pull out the power plug before moving or cleaning the shredder, or any other task outside its normal scope of use.



Maintenance and service tasks may only be performed by HSM customer service and service engineers of our dealers.

Operating controls for your safety

Emergency stop button



In the event of danger, press the emergency stop button immediately.

This switches off the shredder, and stops the cutting block and feed belt.

Main switch (only Solo-version)



In the event of danger, turn the main switch to "0".

You can secure the main switch in this position with a padlock to prevent restarting.

Obsah je uzamčen

Dokončete, prosím, proces objednávky.

Následně budete mít přístup k celému dokumentu.



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

**) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!