

HR-150TEC

HR-200TEC

User's Guide

Bedienungsanleitung

Mode d'emploi

Guía del usuario

Guida dell'utilizzatore

Instruktionshäfte

Gebruiksaanwijzing

Bruksanvisning

Käyttäjän opas

Brugsvejledning


Guia do Usuário

Инструкция по эксплуатации

Felhasználói Útmutató

Návod k použití

Instrukcja Obsługi



CASIO®

CASIO COMPUTER CO., LTD.

6-2, Hon-machi 1-chome
Shibuya-ku, Tokyo 151-8543, Japan

GUIDELINES LAID DOWN BY FCC RULES FOR USE OF THE UNIT IN THE U.S.A. (not applicable to other areas).

NOTICE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Changes or modification to the product not expressly approved by CASIO could void the user's authority to operate the product.

(NL)

Batterij niet weggooien,
maar inleveren als
KCA



CASIO Europe GmbH
Bornbarch 10, 22848 Norderstedt, Germany

English

INDEX

| | | | |
|---|----|--|----|
| NOTICE | 1 | ■ About the Selectors | 21 |
| ■ Handling the Calculator | 1 | ■ Addition and Subtraction | 29 |
| ■ Battery Operation | 1 | ■ IT Function | 30 |
| ■ AC Operation | 1 | ■ Multiplication and Division | 36 |
| ■ About the Input Buffer | 1 | ■ ADD Mode Calculations | 38 |
| SETTINGS | 16 | ■ Independent Memory | 39 |
| ■ To Load Batteries | 16 | ■ Percentages | 41 |
| ■ AC Operation | 17 | ■ Cost, Selling Price, and Margin Calculations | 44 |
| ■ Replacing the Ink Roller (IR-40T) | 17 | ■ Making Corrections | 47 |
| ■ Loading the Paper Roll | 18 | ■ Printing Reference Numbers | 48 |
| GENERAL GUIDE | 19 | ■ Errors | 48 |
| ■ RESET Button | 19 | ■ Specifications | 51 |

- Be sure to keep all user documentation handy for future reference.

NOTICE

■ Handling the Calculator

- Never try to take the calculator apart.
- When using paper, be sure you install it correctly.
- To clean the calculator, wipe it off with a soft cloth.
- Switch power off after use or if you do not plan to use the calculator. It is best to unplug from the AC outlet if you do not plan to use the calculator for a long time.
- In no event will CASIO and its suppliers be liable to you or any other person for any damages, including any incidental or consequential expenses, lost profits, lost saving or any other damages arising out of use of this product.

■ Battery Operation

Any of the following indicates low battery power. Switch power off and replace batteries for normal operation.

- Dim display
- Printing problems

Important!

Note the following to avoid battery leakage and damage to the unit.

- Never mix batteries of different types.
- Never mix old batteries and new ones.
- Never leave dead batteries in the battery compartment.
- Remove batteries if you do not plan to use the calculator for a long time.
- Do not expose batteries to heat, let them become shorted, or try to take them apart.

* Should batteries leak, clean out the battery compartment immediately. Avoid letting the battery fluid come into direct contact with your skin.

* Keep batteries out of the reach of small children. If swallowed, consult with a physician immediately.

■ AC Operation

Important!

- The adaptor normally becomes warm when it is being used.
- Unplug the adaptor from the AC outlet when you are not using the calculator.
- Make sure calculator power is switched off when connecting or disconnecting the adaptor.
- Using another adaptor besides AD-A60024 can damage your calculator.
- * Damage caused by using any other type of adaptor is not covered by your warranty.

■ About the Input Buffer

The input buffer of this calculator can hold up to 12 key operations (both number entries and function commands), so you can continue key input even while another operation is being processed.

Obsah je uzamčen

**Dokončete, prosím, proces objednávky.
Následně budete mít přístup k celému dokumentu.**



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

**) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!