

- EN • Safety and use instructions
 - DE • Sicherheits- und Bedienungshinweise
 - FR • Consignes de sécurité et d'utilisation
 - NL • Veiligheids- en gebruiksvorschriften
 - IT • Norme di sicurezza e d'uso
 - ES • Instrucciones de seguridad y de uso
 - PT • Instruções de segurança e utilização
 - DA • Sikkerheds- og brugsanvisning
 - NO • Råd om sikkerhet og bruk
 - SV • Säkerhets- och användningsinstruktioner
 - FI • Turvallisuus- ja käyttöohjeet
 - EL • Συμβουλές ασφαλείας και χρήσης
 - TR • Güvenlik ve kullanım talimatları
 - PL • Zalecenia dotyczące bezpieczeństwa i użytkowania
 - CS • Bezpečnostní pokyny pro použití
 - SK • Bezpečnostné odporúčania a použitie
 - SL • Navodila za varno uporabo
 - HU • Biztonsági előírások és használati útmutató
 - HR • Sigurnosne upute
 - RO • Instrucțiuni de siguranță și de utilizare
 - RU • Меры безопасности и правила использования
 - UK • Правила техніки безпеки та рекомендації щодо використання
 - ET • Ohutus- ja kasutusjuhend
 - LT • Saugos ir naudojimo reikalavimai
 - LV • Norādījumi par drošību un lietošanu
 - BG • Препоръки за безопасност и употреба
 - TH • คู่มือการใช้งานเพื่อความปลอดภัย
 - SR • Uputstvo za bezbednu upotrebu
 - BS • Uputstvo za sigurnu upotrebu
- AR • إرشادات السلامة والإستعمال
- ZH • 安全及使用說明

- P
p
o
c
re
- N
A
-
-
-
- T
h
re
s
s
- T
(i
s
a
re
a
p
- C
w
- T

EN

Important recommendations

Safety instructions

- Please read these instructions carefully before first use. This product has been designed for domestic and indoor use only. Any commercial use, inappropriate use or failure to comply with the instructions, the manufacturer accepts no responsibility and the guarantee will not apply.
- Never unplug the appliance by pulling the power cord. Always unplug your appliance:
 - before filling the water tank or rinsing the boiler,
 - before cleaning the appliance,
 - after each use.
- The appliance will not work without the limescale collector (depending on model).
- The appliance must be used and placed on a flat, stable, heat-resistant surface. When you place the iron on the iron rest, make sure that the surface on which you place it is stable.
- This appliance is not intended to be used by persons (including children) with reduced or impaired physical, sensory or mental capabilities or persons lacking appropriate knowledge or experience, unless a person responsible for their safety provides either supervision or appropriate instructions concerning use of the appliance prior to its use.
- Children should be supervised to ensure they do not play with the appliance.
- This appliance may be used by children aged 8 or over and

Obsah je uzamčen

Dokončete, prosím, proces objednávky.

Následně budete mít přístup k celému dokumentu.



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

**) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!