

# REMINGTON®

## PRO-Air Light 2200W



AC6120


Thank you for buying your new Remington® product. Please read these instructions carefully and keep them safe.

Remove all packaging before use.

---

## IMPORTANT SAFEGUARDS

---

- 1 This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been supervised/instructed and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be done by children unless they are older than 8 and supervised. Keep the appliance and cable out of reach of children under 8 years.
- 2 Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by Remington.
- 3 Never operate this appliance with a damaged power cord or plug, or if it is not working properly.
- 4 Do not wrap the cord around the unit. Check the cord regularly for any sign damage.
- 5 If the supply cord of this unit becomes damaged, discontinue use immediately and return the appliance to your nearest authorised Remington® service dealer for repair or replacement in order to avoid a hazard.
- 6 Warning: Do not use this appliance near bathtubs, showers, basins or other vessels containing water. 
- 7 When the hairdryer is used in a bathroom, unplug it after use since the proximity of water presents a hazard even when the hairdryer is switched off.
- 8 Warning – for additional protection the installation of a residual current device (RCD) with a rated residual operating current not exceeding 30mA is advisable in the electrical circuit supplying the bathroom. Ask an electrician for advice.
- 9 \*For UK household use Only. Currently the fitting in a bathroom of an electrical socket suitable or capable of operating the dryer/straightener is not permitted (see BS7671).
- 10 Do not plug or unplug the appliance with wet hands.
- 11 Do not use if the cord is damaged.
- 12 Do not allow any part of the appliance touch the face, neck or scalp.
- 13 Keep direct airflow away from eyes or other sensitive areas.
- 14 Ensure the inlet grille is free from obstructions such as fluff, loose hair etc.
- 15 Do not leave the appliance unattended while plugged in.

- 16 Do not set the appliance down while still on.
- 17 Do not place the appliance on any soft furnishings.
- 18 Do not use attachments other than those we supply.
- 19 Do not use diffuser on the highest heat setting.
- 20 This appliance is not intended for commercial or salon use.
- 21 Let the attachments cool before removing.



## KEY FEATURES

- 1 3 heat settings
- 2 2 speed settings
- 3 Cold shot
- 4 Concentrator
- 5 Diffuser
- 6 Removable easy clean rear grille
- 7 Hang up loop
- 8 Cord

# Obsah je uzamčen

**Dokončete, prosím, proces objednávky.**

**Následně budete mít přístup k celému dokumentu.**



**Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:**

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne\*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

*\*) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!