

★★★ TRISTAR

AT-5451



EN | Instruction manual

NL | Gebruiksaanwijzing

FR | Mode d'emploi

DE | Bedienungsanleitung

ES | Manual de usuario

PT | Manual de utilizador

IT | Manuele utente

SV | Bruksanvisning

PL | Instrukcja obsługi

CS | Návod na použití

SK | Návod na použitie




service
.tristar.eu



You can find all information and spare parts at service.tristar.eu

SAFETY

Read and save these instructions

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised.
- Keep the appliance and its cord out of reach of children less than 8 years.
- Never insert fingers, pencils or any other object through the holes of the plastic shell.
- To prevent risk of fire and electric shock. Do not use the unit near windows.
- Power plug must be removed from power socket before cleaning, serving, maintenance and move from one location to another.
- The fan should be placed on a flat and stable surface when operating to avoid overturning.
- Do not put on the product in wet place. For example, bathroom etc.
- Don't use it in the cook-room in order that keeping the plastic part away from greasy dirt.
- If the power cord is damaged, it must be replaced by the manufacturer or its service agent or similar qualified person in order to avoid a hazard.

- Keep electrical appliances out of reach from children or confirm persons, Do not let them use the appliances without supervision.
- This appliance is not adapt for use by persons (children) with reached physical sensory or mental capabilities, or lack of experience and know ledge unless they have been given supervision concerning use of the appliance by a person responsible for their safety .
- Children should be supervised to ensure that they do not play with the appliance.

SPECIFICATIONS:

- Rated Voltage: 220-240V~
- Rated Frequency: 50Hz
- Input Power: 55W

Obsah je uzamčen

Dokončete, prosím, proces objednávky.

Následně budete mít přístup k celému dokumentu.



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

**) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!