

REMINGTON®

7 in 1 Cordless Epilator





EP7035

Thank you for buying your new Remington product. Before use, please read these instructions carefully and keep them safe.
Remove all packaging before use.

IMPORTANT SAFETY INSTRUCTIONS

WARNING - TO REDUCE THE RISK OF BURNS, ELECTROCUTION, FIRE OR INJURY TO PERSONS:

- 1 This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been supervised/instructed and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be done by children unless they are older than 8 and supervised. Keep the appliance and cable out of reach of children under 8 years.
- 2 This appliance should never be left unattended when plugged into a power outlet, except when charging.
- 3 Only set the appliance down on a heat-proof surface.
- 4 Do not use the appliance if it is damaged or malfunctions.
- 5 If the supply cord of this unit becomes damaged, discontinue use immediately and return the appliance to your nearest authorised Remington service dealer for repair or replacement in order to avoid a hazard.
- 6 Do not use attachments other than those we supply.
- 7 Do not twist or kink the cable, or wrap it around the appliance.
- 8 This product is for cordless use only. Do not use your epilator while it is plugged into the mains.
- 9 Make sure the power plug and cord do not get wet.
- 10 Do not plug or unplug the appliance with wet hands.
- 11 Suitable for use in a bath or shower. 
- 12 Ensure the appliance is switched off and unplugged from the mains before cleaning.
- 13 Do not use this appliance with a damaged or broken tweezer barrel as injury may occur.
- 14 This appliance is not intended for commercial or salon use.
- 15  This appliance should be supplied with approved safety isolating adaptors PA-0510EU (for Europe) and PA-0510U (for United Kingdom) with the output capacity of 5DC; 1000mA (adaptor output).



KEY FEATURES

- | | |
|----------------------------------------|-------------------------------|
| 1 Tweezers | 11 Detail Cap |
| 2 Perfect Angle Cap | 12 Massage Cap with Aloe Vera |
| 3 Removable & Washable Head | 13 Bikini Comb |
| 4 Pivoting Head | 14 Shaver Head |
| 5 Precision Light | 15 Pedicure Head |
| 6 On/Off Switch - 2 Speeds | 16 Exfoliating Brush Head |
| 7 Low Battery/Charging Indicator Light | 17 Cleaning Brush (not shown) |
| 8 Power Inlet | 18 Beauty Bag (not shown) |
| 9 Head Release Button | 19 Power Adaptor (not shown) |
| 10 Anti Slip Grip | |

Obsah je uzamčen

Dokončete, prosím, proces objednávky.

Následně budete mít přístup k celému dokumentu.



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

**) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!