
V69	165\\\\\/10	V6516	ED\/10
700	165WV10	, 70010	30 4 10
X68	165MV10), X6816	5BV10
AWS	S8445AB	, AWS84	45AW
X08	155BV-X	, DVB38	50B
	2050///	D1/D20E	\cap N/I

ΕN	USER MANUAL	2	UK	ІНСТРУКЦІЯ З ЕКСПЛУАТАЦІЇ	68
DE	GEBRAUCHSANLEITUNG	6	HU	HASZNÁLATI ÚTMUTATÓ	73
FR	MANUEL D'UTILISATION	11	CS	NÁVOD K POUŽITÍ	77
NL	GEBRUIKSAANWIJZING	16	SK	NÁVOD NA POUŽÍVANIE	81
	MANUAL DE USO	21	RO	MANUAL DE FOLOSIRE	85
PΤ	LIVRO DE INSTRUÇÕES PARA		PL	INSTRUKCJA UŻYTKOWANIA	89
	UTILIZAÇÃO.	26	HR	KNJIŽICA S UPUTAMA	94
	LIBRETTO DI USO	31	SL	NAVODILO ZA UPORABO	98
S۷	ANVÄNDNINGSHANDBOK	35	EL	ΟΔΗΓΊΕΣ ΧΡΉΣΗΣ	102
NO	BRUKSVEILEDNING	39	TR	KULLANIM KITAPÇIĞI	107
FI	KÄYTTÖOHJEET	43	BG	РЪКОВОДСТВО	
DA	BRUGSVEJLEDNING	47		НА ПОТРЕБИТЕЛЯ	112
RU	РУКОВОДСТВО ПО ЭКСПЛУАТАЦ	ΙИИ		ПАЙДАЛАНУШЫ НҰСҚАУЛЫҒЫ	117
		51		УПАТСТВО ЗА КОРИСНИК	122
	KASUTUSJUHEND	56	SQ	UDHËZUES PËR PËRDORIMIN	127
	LIETOŠANAS PAMĀCĪBA	60	SR	корисничко упутство	131
LT	NAUDOTOJO VADOVAS	64	139	كتبيب الاستعمال	AR
			. 00		

USER MANUAL





FOR PERFECT RESULTS

Thank you for choosing this AEG product. We have created it to give you impeccable performance for many years, with innovative technologies that help make life simpler – features you might not find on ordinary appliances. Please spend a few minutes reading to get the very best from it.

Visit our website to:



Get usage advice, brochures, trouble shooter, service information: www.aeq.com



Register your product for better service: www.aeg.com/productregistration



Buy Accessories, Consumables and Original spare parts for your appliance: www.aeg.com/shop

ENVIRONMENT CONCERNS

Recycle the materials with the symbol $\overset{\checkmark}{\hookrightarrow}$. Put the packaging in applicable containers to recycle it. Help protect the environment and human health and to recycle waste of electrical and electronic appliances. Do not dispose appliances marked with the symbol $\overset{\checkmark}{\Longrightarrow}$ with the household waste. Return the product to your local recycling facility or contact your municipal office department for household waste or the shop where you purchased this product.

CUSTOMER CARE AND SERVICE

We recommend the use of original spare parts.

When contacting Service, ensure that you have the following data available.

The information can be found on the rating plate. Model, PNC, Serial Number.

Warning / Caution-Safety information.

i General information and tips

Environmental information.

Subject to change without notice.

1. SAFETY INSTRUCTIONS

Caution! Closely follow the instructions set out in this manual. All responsibility, for any eventual inconveniences, damages or fires caused by not complying with the instructions in this manual, is declined. The extractor hood has been designed exclusively for domestic use.

Caution!Do not connect the appliance to the mains until the installation is fully complete. Before any cleaning or maintenance operation, disconnect hood from the mains by removing the plug or disconnecting the mains electrical supply.

Always wear work gloves during the maintenance, installation and lighting operations. The appliance is not intended for use by children or persons with impaired physical, sensorial or mental faculties. or if lacking in experience or knowledge, unless they are under supervision or have been trained in the use of the appliance by a person responsible for their safety. This appliance is designed to be operated by adults, children should be monitored to ensure that they do not play with the appliance. This appliance is designed to be operated by adults. Children should not be allowed to tamper with the controls or play with the appliance. Never use the hood without effectively mounted grating! The hood must NEVER be used as a support surface unless specifically indicated. The premises where the appliance is nstalled must be sufficiently ventilated, when the kitchen hood is used together with other gas combustion devices or other fuels. The ducting system for this appliance must not be connected to any existing ventilation system which is being used for any other purpose such as discharging exhaust fumes from appliances burning gas or other fuels. The flaming of foods beneath the hood itself is severely prohibited. The use of exposed flames is detrimental to the filters and may cause a fire risk, and must therefore be avoided in all circumstances. Any frying must be done with care in order to make sure that the oil does not overheat and ignite.

Caution! Accessible parts of the hood may became hot when used with cooking appliance.

With regards to the technical and safety measures to be adopted for fume discharging it is important to closely follow the regulations provided by the local authorities. The hood must be regularly cleaned on both the inside and outside (AT LEAST ONCE A MONTH).

This must be completed in accordance with the maintenance instructions provided in this manual). Failure to follow the instructions provided in this user guide regarding the cleaning of the hood and filters will lead to the risk of fires. Do not use or leave the hood without the lamp correctly mounted due to the possible risk of electric shocks. We will not accept any responsibility for any faults, damage or fires caused to the appliance as a result of the non-observance of the instructions included in this manual.

Warning!Failure to install the screws or fixing device in accordance with these instructions may result in electrical hazards

2.USE

The hood serves to aspirate the fumes and vapors resulting from cooking.

The attached installation manual indicates the version to be used depending on the model you have, the suction version with

external evacuation or filtering with internal recirculation.

3.INSTALLATION

The mains power supply must correspond to the rating indicated on the plate situated inside the hood. If provided with a plug connect the hood to a socket in compliance with current regulations and positioned in an accessible area, after installation. If it not fitted with a plug (direct mains connection) or if the plug is not located in an accessible area, after installation, apply a double pole switch in accordance with standards which assures the complete disconnection of the mains under conditions relating to over-current category III in accordance with installation instructions.

Warning!Before re-connecting the hood circuit to the mains supply and checking the efficient function, always check that the mains cable is correctly assembled.

Obsah je uzamčen

Dokončete, prosím, proces objednávky.
Následně budete mít přístup k celému dokumentu.



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.
 - *) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.
- 2) Pak jsou tady "roboti", kteří se přiživují na naší práci a "vysávají" výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!