

Panasonic

Operating Instructions (Household) Epilator

Model No. ES-DEL8A
ES-EL8A
ES-EL3A
ES-EL2A

Contents

Safety precautions	10
Intended use	14
Quick steps for using.....	15
Parts identification	15
Charging.....	16
Before use	16
How to use	17
Cleaning	19
Replacing the outer foil and the inner blade.....	20
Replacing the file.....	20
Troubleshooting	21
Battery life	23
Removing the built-in rechargeable battery	23
Guarantee.....	23
Specifications	23

Thank you for purchasing this Panasonic product.

Before operating this unit, please read these instructions completely and save them for future use.



Warning

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- The supply cord cannot be replaced. If the cord is damaged, the AC adaptor should be scrapped.
- Do not use anything other than the supplied AC adaptor for any purpose. Also, do not use any other product with the supplied AC adaptor. (See page 15.)

- The following symbol indicates that a specific detachable power supply unit is required for connecting the electrical appliance to the supply mains. The type reference of power supply unit is marked near the symbol.



► **Using the head of epilation/shaver**

- These heads can be used for wet. The following symbol means suitable for use in a bath or shower.



► **Using the foot care head**

- The foot care head is washable. The following symbol means that the foot care head can be cleaned under the water.



- Detach the main body from the AC adaptor before cleaning it in water.

GB
D
F
I
NL
E
DK
P
N
S
FIN
PL
CZ
SK
H
RO
TR

Obsah je uzamčen

Dokončete, prosím, proces objednávky.

Následně budete mít přístup k celému dokumentu.



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

**) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!