

EXD16DN4W
EXD20DN4W



EN	Dehumidifier	User Manual	2
BG	Обезвлажнител	Ръководство за потребителя	14
HR	Odvlaživač	Korisnički priručnik	29
CZ	Odvlhčovač	Návod k použití	42
DA	Affugter	Brugsanvisning	55
NL	Ontvochtiger	Gebruiksaanwijzing	68
FI	Kosteudenpoistaja	Käyttöohje	81
FR	Déshumidificateur	Manuel d'utilisation	94
EL	Αφυγρανήρας	Εγχειρίδιο χρήστη	108
HU	Páramentesítő	Felhasználói kézikönyv	123
IT	Deumidificatore	Libretto istruzioni	137
NO	Dehumidifier	User Manual	151
PL	Osuszacz	Instrukcja obsługi	163
RO	Dezumidicator	Manualul utilizatorului	177
SL	Razvlaževalnik	Navodila za uporabo	190
SV	Avfuktare	Bruksanvisning	203



Electrolux

CONTENTS

1. SAFETY INFORMATION.....	3
2. SAFETY INSTRUCTIONS	6
3. BEFORE FIRST USE	7
4. OPERATING INSTRUCTION	8
5. CARE AND CLEANING	10
6. WHAT TO DO IF.....	11
7. ENVIRONMENT CONCERNS.....	13

WE'RE THINKING OF YOU

Thank you for purchasing an Electrolux appliance. You've chosen a product that brings with it decades of professional experience and innovation. Ingenious and stylish, it has been designed with you in mind. So whenever you use it, you can be safe in the knowledge that you'll get great results every time.

Welcome to Electrolux.

Visit our website to:



Get usage advice, brochures, trouble shooter, service information:
www.electrolux.com



Register your product for better service:
www.registerelectrolux.com



Buy Accessories, Consumables and Original spare parts for your appliance:
www.electrolux.com/shop

CUSTOMER CARE AND SERVICE

Always use original spare parts.

When contacting our Authorised Service Centre, ensure that you have the following data available: Model, PNC, Serial Number.

The information can be found on the rating plate.

 Warning / Caution-Safety information.

 General information and tips.

 Environmental information.

Subject to change without notice.

1. ⚠️ SAFETY INFORMATION


This USER MANUAL provides specific operating instructions for your model. Use the dehumidifier only as instructed in this USER MANUAL. These instructions are not meant to cover every possible condition and situation that may occur. Common sense and caution must be practiced when installing, operating, and maintaining any appliance.



WARNING!

Avoid fire hazard or electric shock. Do not use an extension cord or an adaptor plug. Do not remove any prong from the power cord.

- Do not, under any circumstances, cut, remove or bypass the grounding prong.



- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance. Read product labels for flammability and other warnings.
- Discard water from bucket. Water is not potable and cannot be used for drinking.

1.1 Children and Vulnerable People Safety



WARNING!

Risk of suffocation, injury or permanent disability.

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of

Obsah je uzamčen

Dokončete, prosím, proces objednávky.

Následně budete mít přístup k celému dokumentu.



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

**) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!