

ZY0801T	ZY1428T	ZY0814T	ZY1511T	ZY1610T
ZY1701T	ZY0817T	ZY0805T	ZY0901T	ZY1604T
ZY0811T	ZY1433T	ZY1705T	ZY0902T	ZY1605T
ZY1431T	ZY0803T	ZY0815T	ZY0911T	ZY1612T
ZY0802T	ZY1703T	ZY0806T	ZY0903T	ZY1446T
ZY1702T	ZY0813T	ZY1429T	ZY1601T	ZY1447T
ZY0812T	ZY1434T	ZY0816T	ZY0912T	ZY1449T
ZY1432T	ZY0804T	ZY1501T	ZY1602T	
ZY0807T	ZY1704T	ZY1430T	ZY1603T	

GB	Christmas LED Lights + Timer
CZ	Vánoční LED osvětlení + Časovač
SK	Vianočné LED osvetlenie + Časovač
PL	Oświetlenie choinkowe LED + Timer
HU	Karácsonyi LED fényfüzér + Időzítő
SI	LED božična okrasna razsvetljava + Programska ura
RS HR BA	Novogodišnje LED osvjetljenje + Tajmer
DE	LED-Weihnachtsbeleuchtung + Timer
UA	Різдв'яне світлодіодне освітлення + Таймер
RO	Iluminație de crăciun cu LED + Temporizator
LT	Kalėdinė šviesos diodų girlianda + Laikmatis
LV	Ziemassvētku LED apgaismojums + Taimeris



**Type / Typ / Typ / Typ / Típus / Nasvet / Tip / Typ / тип / Tip
/ Tipas / Tips**

LED-40 4M CW IP44 T	LED-40 4M WW IP44 T
LED-40 4M AC IP44 T	LED-80 8M CW IP44 T
LED-80 8M MC IP44 T	LED-80 8M AC IP44 T
LED-100 10M WW IP44 T	LED-100 10M MC IP44 T
LED-120 12M CW IP44 T	LED-120 12M WW IP44 T
LED-120 12M AC IP44 T	LED-180 18M CW IP44 T
LED-180 18M MC IP44 T	LED-240 24M CW IP44 T
LED-240 24M MC IP44 T	LED-500 50M CW IP44 T
LED-500 50M MC IP44 T	LED-768- CW T
LED-768-MC T	LED-80 CH 8M CW IP44 T
LED-80 CH 8M MC IP44 T	LED-200CH 20MCW IP44 T
LED-200CH 20MMC IP44 T	LED-300A(B043)-W T
LED-300A(B043)-M T	LED-480(B043)-W T
LED-480(B043)-M T	LED-160 NET IP44 T
LED-200 NET IP44 WW T	LED-500 50M WW IP44 T
LED-40 4M MC IP44 T	LED-768 76M WW IP44 T
LED-80 8M WW IP44 T	LED-80 CH 8M WW IP44 T
LED-100 10M CW IP44 T	LED-200(B043)-WW T
LED-100 10M IP44 T	LED-300A(B043)-WW T
LED-120 12M MC IP44 T	LED-480(B043)-WW T
LED-180 18M WW IP44 T	LED-180 NET IP44 T
LED-240 24M WW IP44 T	

GB Christmas LED Lights + Timer

Do not use in packaging.

Do not connect another Christmas light.

When handling, disconnect from the power network.

In case of malfunction, do not remove bulbs and do not repair the chain!

LED bulbs are non-replacable.

Do not interfere with the connection.

Use only with the power source supplied with the product.

Timer (T)

The light chain has a built-in timer on the body of the transformer (adapter).

After the first connection, the chain will be constantly lit. After the second connection (a green light will light up), the timer will be set to 6 hours. Afterwards, it turns off automatically and will remain off for 18 hours. The timer will operate automatically in these intervals (6 hours on/18 hours off) until turned off by making a third contact.

Example:

The chain will turn on on 1 December at 18 o'clock. It will remain lit until midnight, then turns off automatically. On 2 December, it will turn on automatically at 18 o'clock and turn off again at midnight. That means that the chain only has to be turned on once, and it will automatically keep lighting in this fashion until you turn it off or after approximately 35 days based on the quality of the batteries and ambient temperature.

Changing the timer settings

If you wish to change the time when the chain automatically turns on and off (e.g. 19 o'clock until 1 o'clock), all you need to do is turn off the chain at the desired time (if it is turned on) and then turn it on again.

Note:

The timer may deviate by a few minutes per month. If you want to adjust the turn-on timer back to the original time, set the timer again.



13.8.2005

Do not dispose with domestic waste. Use special collection points for sorted waste. Contact local authorities for information about collection points. If the electronic devices would be disposed on landfil II, dangerous substances may reach groundwater and subsequently food chain, where it could affect human health.

CZ Vánoční LED osvětlení + Časovač

Nepoužívejte v nerozbaleném stavu.

Nenapojujte další vánoční svítidlo.

Při manipulaci odpojte z elektrické sítě.

V případě poruchy nevytahujte žárovky a řetěz neopravujte!

LED žárovky nejsou vyměnitelné.

Nezasahujte do zapojení.

Používejte jen se zdrojem dodaným k výrobku.

Časovač (T)

Tento světelný řetěz má na těle transformátoru (adaptéru) zabudovaný časovač.

Po prvním sepnutí bude řetěz svítit stále. Po druhém sepnutí (rozsvítí se zelené světlo) se nastaví časovač na dobu 6 hodin. Poté se automaticky vypne a bude po dobu 18 hodin vypnutý. V těchto intervalech (6 hodin zapnuto/18 hodin vypnuto) bude automaticky pracovat do té doby, dokud ho třetím sepnutím nevypnete.

Obsah je uzamčen

**Dokončete, prosím, proces objednávky.
Následně budete mít přístup k celému dokumentu.**



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

**) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!