


LFG719X  
LFG716X  
DBGL1031CN  
DBGL5431CN  
DBGL7731CN



**EN** User manual  
**DE** Gebrauchsanleitung  
**FR** Manuel d'utilisation  
**NL** Gebruiksaanwijzing  
**ES** Manual de uso  
**PT** Livro de instruções  
para utilização  
**IT** Libretto di uso  
**SV** Användningshandbok  
**NO** Bruksveiledning  
**FI** Käyttöohjeet  
**DA** Brugsvejledning

**RU** Руководство по  
Эксплуатации  
**ET** Kasutusjuhend  
**LV** Lietošanas pamācība  
**LT** Naudotojo vadovas  
**UK** Інструкція з експлуатації  
**HU** Használati útmutató  
**CS** Návod k použití  
**SK** Návod na používanie  
**RO** Manual de folosire  
**PL** Instrukcja użytkowania  
**HR** Knjižica s uputama

**SL** Navodilo za uporabo  
**EL** Οδηγίες χρήσης  
**TR** Kullanım kılavuzi  
**BG** Ръководство на  
Потребителя  
**KK** ПайдаланушыНұсқаулығы  
**MK** Упатство за корисник  
**SQ** Udhëzues për përdorimin  
**SR** Корисничко упутство  
دليل المستخدم **AR**



**Electrolux**

# CONTENTS

|                              |   |
|------------------------------|---|
| 1. SAFETY INFORMATION.....   | 2 |
| 2. SAFETY INSTRUCTIONS.....  | 4 |
| 3. MAINTENANCE.....          | 5 |
| 4. CONTROLS.....             | 6 |
| 5. INSTALLATION METHODS..... | 6 |
| 6. LIGHTING.....             | 6 |
| 7. ENVIRONMENT CONCERNS..... | 6 |

## WE'RE THINKING OF YOU

Thank you for purchasing an Electrolux appliance. You've chosen a product that brings with it decades of professional experience and innovation. Ingenious and stylish, it has been designed with you in mind. So whenever you use it, you can be safe in the knowledge that you'll get great results every time.

Welcome to Electrolux.

### Visit our website to:



Get usage advice, brochures, trouble shooter, service information:  
**[www.electrolux.com](http://www.electrolux.com)**



Register your product for better service:  
**[www.registerelectrolux.com](http://www.registerelectrolux.com)**



Buy Accessories, Consumables and Original spare parts for your appliance:  
**[www.electrolux.com/shop](http://www.electrolux.com/shop)**

## CUSTOMER CARE AND SERVICE

Always use original spare parts.

When contacting our Authorised Service Centre, ensure that you have the following data available: Model, PNC, Serial Number.

The information can be found on the rating plate.

 Warning / Caution-Safety information

 General information and tips

 Environmental information

Subject to change without notice.

### 1. SAFETY INFORMATION

Before the installation and use of the appliance, carefully read the supplied instructions. The manufacturer is not responsible for any injuries or damages that are the result of incorrect installation or usage. Always keep the instructions in a safe and accessible location for future reference.

#### 1.1 Children and vulnerable people safety

- This appliance can be used by children aged from 8 years and

above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved.

- Children between 3 and 8 years of age and persons with very extensive and complex disabilities shall be kept away unless continuously supervised.
- Children of less than 3 years of age should be kept away unless continuously supervised.
- Do not let children play with the appliance.
- Keep all packaging away from children and dispose of it appropriately.
- Keep children and pets away from the appliance when it operates.
- Children shall not carry out cleaning and user maintenance of the appliance without supervision.

## 1.2 General Safety

- This appliance is intended for domestic use above hobs, cookers and similar cooking devices.
- Before carrying out any maintenance, disconnect the appliance from the power supply.
- CAUTION: Accessible parts may become hot during use with cooking appliances.
- Use only the fixing screws supplied with the appliance if not supplied, use the screws recommended in the installation instructions.
- Do not use adhesives to fix the appliance.
- The minimum distance between the hob surface on which the pans stand and the lower part of the gas appliance shall be at least 65 cm, unless otherwise specified in the installation instructions. If the hob installation instructions specify a greater distance, it must be taken into account.
- The discharge of air must comply with local authorities regulations.
- Ensure good air ventilation in the room where the appliance is installed to avoid the backflow of unwanted gases into the room from appliances burning gas or other fuels, including open fires.
- Make sure that the ventilation openings are not blocked and the air collected by the appliance is not conveyed into a duct used to

# Obsah je uzamčen

**Dokončete, prosím, proces objednávky.**

**Následně budete mít přístup k celému dokumentu.**



**Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:**

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne\*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

*\*) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!