



# **Smartwatch for sports and outdoors**

CNS-SB41

## **Quick Guide v 1.0**

## Smartwatch for sports and outdoors

- 0,96 inches LCD screen
- IP68 waterproof
- Multi-sport mode
- Weather display
- Compatibility with iOS and Android OS

## Complete set


- Smartwatch
- Battery (build-in)
- Charging kit
- User manual

## Usage

Make sure that your smartwatch is fully charged before usage.

*Charging:* the charging device is similar to a clothespin. Put the watch body into it, in the way that 3 electrodes would match. Gently pinch the "clothespin" on the watch body. If the electrodes match, the pin has to fasten. If not, change position of the watch. After that, stick the USB plug into the USB port of your computer, a wall socket adapter or

a power bank. Charging progress will be indicated on the screen. For better charging compatibility, it is advisable to use a Power Bank produced by Canyon.




*Charger requirements: 5V.*

*Charging time: 2-5 hours depending on a source of charge.*

*Turning on:* press and hold the sensor button marked as a circle on the front side of the watch body. Keep on holding it for at least 3 seconds.

*Turning off:* Press the round sensor button on the front side of your watch body to activate the screen, then tap it several more times to see a menu item "More".



# Obsah je uzamčen

**Dokončete, prosím, proces objednávky.**

**Následně budete mít přístup k celému dokumentu.**



**Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:**

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne\*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

*\*) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!