

ROVUS®



USER MANUAL


Please read this manual thoroughly before using and save it for future reference.

CERAMIC HEATER
MODEL NO.: KPT-150 0586L

EN.....	3	LV.....	39
AL.....	6	MD.....	41
BG.....	9	ME.....	44
BIH.....	13	MK.....	47
CZ.....	17	PL.....	51
EE.....	20	RO.....	54
HR.....	23	RS.....	57
HU.....	27	RU.....	60
KS.....	30	SI.....	64
KZ.....	33	SK.....	67
LT.....	36	UA.....	70

(EN) PICTURES / (AL) FOTOGRAFIN / (BG) ИЛЮСТРАЦИИ / (BIH) SLIKE / (CZ) OBRÁZKY / (EE) JOONISED / (HR) SLIKE / (HU) KÉPEK / (KS) FOTOGRAFIN / (KZ) СУРЕТТЕР / (LT) PAVEIKSLIUOKAI / (LV) ATTĒLI / (MD) IMAGINI / (ME) SLIKE / (MK) СЛИКИ / (PL) RYSUNKI / (RO) IMAGINI / (RS) SLIKE / (RU) RYSUNKI / (SI) SLIKE / (SK) OBRÁZKY / (UA) МАЛЮНКИ

Picture 1



WARNINGS:

1. Children of less than 3 years should be kept away unless continuously supervised.
2. Children aged from 3 years and less than 8 years shall only switch ON/OFF the appliance provided that it has been placed or installed in its intended normal operating position and they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children aged from 3 years and less than 8 years shall not plug in, regulate and clean the appliance or perform user maintenance.
3. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
4. Children shall not play with the appliance.
5. This device is only suitable for well insulated spaces or occasional use.
6. This device is intended for household, indoor and dry use only.
7. CAUTION: Some parts of this product can become very hot and cause burns. Particular attention has to be given where children and vulnerable people are present.
8. In order to avoid overheating, do not cover the heater.
9. The heater must not be located immediately below a power supply socket.
10. Do not use this heater in the immediate surroundings of a bath, a shower or a swimming pool.
11. This heater is not equipped with a device to control the room temperature. Do not use this heater in small rooms when they are occupied by persons not capable of leaving the room on their own, unless constant supervision is provided.
12. Before use, place the product on hard, flat, stable and dry surface.
13. Slight odors are possible at beginning of usage until device reaches its thermal stability.
14. If the device is not working as it should, has received a sharp blow, has been dropped, damaged, left outdoors or dropped into water, do not use it.
15. This device should never be switched on or stay plugged in power supply when not in use, while replacing accessories or during cleaning.
16. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard. Do not use the device if there are visible signs of damage to it or if it malfunctions in any way.
17. Do not use the device in places where it might be exposed to vibration or where it might topple. Do not use it on soft surfaces, such as a beds or high-pile carpets, where openings may become blocked or the tip-over switch cannot be activated.
18. Reduce the risk of fire, keep textiles, curtains, or any other flammable material at a minimum distance of 1m from the device.
19. Always turn the device off before disconnecting the power plug.
20. Never leave the device unattended during use.
21. Avoid the use of extension cords or multi-socket outlets as they may overheat and cause a risk of fire. If their use is unavoidable, they must have an appropriate power rating. Under no circumstances should other high-current appliances be plugged into the same circuit with the appliance since an overload can occur.
22. Ensure the rated voltage shown on the rating label corresponds with the voltage of the power

Obsah je uzamčen

Dokončete, prosím, proces objednávky.

Následně budete mít přístup k celému dokumentu.



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

**) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!