

ROVUS®



USER MANUAL


Please read this manual thoroughly before using and save it for future reference.

TOWER CERAMIC HEATER

MODEL NO.: KPT-2000 5155L

EN.....	3	LV.....	46
AL.....	6	MD.....	49
BG.....	10	ME.....	53
BIH.....	15	MK.....	56
CZ.....	20	PL.....	61
EE.....	23	RO.....	65
HR.....	27	RS.....	69
HU.....	32	RU.....	72
KS.....	35	SI.....	77
KZ.....	39	SK.....	81
LT.....	42	UA.....	84

(EN) PICTURES / (AL) FOTOGRAFIN / (BG) ИЛЮСТРАЦИИ / (BIH) SLIKE / (CZ) OBRÁZKY / (EE) JOONISED / (HR) SLIKE / (HU) KÉPEK / (KS) FOTOGRAFIN / (KZ) СУПЕТТЕР / (LT) PAVEIKSLIAUKAI / (LV) ATTĒLI / (MD) IMAGINI / (ME) SLIKE / (MK) СЛИКИ / (PL) RYSUNKI / (RO) IMAGINI / (RS) SLIKE / (RU) RYSUNKI / (SI) SLIKE / (SK) OBRÁZKY / (UA) МАЛЮНКИ



WARNINGS:

1. Children of less than 3 years should be kept away unless continuously supervised.
2. Children aged from 3 years and less than 8 years shall only switch ON/OFF the appliance provided that it has been placed or installed in its intended normal operating position and they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children aged from 3 years and less than 8 years shall not plug in, regulate and clean the appliance or perform user maintenance.
3. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
4. Children shall not play with the appliance.
5. This device is only suitable for well insulated spaces or occasional use.
6. This device is intended for household, indoor and dry use only.
7. **CAUTION:** Some parts of this product can become very hot and cause burns. Particular attention has to be given where children and vulnerable people are present.
8. In order to avoid overheating, do not cover the heater.
9. The heater must not be located immediately below a power supply socket.
10. Do not use this heater in the immediate surroundings of a bath, a shower or a swimming pool.
11. This heater is not equipped with a device to control the room temperature. Do not use this heater in small rooms when they are occupied by persons not capable of leaving the room on their own, unless constant supervision is provided.
12. Before use, place the product on hard, flat, stable and dry surface.
13. Slight odors are possible at beginning of usage until device reaches its thermal stability.
14. If the device is not working as it should, has received a sharp blow, has been dropped, damaged, left outdoors or dropped into water, do not use it.
15. Never leave weak or empty batteries in the device – especially if you suspect it will not be used for several months. Use the correct size and type of battery specified by the manufacturer and installed in accordance with polarity (+ and – terminals) marked on the device. Do not mix old and new batteries, batteries of different brands, or batteries of different types (alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium)) in the same device as this may cause the batteries to leak. Rechargeable batteries must be removed before being recharged. Do not recharge non-rechargeable batteries. Battery replacement and/or recharging should be done only by adults. Always keep all batteries in a safe place away from children and pets. Store new batteries, in their original packaging, in a dry place and at normal room temperature until ready to use and dispose of used batteries in accordance with your local law. Do not store device with batteries in very warm places as this could result in reduced battery performance and/or battery leakage. Battery acid and leakage can cause personal injury and/or damage to the product and/or surrounding property. If battery leakage occurs, thoroughly wash any affected skin, making sure to keep battery acid away from eyes, ears, nose and mouth. Immediately wash any clothing or other surface that came into contact with leaked battery acid.
16. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard. Do not use the device if there are visible

Obsah je uzamčen

**Dokončete, prosím, proces objednávky.
Následně budete mít přístup k celému dokumentu.**



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

**) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!