


# Amazfit Pace User Manual



# Contents

Appearance and Operation Instructions .....	1
Lock Screen and Operation Status .....	1
Gesture Operations on Touch Screen .....	1
System Status Symbol Description .....	1
Quick Setting menu .....	2
Wearing and Charging Methods .....	3
Daily Wearing .....	3
Wearing during Exercise .....	3
Charging .....	3
Activity Features .....	3
Start Activity .....	3
Start running .....	4
Operations during Running .....	4
Alerts during Running .....	5
Pause or Stop Running .....	5
Running Settings .....	5
Running Training .....	6
About GPS Search.....	6
Indoor Running .....	7
Check Activity Records .....	7
Watch Functions.....	8
1) Watch Face .....	8
2) Widgets and Apps .....	8
3) Data Center.....	9
4) Activity Records.....	9
5) Heart Rate.....	10
6) Music .....	11
7) Phone Music Control.....	11
8) Sleep .....	11
9) Watch Notifications.....	12
10) Weather.....	13
11) Alarm .....	13
12) Other Apps.....	13
13) Connect to Phone .....	14
14) Connect to Computer .....	14
15) Copy Files .....	15
16) Upgrade Watch System .....	15
Routine Watch Maintenance .....	15

The following instructions are based on the WOS 2.0. Please upgrade to the latest version.

# Appearance and Operation Instructions



Button	Short press	Unlock the watch
		Return to the watch face
		Lock screen
	Long press for 4 seconds	Turn on the watch
	Long press for 6 seconds	Prompt the restart or turn off page
	Long press for 10 seconds	Turn off the watch

## Lock Screen and Operation Status

The watch will automatically enter the low-power lock screen status after a period of inactivity, and display the Watch Face page. You can unlock the watch by pressing the button shortly. If no operation is applied, the watch will automatically enter the low-power lock screen status again.

## Gesture Operations on Touch Screen

Tap the screen	Use this function, go to the next item or select the current item
Slide left or right on the screen	Switch pages horizontally
Slide up or down on the screen	Scroll a page up or down
Long press on the screen	Long press on the Watch Face page to activate the watch face selection function

## System Status Symbol Description

System status symbols will appear on the unlocked watch face. Each symbol indicates a status of the watch.

# Obsah je uzamčen

**Dokončete, prosím, proces objednávky.**

**Následně budete mít přístup k celému dokumentu.**



**Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:**

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne\*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

*\*) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!