


ROVUS®



USER MANUAL

Please read this manual thoroughly before using and save it for future reference.


NANO FLOOR STEAMER

MODEL NO.: 8901-B3


EN.....	3	LV.....	37
AL.....	6	MD.....	39
BG.....	8	ME.....	42
BIH.....	13	MK.....	44
CZ.....	17	PL.....	48
EE.....	19	RO.....	51
HR.....	22	RS.....	53
HU.....	26	RU.....	56
KS.....	28	SI.....	59
KZ.....	31	SK.....	63
LT.....	34	UA.....	65

(EN) PICTURES / (AL) FOTOGRAFIM / (BG) ИЛЮСТРАЦИИ / (BIH) SLIKE / (CZ) OBRÁZKY / (EE) JOONISED / (HR) SLIKE / (HU) KÉPEK / (KS) FOTOGRAFIM / (KZ) СУПЕТТЕР / (LT) PAVEIKSLIAUKAI / (LV) ATTĒLI / (MD) IMAGINI / (ME) SLIKE / (MK) СЛИКИ / (PL) RYSUNKI / (RO) IMAGINI / (RS) SLIKE / (RU) RYSUNKI / (SI) SLIKE / (SK) OBRÁZKY / (UA) МАЛЮНКИ


Picture 1




Picture 2




Picture 4




Picture 3




Picture 5




Picture 6




Picture 7



Picture 8



Picture 9



EN

Instruction Manual

Please read user manual before use, especially the Warning and Caution

WARNINGS

1. Children aged from 3 years and less than 8 years shall only switch ON/OFF the appliance provided that it has been placed or installed in its intended normal operating position and they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children aged from 3 years and less than 8 years shall not plug in, regulate and clean the appliance or perform user maintenance.
2. This device is intended for household and indoor use only.
3. This device should never operate empty/unloaded, because such action could result in appliance failure and/or injuries to the user.
4. Sparks inside the motor can ignite flammable vapors or dust. Do not use this product near flammable or combustible liquids, gases, explosive dust or any smoke and fire sources.
5. Never use on or near toxic materials as the vapors or dust may cause a health hazard.
6. Do not use the device to clean plaster, cement, etc. that can harden on coming into contact with water and can thus hamper the normal functioning of the machine.
7. This product is not a toy. Close attention is necessary when used by or near children or pets. Never use this product on pets.
8. Children must be supervised not to play with this appliance.
9. Before use, place the product on hard, flat, stable and dry surface.
10. Slight odors are possible at beginning of usage until device reaches its thermal stability.
11. Plug in power supply that corresponds to the rated one on product only.
12. If the supply cord is damaged, it must be replaced immediately by authorized and qualified person only.
13. If the device is not working as it should, has received a sharp blow, has been dropped, damaged, left outdoors, or dropped into water, do not use it.
14. Do not attempt any modification or repair by yourself and ensure that any repair is conducted only by appropriately qualified technician.

Obsah je uzamčen

**Dokončete, prosím, proces objednávky.
Následně budete mít přístup k celému dokumentu.**



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

**) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!