


**B0524B** | AlphaQ 10**B0524W** | AlphaQ 10

GB	Powerbank
CZ	Powerbank
SK	Powerbank
PL	Powerbank
HU	Powerbank
SI	Powerbank
RS HR BA ME	Powerbank
DE	Powerbank
UA	Powerbank
RO	Powerbank
LT	Energijos talpykla
LV	Ārējais akumulators
EE	Akupank
BG	Външна батерия

**CE**[www.emos.eu](http://www.emos.eu)

## GB | Powerbank

### User manual:

#### Specifications:

Capacity:	10 000 mAh (37.0 Wh)
Accumulator type:	Li-Po 3.7 V
Max. input current:	DC 5 V/2 A; 9 V/2 A; 12 V/1.5 A
Max. output current:	DC 5 V/3 A; 9 V/2 A; 12 V/1.5 A**
Dimensions:	138 × 68 × 16 mm
Weight:	220 g
Operating temperature:	+5 °C ~ 40 °C
Charging time:	4 hours (approximately)*

\*The above charging time may differ depending on ambient conditions.

\* USB power adapter not included.

\* Valid when using a USB adapter or power supply providing max. input current (PD 18 W nebo QC 3.0).

\*\* When using both USB outlets at the same time, max. output of the power bank is only 5 V/3 A.

#### Powerbank battery status indicator:

- To check the powerbank battery level, please press the button on the powerbank.
- The LED indicators will glow during the charging of a connected device the same way to indicate the residual capacity of the powerbank.

Number of glowing LEDs	● ○ ○ ○	● ● ○ ○	● ● ● ○	● ● ● ●
Battery level	0 % ~ 25 %	25 % ~ 50 %	50 % ~ 75 %	75 % ~ 100 %

#### Powerbank charging status indicator:

Glowing/ Flashing LEDs	⚡ ○ ○ ○	● ⚡ ○ ○	● ● ⚡ ○	● ● ● ⚡	● ● ● ●
Battery level	0 % ~ 25 %	25 % ~ 50 %	50 % ~ 75 %	75 % ~ 100 %	100 %*

\*The LED indicators will glow, after charging of the powerbank is complete.

- To extend the battery lifetime, please try to keep its capacity level in the range of 25–75 %.

Supported devices: tablets, mobile phones, cameras, camcorders, MP3 players, GPS navigation, soundboxes.

First charging may take longer than stated.

You can monitor the status of the battery and the process of charging using the LED indicator.

Carefully read the user manual before use.

It is normal that the cover of the power bank warms up during charging and discharging. It will return to room temperature after the process is complete.

If charging does not begin within 3 seconds, unplug the power bank and plug it in again.

Disconnect all cables after charging. The power bank will turn off automatically.

You can use any of the enclosed cables (if included), or any good quality USB cable to charge and use the power bank.

To achieve the shortest charging time possible, use a USB adapter and cable that can carry current equal or higher than the one stated as input current for the power bank.



This device is not intended for use by persons (including children) whose physical, sensory or mental disability or lack of experience and expertise prevents safe use, unless they are supervised or instructed regarding the use of the appliance by a person responsible for their safety.

Protect the product from humidity, water or other liquids, heat or sources of any strong radiation.

Do not disassemble, short-circuit or bend the product and protect it against sudden impacts or heavy objects.



Do not dispose with domestic waste. Use special collection points for sorted waste. Contact local authorities for information about collection points. If the electronic devices would be disposed on landfill, dangerous substances may reach groundwater and subsequently food chain, where it could affect human health.

EMOS spol. s r. o. declares that the AlphaQ 10 is in compliance with the essential requirements and other relevant provisions of Directive. The device can be freely operated in the EU. The Declaration of Conformity can be found at <http://www.emos.eu/download>.

## CZ | Powerbank

### Uživatelská příručka:

#### Specifikace:

Kapacita:	10 000 mAh (37 Wh)
Typ akumulátoru:	Li-Po 3,7 V
Max. vstupní proud:	DC 5 V/2 A; 9 V/2 A; 12 V/1,5 A
Max. výstupní proud:	DC 5 V/3 A; 9 V/2 A; 12 V/1,5 A**
Rozměry:	138 × 68 × 16 mm
Hmotnost:	220 g
Provozní teplota:	+5 °C ~ 40 °C
Doba nabíjení:	4 hodiny (přibližně)*

\* Výše uvedená doba nabíjení se může lišit v závislosti na okolních podmínkách.

\* USB napájecí adaptér není součástí balení.

\* Platí při použití USB adaptéru nebo zdroje poskytující max. vstupní proud (PD 18W nebo QC 3.0).

\*\* Při použití obou USB výstupů najednou je max. výstup powerbanky pouze 5 V / 3 A.

#### Ukazatel stavu baterie powerbanku:

- Pro zjištění stavu baterie powerbanku stiskněte LED tlačítko na powerbanku.

# Obsah je uzamčen

**Dokončete, prosím, proces objednávky.  
Následně budete mít přístup k celému dokumentu.**



**Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:**

1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne\*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

*\*) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!