


# DENON<sup>®</sup>

## DHT-S716H

NETWORK SOUND BAR

# Owner's Manual



|  |           |  |           |
|--|-----------|--|-----------|
| <b>Introduction</b>                        | <b>6</b>  | <b>Setting up your first DHT-S716H</b>     | <b>24</b> |
| <b>Before your begin</b>                   | <b>7</b>  | <b>Adding more HEOS devices</b>            | <b>25</b> |
| System requirements                        | 7         | Adding wired HEOS devices                  | 25        |
| Network requirements                       | 7         | Adding wireless HEOS devices               | 25        |
| Controller requirements                    | 8         | <b>Connecting devices</b>                  | <b>26</b> |
| Getting to know your DHT-S716H             | 9         | Connecting to your TV                      | 26        |
| Front panel                                | 11        | HDMI connection                            | 26        |
| Controls                                   | 12        | Setting the HDMI control function          | 26        |
| Bottom                                     | 13        | Disable your television's speakers         | 27        |
| Back panel                                 | 14        | Playing HDMI (ARC) - Best choice           | 28        |
| Remote control unit                        | 16        | Playing HDMI (without ARC) - Better choice | 29        |
| <b>Placing your DHT-S716H</b>              | <b>17</b> | Connecting an other devices                | 30        |
| Tabletop                                   | 17        | Connecting to your HDMI equipment          | 30        |
| How to attach the feet                     | 17        | Connecting an audio playback device        | 30        |
| IR repeater                                | 18        | Connecting a USB storage device            | 31        |
| Wall-Mounting                              | 19        | IR repeater                                | 31        |
| Before using the remote control unit       | 20        | Pairing a DSW-1H and Surrounds             | 32        |
| Replacing the battery                      | 20        | Pairing the DSW-1H                         | 33        |
| Operating range of the remote control unit | 21        | Adding surround speakers                   | 33        |
| Powering your DHT-S716H                    | 22        | Unpairing DSW-1H and Surrounds             | 34        |
| Getting the HEOS app                       | 23        |  |           |



|   |           |   |    |
|---|-----------|---|----|
| <b>Using your DHT-S716H</b>                             | <b>35</b> | Playing music stored on your mobile device            | 48 |
| HEOS account  | 35        | Playing music from your networked PC or NAS           | 49 |
| What is a HEOS account?                                 | 35        | Streaming an external audio device to any HEOS device | 50 |
| Why do I need a HEOS account?                           | 35        | Playing music from a USB device                       | 51 |
| Signing up for a HEOS account                           | 35        | Playing music from Bluetooth device                   | 52 |
| Selecting a room/device                                 | 35        | Pairing the HEOS device with your Bluetooth devices   | 52 |
| Listening to the same music in multiple rooms           | 36        | Playing from streaming music services                 | 53 |
| Grouping rooms  | 36        | Adding a music service                                | 53 |
| Ungrouping rooms  | 37        | Changing music service settings                       | 53 |
| Grouping all rooms (party mode)                         | 38        | Managing inputs                                       | 54 |
| Ungrouping all rooms                                    | 39        | Changing the name of the inputs                       | 54 |
| Selecting the music track or station from music sources | 40        | Hiding an input                                       | 54 |
| Rearranging the now playing queue                       | 42        | Managing your phone                                   | 55 |
| Deleting songs from the play queue                      | 42        | Using the favorite                                    | 55 |
| Deleting all songs from the play queue                  | 43        | Adding to HEOS favorite                               | 55 |
| Saving playlists  | 43        | Deleting station from the HEOS favorite               | 55 |
| Quick Select function                                   | 44        |   |    |
| Watching TV   | 45        |   |    |
| Watching other device                                   | 46        |   |    |
| Listening to radio                                      | 47        |   |    |



# Obsah je uzamčen

**Dokončete, prosím, proces objednávky.**

**Následně budete mít přístup k celému dokumentu.**



**Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:**

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne\*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

*\*) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!