

ROVUS®



USER MANUAL


This product is only suitable for well insulated spaces or occasional use.

VENTUS SMARTAIR PLUS
MODEL NO.: GS-XH026-B


EN.....	3	LV.....	55
AL.....	7	ME.....	59
BG.....	12	MK.....	63
BIH.....	18	PL.....	68
CZ.....	23	RO.....	73
EE.....	27	RS.....	78
HR.....	32	RU.....	82
HU.....	37	SI.....	87
KS.....	41	SK.....	92
KZ.....	46	UA.....	96
LT.....	51		

(EN) PICTURES / (AL) FOTOGRAFIN / (BG) ИЛЮСТРАЦИИ / (BIH) SLIKE / (CZ) OBRÁZKY / (EE) JOONISED / (HR) SLIKE / (HU) KÉPEK / (KS) FOTOGRAFIN / (KZ) СУРЕТТЕР / (LT) PAVEIKSLIAUKAI / (LV) ATTĒLI / (MD) IMAGINI / (ME) SLIKE / (MK) СЛИКИ / (PL) RYSUNKI / (RO) IMAGINI / (RS) SLIKE / (RU) RYSUNKI / (SI) SLIKE / (SK) OBRÁZKY / (UA) МАЛЮНКИ


Picture 1




Picture 2




Picture 3




Picture 4




Picture 5




Picture 6




Picture 7




Picture 8



Picture 8



Picture 10



EN

Please read this manual thoroughly before using and save it for future reference. This product is only suitable for well insulated spaces or occasional use.

WARNINGS

1. Before use make sure that power supply corresponds to the one listed on rating plate.
2. This device is intended for household use indoor and dry use only.
3. Do not use outdoors or on wet surfaces. Do not use in bathrooms, laundry areas or similar indoor locations. Never locate the appliance where it may fall into a bath or other water container. Do not use or store where it may get wet or in the immediate surroundings of a bath, a shower, or a swimming pool.
4. Before use, place the product on hard, flat, stable and dry surface.
5. Slight odors are possible at beginning of usage until device reaches its thermal stability.
6. This device is equipped with a grounded plug. Please ensure the wall outlet in your house is well earthed.
7. When used in heating mode the device is hot when in use and for a short period after use. To avoid burns, do not let bare skin touch hot surfaces. When moving the appliance hold it by the handle.
8. Keep combustible materials, such as furniture, pillows, bedding, papers, clothes and curtains, at least 1m from the front of the appliance and keep them away from the sides and rear when the appliance is plugged in.
9. Do not allow to be used as a toy. Close attention is necessary when used by or near children. Children of less than 3 years should be kept away unless continuously supervised. Children should be supervised to ensure that they do not play with the appliance and remote control.
10. This device can be used by children aged from 8 years and above as well as by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they

Obsah je uzamčen

Dokončete, prosím, proces objednávky.

Následně budete mít přístup k celému dokumentu.



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

**) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!