

LED DECORATION

ZY2268 ZY2271 ZY2274 ZY2291
ZY2269 ZY2272 ZY2289
ZY2270 ZY2273 ZY2290


GB	LED decoration
CZ	LED dekorace
SK	LED dekorácie
PL	Dekoracje LED
HU	LED-ES dekoráció
SI	LED okrasek
RS HR BA ME	Ukrasne LED lampice
DE	LED-Dekoration
UA	Світлодіодна декорація
RO	Decorațiuni LED
LT	LED dekoracija
LV	LED gaismu dekorācija
EE	LED dekoratsioon
BG	LED декорация



www.emos.eu

**Type / Typ / Typ / Typ / Típus / Nasvet / Tip
/ Typ / тип / Tip / Tipos / Tips / Tüüp / Тип**

LED DECORATION	ZY2268	ZY2273
	ZY2269	ZY2274
	ZY2270	ZY2289
	ZY2271	ZY2290
	ZY2272	ZY2291



GB LED decoration

Safety Instructions

Do not under any circumstances put the device into operation while it is still in packaging! The product is designed for non-commercial use in the household. Like any electric device, the device must be kept out of reach of children.

Protect the product from falls or powerful shocks and vibrations. Do not open the product. Stop using the product if it becomes damaged. Immediately replace discharged batteries and dispose of them in accordance with valid regulations.

Do not modify the product in any way. Doing so voids the warranty. Children should be supervised by an adult to ensure they do not play with the device. Immediately dispose of packaging material in accordance with valid local regulations on waste disposal.

Warning - Batteries

Always use batteries of the correct size and quality class that best fit the purpose. Make sure the batteries are inserted correctly and that polarity is taken into account (+ and -).

Do not bridge the batteries. Do not recharge the batteries. Do not throw the batteries into a fire. Keep the batteries out of reach of children. Do not allow children to replace the batteries unsupervised. Remove the batteries if the product will not be used for an extended period of time. Remove and dispose of used batteries.

Replacing Batteries

The product must be turned off (button in the OFF position). Open the battery compartment on the bottom side of the candle. Insert batteries of the correct type (AA / AAA / CR2032) with the correct polarity.

Close the battery compartment.

Emos spol s.r.o. declares that the LED Candle with Timer is in compliance with the essential requirements and other relevant provisions of Directive. The device can be freely operated in the EU. The Declaration of Conformity can be found at <http://www.emos.eu/download>.

Obsah je uzamčen

Dokončete, prosím, proces objednávky.

Následně budete mít přístup k celému dokumentu.



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

**) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!