

AKAI AESP-312

EN - ENGLISH

AKAI *espresso*

Safety Precautions

The significant contents concerning safety must be read carefully to protect you and others from injury and damage. The wrong operation may cause two degrees of danger:



WARNING! THE CONTENTS THAT MAY CAUSE DEATH OR SERIOUS INJURY.



CAUTION! THE CONTENTS THAT MAY CAUSE DANGER.



WARNING!

- Be careful about scalding.
- Warning: avoid spillage on the connector.
- Warning: potential injury from misuse
- The heating element surface is subject to residual heat after use.
- The machine shall not be placed in a cabinet when in use.
- Cleaning and user maintenance shall not be made by children without supervision.
- This machine can be used by children aged from 8 years and above if they have been given supervision or instruction concerning use of the machine in a safe way and if they understand the hazards involved. Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised. Keep the machine and its cord out of reach of children aged less than 8 years.
- If the machine is used with the AC adaptor, it can be used in household and similar applications such as:
 - staff kitchen areas in shops, offices and other working environments;
 - farm houses;
 - by clients in hotels, motels and other residential type environments;
 - bed and breakfast type environments.
- The machine must not be immersed.
- The machine must not be used on an aircraft.
- Warning: To recharge the battery, only use the detachable supply unit provided with this machine.
- This machine is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge unless they have been given supervision or instruction concerning use of the machine by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the machine.
- The machine is only to be used

EN

with the power supply unit provided with the machine, it must only be supplied at safety extra-low voltage corresponding to the marking on the machine.

- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- This machine can be used in the car. Do not operate the machine while driving.
- Never touch the heating disc and steam vent of machine when and immediately after this machine is used for making and heating the coffee.
- Special care needs to be taken to prevent children from touching the machine (for fear of scalding).
- The air vent water lid must be installed well when the machine is being used for making and heating the coffee.
- The water in the water cavity, if excessive, may overflow (for fear of scalding).
- Never shake the machine body during use. General safety instructions, the machine may topple and fall (for fear of scalding).
- The filled water must not be over the MAX (maximum) water level line marked inside of the water cavity of the machine. The water may overflow.



WARNING! CONDITION OF POWER CABLE, POWER PLUG, AND BATTERY

- Use the rated 7A/100-240V power socket separately. When this machine shares the same multi-purpose socket with other

electric machines, abnormal heating may occur (risk of ignition and fire). If the multi-purpose socket is used, its rated current needs to be above 7A, and it needs to be used separately.

- Insert the power plug into the socket to the end (risk of ignition and fire caused by electric shock and short circuit).
- Remove the dust on the power plug periodically. Bad contact caused by moisture and other reasons (risk of ignition and fire caused by bad contact). Wipe the power plug with a dry cloth.
- Never unplug the power plug with wet hands (risk of electric shock).
- Never destroy the power cable or power plug. Without permission, never machine, damage, excessively bend, forcefully pull or twist the power cable or power plug, place the power cable or power plug near a heating object or under heavy load, or squeeze the power cable or power plug (potential risk of ignition and fire caused by electric shock and short circuit).
- If the power cable or power plug is damaged, or still loose after they are inserted into the socket, never use the machine (risk of ignition and fire caused by electric shock and short circuit).
- Never disassemble or damage the battery (potential risk of ignition and fire caused by short circuit of battery).
- Never place the battery on a flame (maximum temperature rise 30k) (potential risk of ignition and fire caused by a battery).



WARNING! TO AVOID ACCIDENTS, THE FOLLOWING MUST BE FOLLOWED:


- Children must not use the machine independently. Never use the machine at the position that any children can reach (risk of scalding, electric shock or injury).
- Never disassemble, repair or modify this machine (risk of scalding, electric shock or injury). For the repair of the machine, please consult the dealer.
- The machine must not be immersed in water, or splashed by water. (Risk of ignition caused by electric shock and short circuit).
- In case of abnormality or fault, stop the machine immediately, and unplug the plug from the power socket (possibility of smoking, ignition, electric shock, scalding, and injury).
- Abnormality and fault cases:
 - The power cable or power plug is deformed, discolored or damaged;
 - A part of the power cable or the power plug becomes hot;
 - In case of moveable power cable, the machine is powered on and off intermittently;
 - The machine body becomes abnormally hot, or has a burning smell;
 - The application body has abnormal sound during operation.
- For maintenance and repair of the machine, please contact the after-sales department of the Company.



CAUTION! NEVER USE THE MACHINE UNDER THE FOLLOWING CONDITIONS:



CAUTION!

- Never use the machine near a fire (risk of fire).
 - Notice the use of a power plug.
 - To unplug the power plug, it is necessary to hold the power plug, not the power cable (risk of fire caused by electric shock and short circuit).
 - Be careful about scalding or injury.
 - Never open the air vent water lid during or immediately after heating before the water in the water cavity is pumped out (risk of scalding).
 - Never touch the hot water, PTC (positive temperature coefficient) or other high-temperature position during or immediately after use of the machine (risk of scalding).
 - Don't touch the piercing knife during the use of the machine or when cleaning the interior of the capsule insert because the sharp knife may hurt your finger.
-  **CAUTION!**
- The machine can be cleaned after it cools down (risk of scalding).
 - Notice to wash the capsule cap and drinking cup and wipe them dry before and after using the machine; the residual coffee, if any, may cause abnormal taste and food decomposition
 - The machine body can be cleaned by wiping with a cloth.
 - During use, please use clean drinking water for heating and pumping because the sundries or particles in the water, if any, may produce scale deposits inside the machine or damage the water pump.

Obsah je uzamčen

Dokončete, prosím, proces objednávky.

Následně budete mít přístup k celému dokumentu.



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

**) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!