

SAMSUNG

USER MANUAL



(

QLED 8K

₩ 900T	\bigcup_{800T}	₩ 700T

Ιh	ank yo	ou for pi	ırchasing	this S	Samsung	prod	uct.
----	--------	-----------	-----------	--------	---------	------	------

To receive more complete service, please register your product at www.samsung.com

Model ______ Serial No. _____







Before Reading This User Manual

This TV comes with this user manual and an embedded e-Manual. Before reading this user manual, review the following:

	User Manual	Read this provided user manual to see information about product safety, installation, accessories, initial configuration, and product specifications.
Service Servic	e-Manual	For more information about this TV, read the e-Manual embedded in the product. • To open the e-Manual,

On the website (www.samsung.com), you can download the manuals and see its contents on your PC or mobile device.

Learning the e-Manual's assistance functions

• Some menu screens cannot be accessed from the e-Manual.

Q	Search	Select an item from the search results to load the corresponding page.	
A-Z	Index	Select a keyword to navigate to the relevant page. - The menus may not appear depending on the geographical area.	
<u></u>	Site Map	It displays the lists for each item in e-Manual.	
()	Recently Viewed Topics	Select a topic from the list of recently viewed topics.	

Learning the functions of the buttons that appear on e-Manual topic pages

	Try Now	Allows you to access the corresponding menu item and try out the feature right away.
8	Link	Access an underlined topic referred to on an e-Manual page immediately.











Warning! Important Safety Instructions

Please read the Safety Instructions before using your TV.

Refer to the table below for an explanation of symbols which may be on your Samsung product.

CAUTION			Class II product: This symbol indicates that a safety connection to electrical earth (ground) is not required. If this symbol is not present on a product with a mains lead, the product MUST have a reliable connection to protective earth (ground).	
RISK OF ELECTRIC SHOCK. DO NOT OPEN.				
CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). THERE ARE NO USER SERVICEABLE PARTS INSIDE. REFER ALL SERVICING TO QUALIFIED PERSONNEL.		\sim	AC voltage: Rated voltage marked with this symbol is AC voltage.	
This symbol indicates that high voltage is present inside. It is dangerous to make any kind of contact with any internal part of this product.		===	DC voltage: Rated voltage marked with this symbol is DC voltage.	
<u>Î</u>	This symbol indicates that this product has included important literature concerning operation and maintenance.	<u> </u>	Caution. Consult instructions for use: This symbol instructs the user to consult the user manual for further safety related information.	

- The slots and openings in the cabinet and in the back or bottom are provided for necessary ventilation. To ensure reliable operation of this apparatus and to protect it from overheating, these slots and openings must never be blocked or covered.
 - Do not place this apparatus in a confined space, such as a bookcase or built-in cabinet, unless proper ventilation is provided.
 - Do not place this apparatus near or over a radiator or heat register, or where it is exposed to direct sunlight.
 - Do not place vessels (vases etc.) containing water on this apparatus, as this can result in a fire or electric shock.
- Do not expose this apparatus to rain or place it near water (near a bathtub, washbowl, kitchen sink, or laundry tub, in a wet basement, or near a swimming pool, etc.). If this apparatus accidentally gets wet, unplug it and contact an authorised dealer immediately.
- This apparatus uses batteries. In your community, there might be environmental regulations that require you to dispose of these batteries properly. Please contact your local authorities for disposal or recycling information.
- Do not overload wall outlets, extension cords, or adaptors beyond their capacity, since this can result in fire or electric shock.
- Power-supply cords should be placed so that they are not likely to be walked on or pinched by items placed upon or against them. Pay particular attention to cords at the plug end, at wall outlets, and at the point where they exit from the appliance.

 \bigoplus







Obsah je uzamčen

Dokončete, prosím, proces objednávky.

Následně budete mít přístup k celému dokumentu.



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.
 - *) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.
- 2) Pak jsou tady "roboti", kteří se přiživují na naší práci a "vysávají" výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!