

# Hisense

---

2.1 Channel Sound Bar Home Theater System  
Model: HS214



---

## USER MANUAL

---



Before using the sound bar, please read this manual thoroughly and retain it for future reference.

- |    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|
| EN | FR | DE | IT | SP | SL | HR | NL |
| CZ | SK | HU | PT | SR | MK | SQ |    |


## Contents


EN

<b>Important Safety Instructions</b>	<b>3</b>
Safety .....	3
Warning.....	4
<b>Package Contents</b>	<b>5</b>
<b>Product Diagram</b>	<b>6</b>
Main Unit .....	6
Remote Control.....	7
<b>Instructions</b>	<b>7</b>
Prepare the Remote Control .....	7
Replace the Remote Control Battery.....	7
Precautions Concerning Batteries .....	7
Placement and Mounting.....	8
Wall Mounting (if using option-B).....	8
<b>Connections</b>	<b>9</b>
Connect to COAXIAL Socket .....	9
Connect to HDMI ARC Socket .....	9
Connect to AUX Socket .....	9
Connect to OPTICAL Socket .....	10
Connect Power .....	10
<b>Basic Operation</b>	<b>10</b>
Standby/On .....	10
Auto Wake .....	10
How to Enable Auto Wake .....	10
Automatic Power Off Function .....	10
Select Modes .....	10
Adjust the Volume .....	11
Select a Preset Sound Effect .....	11
<b>OPTICAL / COAXIAL / HDMI ARC / AUX Operation</b>	<b>11</b>
<b>Bluetooth Operation</b>	<b>11</b>
Pair Bluetooth-enabled Devices.....	11
Listen to Music from Bluetooth Device .....	12
<b>USB Operation</b>	<b>12</b>
<b>Troubleshooting</b>	<b>13</b>
<b>Specifications</b>	<b>14</b>


## Important Safety Instructions



 The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude as to constitute a risk of electric shock to persons.

 The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

### Safety

- 1 **Read these instructions** – All the safety and operating instructions should be read before this product is operated.
- 2 **Keep these instructions** – The safety and operating instructions should be retained for future reference.
- 3 **Heed all warnings** – All warnings on the appliance and in the operating instructions should be adhered to.
- 4 **Follow all instructions** – All operating and usage instructions should be followed.
- 5 **Do not use this apparatus near water** – The appliance should not be used near water or moisture – for example, in a wet basement or near a swimming pool and the like.
- 6 **Clean only with a dry cloth.**
- 7 **Do not block any ventilation openings.** Install in accordance with the manufacturer's instructions.
- 8 Do not install near any heat sources such as radiators, heaters, stoves, or other apparatus (including amplifiers) that produce heat.
- 9 Do not defeat the safety purpose of the polarized or grounding plug. A polarized plug has two blades with one wider than the other. A grounding plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- 10 Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- 11 Only use attachments/accessories specified by the manufacturer.
- 12  Use only with the cart, stand, tripod, bracket or table specified by the manufacturer, or sold with the apparatus. When a cart or rack is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
- 13 **Unplug** the apparatus during lightning storms or when unused for long periods of time.
- 14 Refer all servicing to qualified personnel. Servicing is required when the apparatus has been damaged in any way, such as power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the unit has been exposed to rain or moisture, does not operate normally, or has been dropped.
- 15  This equipment is a Class II or double insulated electrical appliance. It has been designed in such a way that it does not require a safety connection to electrical earth.
- 16 The apparatus shall not be exposed to dripping or splashing. No objects filled with liquids, such as vases, shall be placed on the apparatus.
- 17 Minimum distance around the apparatus for sufficient ventilation is 5cm.
- 18 The ventilation should not be impeded by covering the ventilation openings with items, such as newspapers, table-cloths, curtains, etc.
- 19 No naked flame sources, such as lighted candles, should be placed on the apparatus.
- 20 Batteries should be recycled or disposed of as per state and local guidelines.
- 21 The use of apparatus in moderate or tropical climates.

EN

# Obsah je uzamčen

**Dokončete, prosím, proces objednávky.**

**Následně budete mít přístup k celému dokumentu.**



**Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:**

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne\*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

*\*) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!