

# Fastbake breadmaker



Please read and keep these instructions



**fast**bake

## getting the best from your new breadmaker...

### **Accurate measuring is essential**

*It is essential to measure ingredient quantities carefully, even slight changes may effect loaf quality*

### **Yeast content**

*If loaf rises too high and then collapses ensure the ingredients were measured accurately. If problem persists, reduce yeast by half a teaspoon*

**2year**  
guarantee

UK  
08450 777700  
**HELPLINE**  
1800 409119  
EFE



# Important safety instructions

---

The use of any electrical appliance requires the following of basic common sense safety rules.

Primarily there is danger of personal injury and secondly the danger of damage to property and the appliance. These are indicated in the text by the following two conventions:

**WARNING: Danger of personal injury**

**IMPORTANT:** Damage to the appliance

In addition we offer the following essential safety advice.

## Location

---

- Always locate your appliance away from the edge of a worktop.
- Ensure that the appliance is used on a firm, flat surface.
- Do not use outdoors.

## Mains lead

---

- The mains lead should reach from the socket to the base unit without straining the connections.
- Do not let the mains lead hang over the edge of a worktop where a child could reach it.
- Do not let the lead run across an open space e.g. between a low socket and table.
- Do not let the lead run across a cooker or toaster or other hot area which might damage the cable.

## Your safety

---

- **WARNING: Do not touch hot surfaces.** Use oven mitts or oven gloves when removing the hot bread pan. Do not cover the steam vent openings under any circumstances.
- **WARNING: Avoid contact with moving parts.**
- To protect against electrical shock, do not immerse cord or plug in water or other liquid.
- Extreme caution must be observed when moving an appliance with hot contents.
- Do not use breadmaker for storage purposes nor insert any utensils, as they may create a fire or electric shock hazard.
- Do not use use the appliance with wet or moist hands.

## Children

---

Never allow a child to operate this appliance. Children are vulnerable in the kitchen particularly when unsupervised and if appliances are being used or cooking is being carried out.

Teach children to be aware of dangers in the kitchen, warn them of the dangers of reaching up to areas where they cannot see properly or should not be reaching.

## Other safety considerations

---

- If the mains lead of this appliance is damaged do not use it. The lead may only be replaced by Morphy Richards Ltd or an agent of the company, since special purpose tools are required. Telephone Morphy Richards helpline for advice.
- The use of accessory attachments not recommended by the manufacturer may cause damage to the breadmaker.
- Do not place the appliance on or near heat sources such as gas or electric stove ovens, or burners.
- To avoid damaging the appliance, do not place the baking pan or any object on top of the unit.
- Do not clean with scouring pads. Do not wash the baking pan, kneading blade measuring cup or spoon in a dishwasher.
- Keep the appliance and the cable away from heat, direct sunlight, moisture, sharp edges and the like.
- The baking pan must be in place prior to switching on the appliance.
- Always remove the plug from the socket whenever the machine is not in use, when attaching accessory parts, cleaning the machine or whenever a disturbance occurs. Pull on the plug, not the cable.

## Operating instructions

---

Important safety instructions	2
Introduction	4
Before first use	4
Electrical requirements	4
About this breadmaker	4
About the recipes	4
Components	5
Control panels buttons, display and functions	6
Program descriptions	7
Using your breadmaker	8
Using the timer	9
Beeper	9
Power interruption	9
Slicing and storing bread	9
Care and cleaning	10
Storing the unit	10
Know your ingredients	11
Measuring ingredients	12
Ingredient temperatures	13
Creating your own yeast breads	13
Special glazes for yeast breads	13
Other tips	13

## Recipes

---

<b>Basic breads</b>	
Basic white bread	14
Softgrain bread	14
Brown loaf	14
Italian herb bread	14
Cheese & onion bread	14
Raisin bread	14
Sun-dried tomato loaf	14
Malt loaf	15
<b>French bread</b>	15
<b>Wholewheat breads</b>	
Wholewheat bread	15
Granary loaf	15
<b>Quick setting</b>	
Banana and nut bread	15
Porridge oats bread	15
<b>Sweet</b>	
Mixed fruit loaf	15
Chocolate bread	16
<b>Fastbake I</b>	
Fastbake small white	16
<b>Fastbake II</b>	
Fastbake large white	16
<b>Dough recipes</b>	
White bread rolls	16
Wholewheat bread rolls	16
Hot cross buns	16
Pizza base	17
<b>Jams</b>	
Marmalade	17
Raspberry and apple	17
<b>Cake recipes</b>	
Standard cake mix	17
Mixed fruit cake	17
<b>Sandwich</b>	
Sandwich loaf	18
Softgrain sandwich loaf	18
<b>Further information</b>	
Baking cycle times	19
Need help? (questions and answers)	20
Troubleshooting	22

# Obsah je uzamčen

**Dokončete, prosím, proces objednávky.**

**Následně budete mít přístup k celému dokumentu.**



**Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:**

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne\*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

*\*) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!