

LAMAX

ELECTRONICS

User manual

LAMAX DRIVE C3



Contents

Introduction	1
LAMAX DRIVE C3 car camera features and functions	1
Pack contents	1
Product picture	1
Product installation	2
Quick functions	2
Icons annotation	2
Using the LAMAX DRIVE C3 car camera	3
1) Inserting a micro SDHC card.....	3
2) Power.....	3
3) Turning the camera on and off.....	3
4) Changing modes and menu navigation.....	3
5) Recording / taking photos / gallery.....	3
6) Deleting the entries on the camera.....	3
7) Protecting the files on the camera.....	3
8) Connecting to a PC.....	4
LAMAX DRIVE C3 car camera settings – video mode	4
1) Video resolution.....	4
2) Time-lapse.....	4
3) Exposure.....	4
4) Motion detection.....	4
5) Audio recording.....	4
6) Display data.....	4
7) G-sensor.....	4
LAMAX DRIVE C3 car camera settings – photo mode	5
1) Image resolution.....	5
2) Photo burst.....	5
3) Quality.....	5
4) Sharpness.....	5
5) White balance.....	5
6) ISO.....	5
7) Exposure.....	5
8) Image stabilization.....	5
9) Preview.....	5
10) Display data.....	5
LAMAX DRIVE C3 car camera basic settings	5
1) Parking mode.....	5
2) Date/Time.....	5
3) Automatic power off.....	5
4) LCD off.....	5
5) Key sound.....	5
6) Language.....	6
7) TV mode.....	6
8) Frequency.....	6
9) LED diode.....	6
10) Format.....	6
LAMAX DRIVE C3 car camera parameters	7
Safety measures	7
Precautions and notices	8
Safety precautions	8
Caring for your device	8
Other information	9
Declaration of Conformity	9

Introduction

Thank you for purchasing the LAMAX DRIVE C3 car camera. You are now the owner of a reliable companion for your car journey. A complete multilingual manual can be downloaded from the product page at www.lamax-electronics.com.

LAMAX DRIVE C3 car camera features and functions

- Interpolated full HD video 1920 x 1080
- G-sensor
- Loop recording
- Parking mode
- Motion sensor
- Multilingual menu
- LED light
- Video lock at the touch of a button

Pack contents

- LAMAX DRIVE C3 car camera
- Power cable
- USB cable
- Camera suction mount
- Camera 3M stick mount
- Quick Guide

Product picture

1. ON/OFF
2. Menu
3. OK (shutter)
4. Down arrow
5. Up arrow
6. Mode
7. Parking mode
8. Micro SDHC card slot



Obsah je uzamčen

Dokončete, prosím, proces objednávky.

Následně budete mít přístup k celému dokumentu.



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

**) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!