


SINGER®

5, 6, 8, 10 Stitch Sewing Machine



Instruction Manual



5, 6, 8, 10 Stitch Sewing Machine

Table of Contents

1. Getting To Know Your Machine

[Principal Parts](#)

[Accessories](#)

[Important Safety Instructions](#)

2. Getting Ready To Sew

[Operating the Machine](#)

[Choosing and Changing Needles](#)

[Changing Presser Feet](#)

[Changing the Needle Plate](#)

[Attaching the Feed Cover](#)

[Removing and Replacing the](#)

[Extension Table](#)

[Fabric Thread and Needle Table](#)

[Winding a Bobbin](#)

[Inserting a Bobbin](#)

[Threading the Machine](#)

[Raising the Bobbin Thread](#)

3. Straight Stitching

[Stitch Width Selector](#)

[Needle Position Selector](#)

[Stitch Length Selector](#)

[Reverse Stitch Button](#)

[Adjusting Thread Tension](#)

[Sewing a Seam](#)

[Starting a seam](#)

[Darning](#)

[Quilting](#)

[Inserting a Zipper](#)

4. Zig-Zag Stitching

[Stitch Pattern Selector](#)

[Needle Position Selector](#)

[Stitch Width Selector](#)

[Adjusting Stitch Length](#)

[Needle Thread Tension](#)

[Zig-Zag Zag Stitch](#)

[Blindstitch](#)

[Ladder Seams](#)

[Multi Stitch Zig-Zag](#)

["M" Stitch](#)

5. Four Step Buttonhole

6. Free-Arm Sewing

7. Twin Needle Sewing

8. Caring For Your Machine

[Removing and Replacing the Bobbin Case](#)

[Changing the Light Bulb](#)

[Cleaning the Machine](#)

[Lubricating the Machine](#)

Additional Accessories

[Attaching a Button](#)

[Performance Checklist](#)

SINGER® 5, 6, 8, 10 Stitch Sewing Machine

Congratulations

As the owner of a new Singer sewing machine, you are about to begin an exciting adventure in creativity. From the moment you first use your machine, you will know you are sewing on one of the easiest to use sewing machines ever made.

In addition to the many familiar SINGER exclusives, like a removable extension table and a horizontal spool pin, this machine offers you these features:

- * Zig-zag stitching for buttonholes, mending and decorative stitches.
- * Flexi stitch patterns for sewing knitted and other stretch fabrics. (only for machines with 6, 8 and 10 stitches)
- * Built-in 4-step buttonholer that takes the difficulty out of making a buttonhole. (only for machines with 5, 6, 8 and 10 stitches)
- * Blindsitching for invisible hems. (only for machines with 5, 6, 8 and 10 stitches)
- * Easy to find "Letter-Coded" Accessories.
- * Drop in front bobbin for easy, quick bobbin replacement.

* Simple stitch length dial and push button reverse stitching.

* Snap on presser feet that are quickly removed and easily replaced.

* One-way needle insertion that makes it impossible to insert the needle incorrectly.

May we recommend that, before you start to use your sewing machine, you discover the many advantages and the ease of operation by going through this instruction book, step by step, seated at your machine.

To ensure that you are always provided with the most modern sewing capabilities, the manufacturer reserves the right to change the appearance, design or accessories of this sewing machine when considered necessary.

*A Trademark of The Singer Company

Copyright (c) 1992 Singer Sewing Machine Company

All rights reserved throughout the world.

Obsah je uzamčen

Dokončete, prosím, proces objednávky.

Následně budete mít přístup k celému dokumentu.



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

**) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!