




INSTRUCTIONS MANUAL

8-Speed Stand Mixer



MM-106W (White)

MM-106R (Red)

THIS PRODUCT IS FOR HOUSEHOLD USE ONLY!

**PLEASE READ THIS MANUAL THOROUGHLY BEFORE
FIRST USE AND SAVE IT FOR FUTURE REFERENCE.**

General Safety Instructions

Read the operating instructions carefully before using the appliance. Keep the instructions including the receipt and, if possible, the box with the internal packing. If you give this device to others, please also pass on the operating instructions.

Misuse of this appliance can damage the unit or injure the user. Assure the appliance is used for which it is designed; we refuse any responsibility for damages caused by incorrect use or bad manipulation.

- Check the voltage of the power supply in your home is suitable to the voltage shown on the rating label of this product.
- The safety instructions do not by themselves eliminate danger completely and proper accident prevention measure must always be used.
- The appliance is only for private use and for the envisaged purpose. This appliance is not fit for commercial use. Do not use outdoors. Keep away from sources of heat, direct sunlight, humidity (never dip it into any liquid) and sharp edges. Do not use the appliance with wet hands. If the appliance is humid or wet, unplug immediately.
- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning. If the appliance is not being used, remove any attached accessories.
- Do not operate the machine without supervision. Should you leave the workplace, always turn off machine.
- Check the appliance and the power cord for damage or deterioration on a regular basis. Do not use the appliance if it is damaged.
- Do not try to repair the appliance on your own. Always contact an the manufacture or qualified technician.
- Use only original spare parts.
- Avoid contacting moving parts. Keep hands, hair and clothing as well as spatulas and utensils away from attachments during operation.

- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or damaged in any manner. Contact Sunpentown for information on examination or repair.
- The appliance is not intended to be operated via an external timer or a separate remote –control system.
- Never immerse the base of the unit in water or any other liquid. Do not place in dishwasher.
- Be careful if hot liquid is poured into the processor or blender.
- Pay attention to the following “Special Safety Instructions”.
- In order to ensure your children’s safety, please keep all packaging (plastic bags, boxes, polystyrene etc.) out of their reach.

Caution! Do not allow small children to play with the packaging materials due to ***danger of suffocation!***

- In order to protect children or frail individuals from the hazards of electrical equipment, please ensure that this device is only used under supervision. This device is not a toy. Do not allow small children to play with it.
- No liability is accepted for damage due to improper use or the failure to observe operating instructions and safety notes.
- Be sure to turn the speed selector to OFF position after each use.

WARNING! This appliance has a polarized plug (one blade is wider than the other). The plug fits only one way into a polarized outlet. Do not defeat the safety purpose by modifying the plug in any way or by using an adapter. If the plug does not fully fit into the outlet, reverse the plug. If it still does not fit, contact an electrician.

Technical information

- Voltage/frequency: 120V~ 60Hz 550W
- Bowl capacity: 5.2 liters
- Blender (optional purchase) capacity: 1.5 liters

Obsah je uzamčen

Dokončete, prosím, proces objednávky.

Následně budete mít přístup k celému dokumentu.



Proč je dokument uzamčen? Nahněvat Vás rozhodně nechceme. Jsou k tomu dva hlavní důvody:

- 1) Vytvořit a udržovat obsáhlou databázi návodů stojí nejen spoustu úsilí a času, ale i finanční prostředky. Dělali byste to Vy zadarmo? Ne*. Zakoupením této služby obdržíte úplný návod a podpoříte provoz a rozvoj našich stránek. Třeba se Vám to bude ještě někdy hodit.

**) Možná zpočátku ano. Ale vězte, že dotovat to dlouhodobě nelze. A rozhodně na tom nezbohatneme.*

- 2) Pak jsou tady „roboti“, kteří se přiživují na naší práci a „vysávají“ výsledky našeho úsilí pro svůj prospěch. Tímto krokem se jim to snažíme překazit.

A pokud nemáte zájem, respektujeme to. Urgujte svého prodejce. A když neuspějete, rádi Vás uvidíme!